

T28

AT Command

Online Reference

Contents

1	Introduction	5
1.1	About this manual	5
1.2	Using this manual	6
1.3	Using the Ericsson Mobile Office Suite Telephone	7
	Data functions	7
	Facsimile functions	7
	Mobile Phone Manager	7
1.4	Communications programs	8
	Configuring third party communication programs	8
	Configure for V.25ter	8
	Locate a Mobile Phone Modem driver	8
	Configure the data communications program manually .	8
	Configure your facsimile communications program manually	9
2	Result and Error Codes	10
2.1	Result codes	10
	Final result codes from AT commands	10
	Result codes from call connections	12
	Format of the result codes	12
2.2	Error codes	13
	Report mobile phone failure (+CMEE)	13
	Report operational/access failure (+CMS)	14
	Service Report (+CR)	16
	Cellular Result Codes (+CRC)	16
3	AT Commands	17
3.1	Introduction to AT commands	17
3.2	Infrared Modem operating modes	17
3.3	Changing the Infrared Modem operating mode	18
	Operating in off-line command mode	19
	Switching to on-line data mode	19
	Switching back to off-line command mode	19
	Using AT commands during a data connection	20
	Switching from on-line command mode to on-line data mode	20
	Switching from on-line command mode to off-line command mode	

Contents

	20	
3.4	Operating the AT commands	21
	Entering a set command	21
	Entering an execute command	22
	Using read command to view the command settings	23
	Using test command to request command help	23
3.5	AT command list	24
	General AT commands	24
4	AT Commands Phone Terminal Terminated	37
4.1	Ensemble S1/B/E : GSM DTE-DCE Interface commands	37
4.2	Ensemble C2/C/E : Control and Identification	38
4.3	Ensemble S2/E : GSM Call Control	43
	Unsolicited Result Codes	47
4.4	Ensemble C3/E : Call Control	48
	Unsolicited Result Codes	51
4.5	Ensemble C4/E : Interface Commands	52
4.6	Ensemble S6/C/E : GSM Network Services	58
	Unsolicited Result Codes	91
4.7	Ensemble S8/C/E : GSM Facility Lock	97
4.8	Ensemble C9/C/E : Multi Mode Phones	102
4.9	Ensemble S9/C/E : GSM Mobile Equipment,Control and Status 105	
	Unsolicited Result Codes	139
4.10	Ensemble S11/C/E : GSM SMS and CBS PDU Mode	144
	Unsolicited Result Codes	164
4.11	Ensemble S14/E : GSM Digital Binary Ping Pong Mode	169
4.12	Ensemble S16/C/E : GSM Phonebook Commands	170
4.13	Ensemble S18/E : GSM Clock, Date and Alarm Handling 184	
4.14	Ensemble S19/E : GSM Subscriber Identification	186
4.15	Ensemble C20/C/E : Audio Control	187
	Unsolicited Result Codes	195
4.16	Ensemble S20/C/E : Ericsson Specific AT Commands for GSM 196	
	Unsolicited Result Codes	218
4.17	Ensemble C21/C/E : Accessory Menus	220

Contents

Unsolicited Result Codes	228
4.18 Ensemble C22/C/E : Accessory Authentication	231
4.19 Ensemble C24/C/E : Voice Call Control	233
4.20 Ensemble C25/E : ETSI 07.10 Multiplex Protocol	234
4.21 Ensemble C26/C/E : Accessory Identification	235
4.22 Ensemble C30/C/E : VAD Support for Vehicle HF 3V	238
Unsolicited Result Codes	243
4.23 Ensemble C31/C/E : Quick Menu	247
5 AT Commands Modem Terminated	249
5.1 Ensemble S1/B/E : GSM DTE-DCE Interface commands	249
5.2 Ensemble C2/B : Identification and Control	250
5.3 Ensemble S2/B : GSM Call Control	256
Unsolicited Result Codes	258
5.4 Ensemble C3/B : Call Control	259
5.5 Ensemble S3/B : GSM Data/Fax	264
5.6 Ensemble C4/B : Interface Commands	267
5.7 Ensemble S4/B : GSM Extended Error Reporting	284
5.8 Ensemble C6/B : Data Compression	285
Unsolicited Result Codes	288
5.9 Ensemble S10/B : GSM Mobile Equipment Error Control	289
5.10 Ensemble C18/B : Fax Class 1	290
5.11 Ensemble C19/B : Fax Class 2	297
6 Glossary	337
7 Index	346

1

Introduction

This Manual describes the operation of the AT commands supported by the T28 Telephone. The information here is not relevant for day-to-day operation of the Telephone, which is described in the User Manual supplied with the Ericsson Mobile Office Suite.

The On-line Reference Manual is for advanced users who require detailed information in order to:

- develop new communications software;
- add the T28 to an application's list of compatible modems;
- adjust the settings of their mobile telephone and modem.

1.1 About this manual

This manual is designed to supplement the Ericsson T28 Telephone User Manual.

All rights reserved.

© Ericsson Mobile Communications AB, 1998.

® Ericsson T28 and Ericsson Infrared Modem and Ericsson Mobile Office are Registered trademarks of Ericsson Mobile Communications AB.

® Windows is a registered trademark of the Microsoft Corporation.

All other registered trademarks used in this document are also acknowledged.

1.2 Using this manual

The standard text in this manual is modified to distinguish between the text displayed on the screen, typed instructions and examples of command dialog. The distinctions are as follows:

- 1) Typed commands and option values are written in bold text.

For example: **S2=<esc>** Options: <esc> **0 - 127**

- 2) Any key strokes are written in bold text in brackets.

For example: **<CR>**

- 3) Examples of command dialogue, including keyboard entries and on-screen responses, are written in Courier text.

For example:

```
AT+CBC=?
```

```
+CBC: ( 0 , 1 ) , ( 0 - 100 )
```

```
OK
```

- 4) The default setting used by a command is indicated by **bold** text.

For example: **Default = 0**

1.3 Using the Ericsson Mobile Office Suite Telephone

The telephone connects to your computer via an Infrared Modem by means of a digital infrared link.

Data functions

Transmission speed conforms to the ITU-T standard V.22bis which facilitates data transfer at 2,400, 4,800 and 9,600 bits/s. By implementing data compression the transmission speed can be increased to a theoretical maximum data throughput of 38,400 bits/s. between computers.

Facsimile functions

Facsimile operation, at 2,400, 4,800, 7,200 and 9,600 bits/s. conforms to Service Class 1 and the proposed Service Class 2 standards.

Short Message Service

The telephone supports the short message service (SMS) with messages up to 160 characters long, according to ETSI (GSM) 07.05 using the GSM character set.

Mobile Phone Manager

The Infrared Modem supports commands for access of the mobile phone book and short message service according to ETSI (GSM) 07.05 and 07.07.

1.4 Communications programs

Please refer to the User Manual for instructions on the installation and use of the Ericsson Infrared Modem software drivers.

Configuring third party communication programs

If you want to use a communication program which does not include the Ericsson Infrared Modem in the list of supported hardware, the following options are suggested:

Configure for V.25ter

The Infrared Modem supports the V.25ter command set. If your communication program can generate and support a V.25ter command, the Infrared Modem does not require the installation of a specific driver.

Locate a Mobile Phone Modem driver

A Mobile Phone Modem driver for your communication program may be available on either the Ericsson Infrared Mobile Phone Modem utilities disk or from one of the on-line services.

Configure the data communications program manually

To configure your data communications program manually:

1. Select a generic Mobile Phone Modem driver from the list of available Mobile Phone Modem drivers.
2. Set the Init string to `ATZ^M`.
3. Set the optional setup string to Asynchronous RLP:

`AT+CBST=0,0,1`

Configure your facsimile communications program manually

To manually configure your facsimile communications program, select a Fax Class 1 driver. The Infrared Modem supports Fax Class 2 facsimile which might be used if there are problems with the fax service or speed of the computer, or your fax application does not support Fax Class 1.

2 Result and Error Codes

2.1 Result codes

When you send a command from your PC to the Infrared Modem, the response is terminated by a result code which is shown on the computer screen. You use this code to confirm correct operation or to identify any problem with the command.

There are two types of result codes:

- final result codes related to the operation of AT commands;
- result codes associated with call connections.

Final result codes from AT commands

The Infrared Modem always terminates each response to an AT command with a final result code:

OK The command(s) and any specified parameters were valid and the command has completed execution.

Note

*Some AT commands are not relevant to the Infrared Modem operations or can only be set to one parameter value. For completeness and to allow the parameter to be read, some of these commands are supported but not implemented. Calling a command of this type will produce the **OK** result code but will not cause any change to the Infrared Modem. These commands are included in the command descriptions in Chapters 4, 5 and 6.*

ERROR

An error has occurred during the command processing.

This could arise because:

- there is a fault in the command syntax;
- one or more parameters are outside the permitted range;
- the command you issued is not implemented on the Infrared Modem;
- the command is not appropriate to the service;
- class the Infrared Modem is operating.

When an error is reported, the **ERROR** message is preceded by a copy of the text response from the last valid AT command. This is shown in the following example:

Valid command	AT+CBC=?
Response	+CBC: (0 , 2) , (0-100)
	OK
Invalid command	AT+CBC=? ; +FCLASS=3
Response	+CBC: (0 , 2) , (0-100)
	ERROR

Result codes from call connections

During on-line operation of the telephone, result codes inform you about the progress of call connections:

CONNECT	<speed>	A connection has been established and the data rate <speed> is shown.
BUSY		The number you called is engaged.
NO DIALTONE		Unable to establish the initial connection.
NO CARRIER		Either a connection could not be established or an existing connection has been lost.
RING		There is an incoming call. This is not a consequence of local activity and is referred to as an unsolicited result code.

Format of the result codes

The result codes described above are in verbose format. You can command the Infrared Modem to display result codes in verbose or numeric format or you can switch them off completely.

To switch between verbose and numeric format, please refer to the use of the AT V command on [page 57](#) and [page 57](#).

To switch the display of result codes on or off, please refer to the use of the AT Q command on [page 56](#).

2.2 Error codes

The `+CME ERROR` result codes indicate an error relating to the functionality of the Infrared Modem or Mobile Phone and replaces the final result code `ERROR` when first enabled with the `AT+CME` command.

Report mobile phone failure (+CMEE)

<code>+CME ERROR: 0</code>	Phone failure.
<code>+CME ERROR: 1</code>	No connection to phone.
<code>+CME ERROR: 2</code>	Phone modem link reserved.
<code>+CME ERROR: 3</code>	Operation not permitted.
<code>+CME ERROR: 4</code>	Operation not supported.
<code>+CME ERROR: 5</code>	PH-SIM card PIN required.
<code>+CME ERROR: 10</code>	SIM card not inserted.
<code>+CME ERROR: 11</code>	SIM card PIN required.
<code>+CME ERROR: 12</code>	SIM card PUK required.
<code>+CME ERROR: 13</code>	SIM card failure.
<code>+CME ERROR: 14</code>	SIM card busy.
<code>+CME ERROR: 15</code>	SIM card wrong.
<code>+CME ERROR: 16</code>	Incorrect password.
<code>+CME ERROR: 20</code>	Memory full.
<code>+CME ERROR: 21</code>	Invalid index.
<code>+CME ERROR: 22</code>	Not found.
<code>+CME ERROR: 23</code>	Memory failure.

+CME ERROR: 24	Text string too long.
+CME ERROR: 25	Invalid character in text string.
+CME ERROR: 26	Dial string too long.
+CME ERROR: 27	Invalid character in dial string.
+CME ERROR: 100	Unknown.

Report operational/access failure (+CMS)

The +CMS ERROR result codes indicate an error relating to the Infrared Modem, Mobile Phone or Network relating to the Short Message Service (SMS) and replaces the final result code ERROR.

+CMS ERROR: 0	GSM 04.11 Annex E-2 values.
to	
+CMS ERROR: 127	
+CMS ERROR: 128	GSM 03.40 Section 9.2.3.22 values.
to	
+CMS ERROR: 255	
+CMS ERROR: 300	Mobile phone failure.
+CMS ERROR: 301	Short message service of mobile phone reserved.
+CMS ERROR: 302	Operation not allowed.
+CMS ERROR: 303	Operation not supported.
+CMS ERROR: 304	Invalid PDU mode parameter.

+CMS ERROR: 305	Invalid text mode parameter.
+CMS ERROR: 310	SIM card not inserted.
+CMS ERROR: 311	SIM card PIN necessary.
+CMS ERROR: 312	SIM card PIN necessary for PH-SIM.
+CMS ERROR: 313	SIM card failure.
+CMS ERROR: 314	SIM card busy.
+CMS ERROR: 315	SIM card wrong.
+CMS ERROR: 316	SIM PUK required
+CMS ERROR: 317	SIM PIN2 required
+CMS ERROR: 318	SIM PUK2 required
+CMS ERROR: 320	Memory failure.
+CMS ERROR: 321	Invalid memory index.
+CMS ERROR: 322	Memory full.
+CMS ERROR: 330	SMSC address unknown.
+CMS ERROR: 331	No network service.
+CMS ERROR: 332	Network timeout.
+CMS ERROR: 340	no +CNMA acknowledgement expected
+CMS ERROR: 500	Unknown error.
+CMS ERROR: ...511	range 256...511 reserved
+CMS ERROR: 512...	manufacturer specific

Service Report (+CR)

When a data connection is being established, the +CR messages are sent to the PC before the final result code `CONNECT`. Use the `AT+CR` command to enable these messages.

+CR: ASYNC	Asynchronous transparent.
+CR: SYNC	Synchronous transparent.
+CR: REL ASYNC	Asynchronous non-transparent.
+CR: REL SYNC	Synchronous non-transparent.

Cellular Result Codes (+CRC)

The +CRC messages replace the unsolicited result code `RING` and provide more information about the type of the incoming call. Use the `AT+CRC` command to enable these messages.

+CRING: ASYNC	Asynchronous transparent.
+CRING: SYNC	Synchronous transparent.
+CRING: REL ASYNC	Asynchronous non-transparent.
+CRING: REL SYNC	Synchronous non-transparent.
+CRING: FAX	Facsimile.
+CRING: VOICE	Normal voice.

3 AT Commands

3.1 Introduction to AT commands

This chapter describes how AT commands are used to exchange information with your mobile telephone and Infrared Modem. The AT commands are listed at the end of this chapter. For a description of each command, refer to Chapters 4, and 5.

You use AT commands to:

- configure your mobile telephone and Infrared Modem;
- request information about the current configuration or operational status of your mobile phone/modem;
- test availability and request the range of valid parameters, when applicable, for an AT command.


3.2 Infrared Modem operating modes

The Infrared Modem can be set in any one of three modes of operation. These are:

- | | |
|------------------------------|---|
| off-line command mode | the Infrared Modem is placed in off-line command mode when first powered up and is ready for entry of AT commands. |
| on-line data mode | allows “normal” operation of the Infrared Modem, exchanging data or facsimile with the remote modem. |
| on-line command mode | you can switch to on-line command mode when you want to send AT commands to the Infrared Modem while still remaining connected to the remote modem. |

3.3 Changing the Infrared Modem operating mode

The following illustration summarises the methods that are used to switch between the three Infrared Modem operating modes:



&D previously set to 1.

* &D previously set to 2.

Operating in off-line command mode

In off-line command mode, the Infrared Modem accepts data as commands and not as normal communications traffic. You enter commands by typing at the PC keyboard.

Switching to on-line data mode

To enter on-line data mode, so that you can exchange data with the modem at the other end of the link, you enter the **ATD** command followed by the telephone number to make the call. Alternatively, typing **ATA** to answer an incoming call will also place the Infrared Modem in on-line mode.

Switching back to off-line command mode

Any of the following will return the Infrared Modem to off-line command mode from on-line data mode:

- loss of the connection (**NO CARRIER** error);
- loss of the I.R. link between the Infrared Modem and your computer;
- pressing the “NO” button on your mobile phone;
- pulling DTR low provided &D has previously been set to 2.

Note: *The &D command is described on [page 274](#). The setting of &D determines the action taken when DTR is pulled low while you are in on-line data mode*

*&D set to 1 - Infrared Modem switches to on-line command mode
&D set to 2 - Infrared Modem switches to off-line command mode.*

Using AT commands during a data connection

If you wish to use AT commands while connected to a remote modem in on-line data mode and maintain connection with the remote modem, you must first enter on-line command mode.

There are two ways you can switch from on-line data mode to on-line command mode:

- Type the escape sequence “+++” followed by an appropriate AT command. This command must be selected from the options **AT**, **ATE**, **ATH**, **ATI**, **ATL**, **ATM**, **ATQ**, **ATV** and **ATX**. Using this method you can perform an AT function as you move in to on-line command mode. For example, if you switch using:

+++ATH<CR>

the Infrared Modem is switched to on-line command mode and the AT command is executed, causing the connection to be terminated (hang-up). If you type the escape sequence “+++” without any following command, the system waits one second, switches to on-line command mode and responds OK;

- Pull DTR low after previously setting &D to 1.

Switching from on-line command mode to on-line data mode

To return to on-line data mode while in on-line command mode, type:

ATO<CR>

Switching from on-line command mode to off-line command mode

To return the Infrared Modem to off-line command mode from on-line command mode:

- use any of the methods described in “Switching back to off-line command mode” above;
- type **+++ATH <CR>** to switch to on-line command mode and hang up at once.

3.4 Operating the AT commands

In command mode, there are four types of command you can issue:

- a set command to adjust the Infrared Modem’s operating parameters;
- an execute command which directs action without the need of any parameters;
- a read command to view the current command settings;
- a test command to view the available command parameters.

Not all AT commands support all four functions. The descriptions in Chapters 4 to 6 list the functions available for each AT command.

Entering a set command

The standard format for entering a set command is:

```
AT<command>=<parameters> <CR>
```

Where:	AT	Notifies the Infrared Modem that a command is being entered.
	<command>	The name of the command being entered.
	<parameters>	The values to be used by the command.
	<CR>	All command lines are terminated by pressing the <CR> (Return or Enter) key.

Note:

All command lines are completed by pressing the <CR> key on the computer keyboard. For the remainder of this manual, appropriate use of the <CR> key is assumed.

To set the Infrared Modem to operate with autobaud over an asynchronous connection the command line would be:

AT+CBST=0,0,1

However, the commands also have default settings. These are values which are assumed to have been entered when no actual value is placed in the command line.

For example, the above command can be entered as:

AT+CBST=,,1

The default values used by the commands are indicated in the following descriptions by bold text.

When the parameter is a character string (for example "<name>") then the value should be entered between quotes. For example "Peter".

Optional parameters are shown in square brackets. For example [<value>].

Entering an execute command

Execute commands are very similar to set commands. They usually do not require any parameters and are used to obtain information about the mobile phone or Infrared Modem or to execute an event.

For example, to find out information about the mobile phone battery, enter the +CBC command:

AT+CBC

The Infrared Modem responds:

+CBC: 0,60

indicating that the mobile phone battery is connected (0) and that it has 60% charge remaining.

To answer an incoming call, you execute the A command:

ATA

Using read command to view the command settings

To check the current settings of a command, use the '?' option.

For example, to check the current settings of the +CBST command, enter:

AT+CBST?

If CBST has been set according to the previous example, the settings are displayed as:

+CBST: 0,0,1

Using test command to request command help

To test the availability of a command and the range of parameters, use the '=' option with the command.

For example, to check the parameters available to the command line in the example above, enter:

AT+CBST=?

The line:

+CBST: (0,4,6,7,68,70,71),(0),(1)

is displayed indicating the range of valid entries that can be set for the parameters <data rate>, <bearer service> and <connection element>.

3.5 AT command list

General AT commands

Ensemble S1/B/E : GSM DTE-DCE Interface commands

+CSCS	Select terminal character set	37
-------	-------------------------------------	----

Ensemble C2/C/E : Control and Identification

AT	Attention Command	38
Z	Reset to user defined configuration	38
&F	Set to factory configuration	39
+CGMI	Request mobile phone manufacturer identification	40
+CGMM	Request mobile phone model identification	40
+CGMR	Request mobile phone revision identification	41
+CGSN	Request ME product serial no identification	42
*	List all supported commands	42

Ensemble S2/E : GSM Call Control

+CMOD	Set call mode	43
+CHUP	Call hang-up	44
+CRC	Cellular result codes	45
+VTS	DTMF and tone generation.....	46

Unsolicited Result Codes

+CRING	Call mode indication	47
--------	----------------------------	----

Ensemble C3/E : Call Control

A	Answer.....	48
H	Hook control	48
D	Dial	49
+CFUN	Set mobile phone functionality.....	50
L	Monitor speaker loudness control.....	51

Unsolicited Result Codes

RING	Incoming Call Indication	51
------	--------------------------------	----

Ensemble C4/E : Interface Commands

S3	Command line termination character	52
S4	Response formatting character	53
S5	Command line editing character	54
E	Command echo	55
Q	Result code suppression	56
V	Result code format	57

Ensemble S6/C/E : GSM Network Services

+CAOC	Advice of charge	58
+CNUM	Subscriber number	59
+CREG	Set network registration	60
+COPS	Set operator selection	62
+CLIP	Calling line identification presentation	64
+CLIR	Calling line identification restriction	65
+CCFC	Call forwarding	67
+CCWA	Call waiting	69
+CHLD	Call related supplementary services	71
+CSSN	Supplementary service notifications	73
+CACM	Accumulated Call Meter	75
+CAMP	Accumulated Call Meter Maximum	76
*EALS	Ericsson Request ALS Status	77
*ECSP	Ericsson Customer Service Profile	78
*ELIN	Ericsson line set	79
*EPNR	Ericsson Read SIM Preferred Network	80
*EPNW	Ericsson Write SIM Preferred Network	82
*ESLN	Ericsson Set Line Name	83
*ESCN	Ericsson Set Credit Card Number	84
+CPUC	Price Per Unit And Currency Table	86

*ESVM	Ericsson Set Voice Mail Number	87
*EDIF	Ericsson Divert Function.....	89
*EDIS	Ericsson Divert Set	90

Unsolicited Result Codes

+CREG	Network Registration	91
+CLIP	Calling Line Identification Presentation	91
+CCWA	Call Waiting	92
+CSSU	Supplementary service notification	93
+CSSI	Supplementary service notification	94
*EDIF	Ericsson Divert Function.....	95

Ensemble S8/C/E : GSM Facility Lock

+CLCK	Facility lock	97
+CPWD	Set/change new password	100

Ensemble C9/C/E : Multi Mode Phones

+WS46	Mode selection	102
-------	----------------------	-----

Ensemble S9/C/E : GSM Mobile Equipment,Control and Status

+CKPD	Keypad control.....	105
+CIND	Indicator control	106
+CPAS	Mobile phone activity status	108
+CPIN	Send Password	110
+CBC	Mobile phone battery charge	112
+CSQ	Mobile phone signal quality	114
+CMER	Mobile equipment event reporting	115
+CVIB	Vibrator Mode	117
*ECAM	Ericsson call monitoring.....	118
*EDME	Ericsson enable data menus	119
*ELAN	Ericsson Language.....	120
*EMAR	Ericsson master reset.....	122

*ERIL	Ericsson ring level set.....	123
*ERIN	Ericsson ring set.....	125
*ERIP	Ericsson ring signal playback command	126
*ESIL	Ericsson silence command.....	127
*ESKL	Ericsson settings key lock mode	128
*ESKS	Ericsson settings key sound	129
*ESMA	Ericsson set message alert sound.....	130
*ESMM	Ericsson settings minute minder.....	131
*ESAM	Ericsson settings answer mode	132
*ESBL	Ericsson settings back light mode	133
*ESDF	Ericsson settings date format	134
*ESOM	Ericsson settings own melody	135
*ESTF	Ericsson settings time format	137
*ETXT	Ericsson text command	138

Unsolicited Result Codes

+CKEV	Keypad event.....	139
+CIEV	Indicator event reporting.....	140
*ECAV	Ericsson Call Monitoring event	141

Ensemble S11/C/E : GSM SMS and CBS PDU Mode

+CSMS	Select SMS message service	144
+CPMS	Preferred SMS message storage	146
+CMGL	List messages.....	148
+CMGR	Read message	150
+CMGS	Send SMS messages	152
+CMSS	Send from storage	153
+CMGW	Write message to memory.....	154
+CMGD	Delete message.....	155
+CMGF	Message format.....	156
+CSCA	SMS service centre address.....	157

+CSCB	Select cell broadcast message type	159
+CSAS	Save Settings	160
+CRES	Restore Settings	161
+CNMI	New message indication to TE	162

Unsolicited Result Codes

+CBM	New Message Indication	164
+CMTI	New Message Indication	165
+CMT	Received Message	166
+CMS	Report operational/access failure (+CMS).....	167

Ensemble S14/E : GSM Digital Binary Ping Pong Mode

*BINARY	Start binary mode	169
---------	-------------------------	-----

Ensemble S16/C/E : GSM Phonebook Commands

+CPBS	Select mobile phone phonebook memory storage	170
+CPBR	Read mobile phone phonebook entries	171
+CPBF	Phonebook Find	173
+CPBW	Write mobile phone phonebook entries	175
*ECAR	Ericsson Callers Allowed Read	177
*ECAW	Ericsson Callers Allowed Write.....	178
*EPRR	Ericsson Personal Ringtype Read.....	179
*EPRW	Ericsson Personal Ringtype Write	181
*ECAS	Ericsson Callers Allowed Set.....	183

Ensemble S18/E : GSM Clock, Date and Alarm Handling

+CCLK	Clock.....	184
+CALA	Alarm	185

Ensemble S19/E : GSM Subscriber Identification

+CIMI	Read International Mobile Subscriber Identity (IMSI) ...	186
-------	--	-----

Ensemble C20/C/E : Audio Control

*EALR	Audio Line Request	187
*EARS	Analog Ring Signal Request.....	188
*EMIR	Mute Indication Request.....	189
*EAMS	Audio Mode Selection.....	190
*EPHD	Portable Hands Free Detection	193
*ECBP	CHF Button Pushed.....	194

Unsolicited Result Codes

*EALV	Audio Line Response	195
*EMIV	Music Mute Indication Response.....	195

Ensemble S20/C/E : Ericsson Specific AT Commands for GSM

*ECUR	Ericsson current report	196
*EENL	Ericsson Environment List.....	197
*EKSP	Ericsson Key Sound Playback.....	199
*EKSR	Ericsson Key Sound Change Report.....	200
*EMIC	Ericsson microphone mode	202
*EPEC	Ericsson Profile Environment Change	203
*EPEE	Ericsson pin event	204
*EPED	Ericsson Profile's List Of Environments Delete	205
*EPEW	Ericsson Profile's List Of Environments Write	207
*EAPS	Ericsson Active Profile Set	209
*EAPN	Ericsson Active Profile Rename	211
*ESNU	Ericsson settings number	212
*EBCA	Ericsson Battery And Charging Algorithm	213
*EQVL	Ericsson External Volume Status	216
*EXVC	Ericsson Set External Volume Control	217

Unsolicited Result Codes

*EBCA	Ericsson Indication Algorithm Status	218
*EPEV	Ericsson Pin Code event	218
*EVOLC	Ericsson Volume Change Report	218

*EKSC	Ericsson Key Sound Change Report.....	219
-------	---------------------------------------	-----

Ensemble C21/C/E : Accessory Menus

*EAM	Ericsson Add Accessory Menu Item.....	220
*EAST	Ericsson Accessory Status Text.....	221
*EASM	Ericsson Accessory Sub Menu.....	222
*EAID	Ericsson Accessory Input Dialog	224

Unsolicited Result Codes

*EAAI	Ericsson Accessory Additional Indication	228
*EAMI	Ericsson Accessory Menu Indication	228
*EAIL	Ericsson Accessory Input Dialog Indication.....	229

Ensemble C22/C/E : Accessory Authentication

+CSCC	Secure Control Command	231
-------	------------------------------	-----

Ensemble C24/C/E : Voice Call Control

*EVA	Answer Incoming Call Command	233
*EVD	Voice Dial Command.....	233
*EVH	Voice Hook Command.....	233

Ensemble C25/E : ETSI 07.10 Multiplex Protocol

+CMUX	Activate Multiplex Protocol	234
-------	-----------------------------------	-----

Ensemble C26/C/E : Accessory Identification

*EACS	Ericsson Accessory Status	235
-------	---------------------------------	-----

Ensemble C30/C/E : VAD Support for Vehicle HF 3V

*EYRR	Recording Result	238
*EYRE	Recognised Entry	240
*EYDO	Done	241
*EYRV	Registered VAD	241
*EYPI	Phone Info	242

Unsolicited Result Codes

*EYPE	Play Entry	243
*EYPP	Play Prompt	243
*EYRE	Recognise	243
*EYTN	Train Name	244
*EYPT	Play Training Recording	244
*EYDE	Delete Entry	244
*EYSR	Save Recording	245
*EYAB	Abort	245
*EYGP	Get Phones	245
*EYDP	Delete Phone	246
*EYRP	Register Phone	246
*EYSS	Start Synchronise	246

Ensemble C31/C/E : Quick Menu

*ECMW	Ericsson Customized Menu Write	247
*EMLR	Ericsson Menu List Read	248

Ensemble S1/B/E : GSM DTE-DCE Interface commands

+CSCS	Select terminal character set	249
-------	-------------------------------------	-----

Ensemble C2/B : Identification and Control

AT	Attention Command	250
Z	Reset to user defined configuration	250
&F	Set to factory configuration	251
I	Identification information	252
+GMI	Request Infrared Modem manufacturer identification...	253
+GMM	Request Infrared Modem model identification	253
+GMR	Request Infrared Modem revision identification	254
+GCAP	Request Infrared Modem capabilities list	255

Ensemble S2/B : GSM Call Control

+CR	Service reporting control	256
-----	---------------------------------	-----

+CRC	Cellular result codes	257
------	-----------------------------	-----

Unsolicited Result Codes

*CRING	Cellular result code	258
--------	----------------------------	-----

Ensemble C3/B : Call Control

A	Answer	259
H	Hook control	259
D	Dial	260
O	Return to on-line data mode	262
P	Select pulse dialling	262
T	Select tone dialling	262

Ensemble S3/B : GSM Data/Fax

+CRLP	Radio link protocol	264
+CBST	Select bearer service type	265

Ensemble C4/B : Interface Commands

S2	Escape sequence character	267
S3	Command line termination character	268
S4	Response formatting character	269
S5	Command line editing character	270
E	Command echo	271
Q	Result code suppression	272
V	Result code format	273
&C	Circuit 109 (DCD) control	274
&D	Circuit 108 (DTR) response	274
+IFC	DTE-DCE local flow control	275
S0	Automatic answer control	277
S6	Blind dial delay control	278
S7	Connection completion timeout	279
S8	Comma dial modifier delay control	280
S10	Automatic disconnect delay control	281

M	Monitor speaker control	282
X	Call progress monitoring control	283

Ensemble S4/B : GSM Extended Error Reporting

+CEER	Extended error report	284
-------	-----------------------------	-----

Ensemble C6/B : Data Compression

+DS	Data compression.....	285
+DR	Data compression reporting	287

Unsolicited Result Codes

+DR	Data Compression Indication	288
-----	-----------------------------------	-----

Ensemble S10/B : GSM Mobile Equipment Error Control

+CMEE	Report mobile equipment error.....	289
-------	------------------------------------	-----

Ensemble C18/B : Fax Class 1

+FCLASS	Capabilities Identification and Control	290
+FMI	Manufacturer identification	291
+FMM	Request product identification	291
+FMR	Request version.....	292
+FTS	Stop transmission and wait.....	292
+FRS	Receive silence	293
+FTM	Facsimile transmit.....	294
+FRM	Facsimile receive	295
+FTH	Transmit HDLC.....	296
+FRH	Receive HDLC	296

Ensemble C19/B : Fax Class 2

+FCLASS	Capabilities Identification and Control	297
+FAA	Fax auto answer setting	298
+FAXERR	Request hang-up cause code.....	299
+FBADLIN	Number of consecutive bad lines to accept.....	302

+FBADMUL	Bad line multiplier parameter	303
+FBOR	Facsimile page transfer bit order parameter.....	304
+FBUF	Buffer size report	305
+FBUG	Session Message Report	306
+FCQ	Copy quality checking.....	307
+FCR	Capability to receive parameter	308
+FCIG	Local polling ID parameter.....	309
+FCTCRTY	Continue to correct count during ECM	310
+FDFFC	Data format failure check.....	311
+FDCC	TAE Capability parameters.....	312
+FDCS	Session results	315
+FDIS	Current session negotiation parameters.....	316
+FDR	Fax data receive command	318
+FDT	Fax data transmission command.....	320
+FECM	Error correction mode	322
+FET	Page punctuation.....	323
+FK	Orderly fax abort.....	324
+FLID	Local polling ID parameter.....	324
+FLNFC	Page length format conversion parameter	325
+FLPL	Document for polling parameter	326
+FMDL	Request product identification	327
+FMFR	Request manufacturer's identification	327
+FMINS	Minimum facsimile page transfer speed parameter.....	328
+FPHCTO	Facsimile page transfer timeout parameter	329
+FPTS	Page transfer status parameter	330
+FRE	Request DCE revision	331
+FRBC	Receive data block size	331
+FREL	Facsimile page transfer EOL alignment parameter	332
+FSPL	Enable polling parameter.....	333
+FTBC	Fax page transfer data transmit byte count parameter.	334

+FVRFC	Vertical resolution conversion parameter	335
+FWDFC	Page width conversion parameter	336

4 AT Commands Phone Terminal Terminated

4.1 Ensemble S1/B/E : GSM DTE-DCE Interface commands

+CSCS *Select terminal character set*

Description: Defines the character set to be used.

Set command: **+CSCS=[<chset>]**

Options: <chset> "GSM" Default GSM alphabet.

Example: AT+CSCS="GSM"

OK

Read command: **+CSCS?** Returns the current setting.

Example: AT+CSCS?

+CSCS: "GSM"

OK

Test command: **+CSCS=?**

Example: AT+CSCS=?

+CSCS: "GSM", "IRA", "88591", "ERICSSON"

OK

4.2 Ensemble C2/C/E : Control and Identification

AT ***Attention Command***

Description: Determines the presence of an MS.

Execute command: **AT**

Example: AT

OK

Z ***Reset to user defined configuration***

Description: Perform a 'soft reset', i.e. terminate any ongoing operation and connection and restore one of the configurations stored in nonvolatile memory as the active profile.

Set command: **Z**

Example 1: ATZ

OK

Test command: **Z=?**

Example: ATZ=?

OK

AT Commands Phone Terminal Terminated

&F *Set to factory configuration*

Description: Resets the settings to the predefined factory configurations. Configurations which would adversely effect an open connection or a current data transmission are not loaded until the connection ceases.

Command: **&F=[<pr>] or &F[<pr>]**

Options: <pr> **0** Reset all the settings to the factory defaults.

Example: AT&F
OK

Test command: **&F=?** Always returns (0).

Example: AT&F=?
&F: (0)
OK

+CGMI *Request mobile phone manufacturer identification*

Execute command: **+CGMI**

Test command: **+CGMI=?**

+CGMM *Request mobile phone model identification*

Execute command: **+CGMM**

Example: AT+CGMM
1050501S
1018
OK

Test command: **+CGMM=?**

+CGMR *Request mobile phone revision identification*

Execute command: **+CGMR**

Example: AT+CGMR
9710051610 Type numbering structure
OK

Test command: **+CGMR=?**

AT Commands Phone Terminal Terminated

+CGSN *Request ME product serial no identification*

Description: Returns a string containing the IMEI number of the MS.

Execute command: **+CGSN**

Returns: <imei> A string containing the IMEI number of the MS.

Example: AT+CGSN
10110100101
OK

Test command: **+CGSN=?**

Example: AT+CGSN=?
OK

***** *List all supported commands*

Description: Lists one or more lines of AT commands supported by the MS.

Execute command: *

Example: AT*
AT+CGMI
AT+CGMM
AT+CGMR
AT+CGSN
OK

4.3 Ensemble S2/E : GSM Call Control

+CMOD *Set call mode*

Description: Sets the call mode for further dialling commands or the next answering command.

Set command: **+CMOD=<mode>**

Options:	<mode>	0	Single mode.
		1	Alternating voice/fax.

Example: AT+CMOD=1 Change to voice/fax mode.

OK

Read command: **+CMOD?** Returns the current setting.

Example: AT+CMOD?

+CMOD: 1

OK

Test command: **+CMOD=?** Always returns (0-1).

Example: AT+CMOD=?

+CMOD: (0-1)

OK

AT Commands Phone Terminal Terminated

+CHUP *Call hang-up*

Description: Terminates the current call. Command is used to provide an assured means of terminating an alternating mode call.

Execute command: **+CHUP**

Example: AT+CHUP

OK

Test command: **+CHUP=?**

Example: AT+CHUP=?

OK

+CRC	Cellular result codes	
Description:	Determines whether or not the extended format of report for an incoming call should be used.	
Set command:	+CRC=[<mode>]	
Options:	<mode>	0 Disable extended result codes. 1 Enable extended result codes. Default = 0.
Example:	AT+CRC=0 OK	
Read command:	+CRC?	Returns the current setting.
Example:	AT+CRC? +CRC: 0 OK	
Test command:	+CRC=?	Always returns (0-1).
Example:	AT+CRC=? +CRC: (0-1) OK	
Unsolicited Result code:	+CRING:<type>	

AT Commands Phone Terminal Terminated

+VTS *DTMF and tone generation*

Description: Allows the transmission of DTMF tones and arbitrary tones.

Execute command: **+VTS=<DTMF>**

Options: <DTMF> Single ASCII character in the set 0-9, #, *, A-D.

Example: AT+VTS="1" Transmit DTMF tone.

OK

Test command: **+VTS=?**

Example: AT+VTS=?

OK

Unsolicited Result Codes

+CRING *Call mode indication*

Description: Set command controls whether or not the extended format of incoming call indication is used.

Unsolicited Result code:	*CRING: <type>	When enabled, indicates the incoming call to the TE instead of the normal RING.
Defined values:	<type>	
	ASYNC	Asynchronous transparent.
	FAX	Facsimile (TS 62).
	VOICE	Normal voice (TS 11).
	ALT FAX/VOICE	Alternating voice/fax, voice first (TS 61).
	ALT VOICE/FAX/	Alternating voice/fax, fax first (TS 61).

4.4 Ensemble C3/E : Call Control

A ***Answer***

Description: Answer and initiate connection to an incoming call.

Execute command: **A**

Example: ATA

OK

H ***Hook control***

Description: Terminates a connection.

Execute command: **H**

Example: ATH

OK

AT Commands Phone Terminal Terminated

D

Dial

Description: Initiate a phone voice connection (phone number terminated by semicolon). The phone number used to establish the connection will consist of digits and modifiers or a stored number specification.

Execute command: **D<n>** Dial the phone number specified in the command as <n>.

Modifiers: ; Informs the Infrared Modem that the number is a voice rather than a fax or data number.

Dial examples: ATD046193000 ; Voice dial, immediately returns OK .

Responses: ERROR An unexpected error occurred while trying to establish the connection.

NO DIALTONE The line is busy.

NO CARRIER The mobile phone is not registered.

AT Commands Phone Terminal Terminated

+CFUN *Set mobile phone functionality*

Description: Sets the power status of the mobile phone to either on or off.

Set command: **+CFUN=[<fun>]**

Options: <fun> **0** Switch off the mobile phone.

1 Switch on the mobile phone.

Default = 0.

Example: AT+CFUN=0

 OK

Read command: **+CFUN?** Returns the current setting.

Example: AT+CFUN?

 +CFUN: 1

 OK

Test command: **+CFUN=?**

Example: AT+CFUN=?

 +CFUN: (0-1)

 OK

Note that when the keylock is activated on the phone, you cannot turn it off by means of the +CFUN command.

AT Commands Phone Terminal Terminated

L ***Monitor speaker loudness control***

Description: Set the volume of the speaker.

Set command: **L[=][<vol>]**

Options: <vol> 0-8 0 is off, 8 is loudest.

Default = 2.

Examples: ATL=4

OK

Read command: **L?**

Example: ATL?

L: 0

OK

Test command: **L=?** Always returns (0-8).

Example: ATL=?

L: (0-8)

OK

Unsolicited Result Codes

RING ***Incoming Call Indication***

Description: Indicates that the MS is being asked to accept a call.

Unsolicited Result

code: **RING**

Produced when an accessory is connected to the MS (i.e. DTMS is asserted).

4.5 Ensemble C4/E : Interface Commands

S3 *Command line termination character*

Description: Defines the character to be used as the line termination character. This is used both for the detection of an end of command and in formatting of responses. The response to the command is modified to reflect the change.

Set command: **S3=[<value>]**

Options: <value> **0..127**

The ASCII value of an end Command Line termination character.

Default = **13**.

Example: **ATS3=13**

OK

Read command: **S3?**

Returns the current setting.

Example: **ATS3?**

013

OK

Test command: **S3=?**

Example: **ATS3=?**

S3: (0-127)

OK

AT Commands Phone Terminal Terminated

S4 *Response formatting character*

Description: Defines the character to be used as the line formatting character. The response to the command is modified to reflect the change.

Set command: **S4=[<value>]**

Options: <value> **0..127** The ASCII value of formatting character.
Default = **10**.

Example: ATS4=10
OK

Read command: **S4?** Returns the current setting.

Example: ATS4?
010
OK

Test command: **S4=?**

Example: ATS4=?
S4: (0-127)
OK

S5 *Command line editing character*

Description: Defines the character to use as command line editing character.

Set command: **S5=[<value>]**

Options: <value> **0..127** The default ASCII value of the Line Editing Character.
Default = **8**.

Example: ATS5=8
OK

Read command: **S5?** Returns the current setting.

Example: ATS5?
008
OK

Test command: **S5=?**

Example: ATS5=?
S5: (0-127)
OK

AT Commands Phone Terminal Terminated

E **Command echo**

Description: Enables or disables the command line echo.

Set command: **E=[<value>] or E[<value>]**

Options: <value> **0** No echo of command mode characters.

1 Echo command mode characters.

Default = 1.

Example: ATE=1

OK

Read command: **E?** Returns the current setting.

Example: ATE?

E: 1

OK

Test command: **E=?** Always returns (0,1).

Example: ATE=?

E: (0,1)

OK

Q ***Result code suppression***

Description: Enables or disables the display of result codes. When the result code is disabled, the Infrared Modem does not issue any final result codes but continues to provide normal text in response to commands.

Set command: **Q=[<value>] or Q[<value>]**

Options: <value> **0** Enable result codes.
 1 Disable result codes.
 Default = **0**.

Example: ATQ=1
 OK

Read command: **Q?** Returns the current setting.

Example: ATQ?
 Q: 1
 OK

Test command: **Q=?** Always returns (0,1).

Example: ATQ=?
 Q: (0,1)
 OK

V **Result code format**

Description: Select either verbose or numeric response codes.

Set command: **V**=[<value>] or **V**[<value>]

Options: <value> **0** Display numeric result codes.

1 Display verbose result codes.

Default = **1**.

Example: ATV=1

 OK

Read command: **V?** Returns the current setting.

Example: ATV?

 V: 1

 OK

Test command: **V=?** Always returns (0-1).

Example: ATV=?

 V: (0-1)

 OK

4.6 Ensemble S6/C/E : GSM Network Services

+CAOC *Advice of charge*

Description: Returns the current call meter value in hexadecimal format. Must be supported on SIM-card.

Execute command: **+CAOC**[= < mode >]

Options:	<mode>	0	Query CCM Value.
		1	Deactivated the unsolicited reporting of CCM value.
		2	Activated the unsolicited reporting of CCM value.
			Default = previous value .

Returns: <ccm> Three byte Hex value of current call meter value.

Example: +CAOC = [<mode>]

+CAOC : <ccm>

OK

Read Command: **+CAOC?**

+CAOC : <mode>

OK

Test command: **+CAOC=?**

Example: AT+CAOC=?

OK

Unsolicited Result
code: **+CCCM**: < ccm >

+CNUM *Subscriber number*

Execute command: **+CNUM**

<alphax>		Optional alphanumeric string associated with <numberx>.
<numberx>		String type phone number of format specified by <typex>.
<typex>		Type of octet address in integer format.
<speed>	8	No speed specification needed.
<service>	0	Asynchronous modem.
	4	Voice.
	5	Fax.
<itc>	0	3.1 kHz.
	1	UDI.

Test command: **+CNUM=?**

Page 59
Online Reference

AT Commands Phone Terminal Terminated

+CREG *Set network registration*

Description: Allows network registration of an unsolicited result code.

Set command: **+CREG=[< n >]**

Options:	<n>	0	Disable network registration of unsolicited result code.
		1	Enable network registration of unsolicited result code. That is, it sends an unsolicited result code for every change in the status.

Example: **AT+CREG=1** Activate.

OK

Read Command: **+CREG?** Returns the current setting.

Returns: **+CREG:<n>,<stat>**

<n>	0	Disable network registration code.
	1	Enable network registration code.
<stat>	0	Not registered.
	1	Registered, home network.
	2	Not registered, currently searching for a new operator to register to.
	3	Registration denied.
	4	Unknown.
	5	Registered, roaming

AT Commands Phone Terminal Terminated

Example: AT+CREG?

 +CREG: 0,1

 OK

Test Command: **+CREG=?** Always returns (0-1).

Example: AT+CREG=?

 +CREG: (0-1)

 OK

Unsolicited Result
code: **+CREG:** <stat> [,<lac>,<ci>]

AT Commands Phone Terminal Terminated

+COPS *Set operator selection*

Description: Allows the automatic or manual selection of the GSM network operator.

Set command: **+COPS**=[< mode >[,< format >[,< oper >]]]

Options:	<mode>	0	Automatic (<oper> field is ignored).
		1	Manual (<oper> field is present).
		4	Manual/automatic (<oper> field is present).
	<format>	0	Long alphanumeric format 16 characters.
		1	Short alphanumeric format. 8 characters.
		2	Numeric. GSM Location Area Identification number which consists of a three BCD digit country code and a two BCD digit network code.
	<oper>		String type as specified by <format>.

Example: AT+COPS=0
OK

AT Commands Phone Terminal Terminated

Read command: **+COPS?**

Example: AT+COPS? Returns the current setting.

+COPS: 0,0,"RADIOLINJA"

OK

Test command: **+COPS=?**

Returns: +COPS: (<status>,<long>,<short>,<numeric>)

<status> **0** Unknown.

1 Available.

2 Current.

3 Forbidden.

<long> Long alphanumeric format.

<short> Short alphanumeric format.

<numeric> GSM Location Area Identification number which consists of a three BCD digit country code and a two BCD digit network code.

Example: AT+COPS=?

+COPS: (2,"RADIOLINJA","RL","24405")

+COPS: (0,"TELE","TELE","24491")

OK

Two operator networks have been found, the status of TELE is unknown and RADIOLINJA is currently selected.

AT Commands Phone Terminal Terminated

+CLIP *Calling line identification presentation*

Description: Calling line identification presentation allows the subscriber to get the calling line identity of the calling party when receiving a mobile terminated call.

Set command: **+CLIP=** [< n >]

Options:	<n>	0	Disable.
		1	Enable.
			Default = 0 .

Example: AT+CLIP=1
OK

Read command: **+CLIP?** Returns the current setting.

Returns:	+CLIP: <n>, <m>	
	<m>	0 CLIP not provisioned.
		1 CLIP provisioned.
		2 Unknown, e.g. no network.

Example: AT+CLIP?
+CLIP: 1,1
OK

Test command: **+CLIP=?** Returns (0-1).

Example: AT+CLIP=?
+CLIP: (0-1)
OK

Unsolicited Result
code: **+CLIP:** <number>,<type>

AT Commands Phone Terminal Terminated

+CLIR *Calling line identification restriction*

Description: Calling line identification restriction allows the calling subscriber to enable or disable the presentation of the calling line identity to the called party.

Set command: **+CLIR=[<n>]**

Options:	<n>	0	Presentation according to the subscription of the CLIR service.
		1	CLIR invocation.
		2	CLIR suppression.
			Default = 0 .

Example: AT+CLIR=1

OK

Read command: **+CLIR?** Returns the current setting.

Returns: +CLIR: <n>,<m>
 <m>

		CLIR service status in the network.
	0	CLIR not provisioned.
	1	CLIR provisioned in permanent mode.
	2	Unknown, e.g. no network.
	3	CLIR temporary mode, presentation restricted.
	4	CLIR temporary mode, presentation allowed.

AT Commands Phone Terminal Terminated

Example: AT+CLIR?
 +CLIR: 1,1
 OK

CLIR invoked and
permanently provisioned.

Test command: **+CLIR=?** Always returns (0-2).

Example: AT+CLIR=?
 +CLIR: (0-2)
 OK

AT Commands Phone Terminal Terminated

+CCFC *Call forwarding*

Description: Allows control of the call forwarding supplementary service. Registration, erasure, activation, deactivation and status query are all supported.

Set command: **+CCFC**=<reason>,<mode>[,<number>[,<type>[,<classx>]]]

Options:	<reason> 0	Unconditional.
	1	Mobile busy.
	2	No reply.
	3	Not reachable.
	4	All call forwarding.
	5	All conditional call forwarding.
	<mode> 0	Disable.
	1	Enable.
	2	Query status.
	3	Registration.
	4	Erasure.
	<number> String	String type phone number of forwarding address in format specified by <type>.
	<type> Integer	Type of octet address in integer format (GSM 04.08, [3]). Default 145 when international code included, otherwise 128.

AT Commands Phone Terminal Terminated

	<class> 1	Voice L1.
	2	Data.
	4	Fax.
	128	Voice L2.
Query (mode=2) returns:	+CCFC: <status>,<class1>[,<number>,<type>][<CR><LF> +CCFC: <status>,<class2>[,<number><type>] [...]]	
Defined values:	<status> 0	Active voice.
	1	Active.
Example 1:	AT+CCFC=1,1,"931123456" OK Enable CFB.	
Example 2:	AT+CCFC=1,2 +CCFC: Query CFNRy. "35821654321",145,,,20 OK Forward after 20 seconds.	
Example 3:	AT+CCFC=1,3,"931123456" OK Registration.	
Example 4:	AT+CCFC=1,4,"931123456" OK Erasure.	
Test command:	+CCFC=?	Always returns (0-5).
Example:	AT+CCFC=? +CCFC: (0-5) OK	

AT Commands Phone Terminal Terminated

+CCWA *Call waiting*

Description: Allows control of the call waiting supplementary service.

Set command: **+CCWA=[<n>[,<mode>[,<classx>]]]**

Options:	<n>	0	Disable the result code representation.
		1	Enable the result code representation.
	<mode>	0	Disable.
		1	Enable.
		2	Query status.
	<classx>	1	Voice L1.
		2	Data.
		4	Fax.
		128	Voice L2.

Returns: When <mode>=2 and command is successful.

```
+CCWA:
<status>,<class1>[<CR><LF>+CCWA:
<status>,<class2>[...]]
```

Example 1: AT+CCWA=1,1 Enable call waiting.

OK

Example 2: AT+CCWA=1,2

+CCWA: 1,1

+CCWA: 1,2

+CCWA: 1,4

+CCWA: 0,128

OK

AT Commands Phone Terminal Terminated

Read command: **+CCWA?** Returns the current setting.

Example: AT+CCWA?

+CCWA: 1

OK

Test command: **+CCWA=?** Always returns (0-1).

Example: AT+CCWA=?

+CCWA: (0-1)

OK

Unsolicited Result
code: **+CCWA:** <number>, <type>, <class>

AT Commands Phone Terminal Terminated

+CHLD *Call related supplementary services*

Description: Temporarily disconnects a call, but retains the connection to the network and to a service that allows multiparty conversation.

Execute command: **+CHLD=<n>**

Options:	<n>	0	Releases all held calls or sets User Determined User Busy (UDUB) for a waiting call.
		1	Releases all active calls (if any exist) and accepts the other (held or waiting) call.
		1X	Release a specific active call X.
		2	Places all active calls (if any exist) on hold and accepts the other (held or waiting) call.
		2X	Places all active calls on hold except call X with which communication is supported.
		3	Adds a held call to the conversation.
		4	Connects the held and waiting call and disconnects the user.

Example 1: AT+CHLD=1
 OK

Activate call hold and waiting.

Example 2: AT+CHLD=0
 OK

Deactivate.

AT Commands Phone Terminal Terminated

Test command: **+CHLD=?** Always returns (0-4,11-16,21-26).

Example: AT+CHLD=?
+CHLD: (0-4,11-16,21-26)
OK

Note that X is the numbering (starting with 1 but not greater than 6) of the call given by the sequence of setting up or receiving calls (active, held or waiting) as seen by the served subscriber. Calls hold their number until they are released and new calls take the lowest possible number.

Where both a held call and a waiting call exists, the procedures will apply to the waiting call (not the held call) in a conflicting situation.

Note that the “directory number” case will be handled by the dial command D and the END case with hangup command H or +CHUP.

AT Commands Phone Terminal Terminated

+CSSN *Supplementary service notifications*

Description: Allows supplementary service related network initiated notification result codes to be presented.

Set command: **+CSSN**=[<n>[,<m>]]

Options:	<n>	0	Disable +CSSI result code presentation.
		1	Enable +CSSI result code presentation.
	<m>	0	Disable +CSSU result code presentation.
		1	Enable +CSSU result code presentation.

Example: AT+CSSN=1 , 1

OK Enable.

Read command: **+CSSN?** Returns the current setting.

Example: AT+CSSN?

+CSSN: 1 , 1

OK

Test command: **+CSSN=?** Always returns (0-1),(0-1).

Example: AT+CSSN=?

+CSSN: (0 - 1) , (0 - 1)

OK

Unsolicited Result
code: **+CSSU**:<code2>[,<index>]

AT Commands Phone Terminal Terminated

Intermediate
Result codes:

+CSSI:<code1>[,<index>]

<code1>	0	Unconditional call forwarding active.
	1	Some conditional call forwardings active.
	2	Call has been forwarded.
	3	A call is waiting.
	4	CUG call. Not supported.
	5	Outgoing calls barred.
	6	Incoming calls barred.
	7	CLIR suppression rejected.
<index>	0...9	CUG index.
	10	no index.

Unsolicited Result
code:

+CSSI:<code2>

AT Commands Phone Terminal Terminated

+CACM *Accumulated Call Meter*

Description: Resets the Advice of Charge related accumulated call meter value in SIM file EFACM. ACM contains the total number of home units for both the current and preceding calls.

Set command: **+CACM=[<passwd>]**

Options: <passwd> **String** SIM PIN2 password

Example: AT+CACM= Resets the ACM value.

OK

Read command: **+CACM?** Returns the current value.

Returns: **+CACM:** <acm>

Defined values: <acm> **String** Accumulated call meter value similarly coded as <ccm> under +CAOC.

Example: AT+CACM?

+CACM: 00A41B

OK

Test command: **+CACM=?**

Example: AT+CACM=?

OK

AT Commands Phone Terminal Terminated

+CAMP *Accumulated Call Meter Maximum*

Description: Set command sets the Advice of Charge related accumulated call meter maximum value in SIM file EFACMmax.

Set command: **+CAMP=[<acmmax>[,<passwd>]]**

Options: **<acmmax String >** Accumulated call meter maximum value similarly coded as <ccm> under +CAOC; value zero disables ACMmax feature

<passwd> String SIM PIN2 password

Example: AT+CAMP=001000
 OK

Read command: **+CAMP?** Returns the current value.

Example: AT+CAMP?
 +CAMP: 001000
 OK

Test command: **+CAMP=?**

Example: AT+CAMP=?
 OK

***EALS** *Ericsson Request ALS Status*

Description: Used to request the MS to give status for ALS (Alternate Line Services). The information is available on the SIM card. If ALS is active, the user has two lines for voice calls. The line number or name tag for the line is then indicated on the display.

Execute command: ***EALS**

Returns: ***EALS: <status>**

Defined values	<status> 0	ALS function is not active (off).
	1	ALS function is active (on).

Example: AT*EALS

 *EALS:0

 OK

Test command: ***EALS=?**

Example: AT*EALS=?

 OK

AT Commands Phone Terminal Terminated

***ELIN** *Ericsson line set*

Description: This requests the ME to set the current line to <line>.

Set command: ***ELIN=<line>**

Options: <line> **1** L1
 2 L2

Example: AT*ELIN=1
 OK

Read command: ***ELIN?**

Example: AT*ELIN?
 *ELIN: 1
 OK

Test command: ***ELIN=?**

Example: AT*ELIN=?
 *ELIN: (1-2)
 OK

AT Commands Phone Terminal Terminated

OK

AT Commands Phone Terminal Terminated

***EPNW** *Ericsson Write SIM Preferred Network*

Description: Used to edit the SIM preferred list of networks (EFPLMNsel).

Set command: ***EPNW=[<index>] [,<format>,<oper>]**

Options: <index> **Integer** Index to entry in SIM preferred list. The SIM preferred list contains at least 8 positions according to GSM 11.11.

 <format> **0** Long format alphanumeric <oper>. Not supported!

1 Short format alphanumeric <oper>. Not supported!

2 Numeric <oper>. Default=**2**

 <oper> **String** String indicates the code for the operator. E.g. GSM - Sweden - Europolitan: "24008" (3 + 2). PCS: 3 digits for Country and 3 digits for Network.

Example: AT*EPNW=1 , , 24008
 OK

Test command: ***EPNW=?**

Example: AT*EPNW=?
 *EPNW: (1-2) , 2
 OK

AT Commands Phone Terminal Terminated

***ESLN** *Ericsson Set Line Name*

Description: Sets the nametag for a selected line.

Set command: ***ESLN=<line>[,<name>]**

Options:	<line>	0	The two lines will use the default name tags, i.e. "L1" and "L2". Default= 0 .
		1	Line 1
		2	Line 2
	<name>	String	Characters for name tag. This parameter is optional when <line> is set to 0.

Example: AT*ESLN=2,Private

OK

Read command: ***ESLN?**

Example: AT*ESLN?

*ESLN:1,L1

*ESLN:2,Private

OK

Test command: ***ESLN=?**

Returns: ***ESLN:(list of supported <line>s),<lname>**

Defined values: **<lname>** **Integer** Max. number of characters to use in <name> string.
Default=**20**.

Example: AT*ESLN=?

*ESLN: (1-2),20

OK

***ESCN** **Ericsson Set Credit Card Number**

Set command: ***ESCN**=<mode> [,<passwd>][,<indexn>]
[,<asn>,<type>,<name>,<vercode>,<send order>]]

1 Disable credit card calling
 (<passwd>).

2 Enable one of the credit card call services (<passwd>, <indexn>).

3 Query (<passwd>, <indexn>).

4 Query for the selected credit call access server.

<passwd> String	Phone lock code "PS", PH-SIM.
------------------------	-------------------------------

<indexn> 1	Index number to the 1st Credit Card Call access server.
------------	---

2 Index number to the 2nd Credit Card Call access server.

AT Commands Phone Terminal Terminated

	<asn>	0..9,+	Max. 20 characters Phone number of format specified by <typex>.
	<type>	Integer	Type of address, (refer GSM 04.08 [3] subclause 10.5.4.7).
	<name>	String	Character string of the name tag.
	<vercode>	0..9,A,B,C	Max. 20 characters.
	>	,D,#,*	
	<send order>	1	Verification code 1st Default=1.
		2	Phone number to call 1st.
Query (mode=3) returns:	*ESCN: <indexn>,<asn>,<type>,<name>,<vercode>,<send order>		
Query (mode=4) returns:	*ESCN: <selindexn>		
Defined values:	<selindex n>	0	Credit card calling disabled. Default= 0 .
		1	Index number to the 1st Credit Card Call access server.
		2	Index number to the 2nd Credit Card Call access server.
Test command:	*ESCN=?		
Example:	AT*ESCN=?		
	*ESCN: (1-2) , (0-4) , (1-2)		
	OK		

AT Commands Phone Terminal Terminated

+CPUC *Price Per Unit And Currency Table*

Description: Sets the parameters of Advice of Charge related price per unit and currency table in SIM file EFPUCT. PUCT information can be used to convert the home units (as used in +CAOC, +CACM and +CMM) into currency units.

Set command: **+CPUC=<currency>,<ppu>[,<passwd>]**

Options:	<currency String >	Alpha-identifier of the currency code (3 characters, e.g. SEK)
	<ppu> String	Price per unit; dot is used as a decimal separator (e.g. "2.66")
	<passwd> String	SIM PIN2 password.

Example: AT+CPUC= SEK,2.66
OK

Read command: **+CPUC?**

Example: AT+CPUC?
+CPUC: SEK,2.66
OK

Test command: **+CPUC=?**

Example: AT+CPUC=?
OK

AT Commands Phone Terminal Terminated

***ESVM** *Ericsson Set Voice Mail Number*

Description: The number to the voice mail server is set with this command. If ALS is active, L1 and L2 has one voice mail number each. The numbers can be different or the same.

Set command: ***ESVM=<line>,<onoff>[,<number>,<type>]**

Options:	<line>	1	Line 1
		2	Line 2
	<onoff>	0	Disable the voice mail number. Shortcut menu on the phone MMI is removed. Not Supported.
		1	Enable the voice mail number.
	<number>	0..9,+	Character string.
	<type>		Type of address octet (refer GSM 04.08 [3] section 10.5.4.7)
		129	ISDN / telephony numbering plan, national / international unknown.
		145	ISDN / telephony numbering plan, international number
		161	ISDN / telephony numbering plan, national number.
		128..255	Other values refer GSM 04.08 [3] section 10.5.4.7.

Example: **AT*ESVM=1,1,"90823677",129**

OK

Read command: ***ESVM?**

AT Commands Phone Terminal Terminated

Example: AT*ESVM?

*ESVM: 1,1,"90823672",129

OK

Test command: ***ESVM=?**

Example: AT*ESVM=?

*ESVM: (1-2),(0-20 - maximum length of
1),20 voice mail number.

OK

***EDIF** *Ericsson Divert Function*

Description: Enables and disables notification of divert status changes with the unsolicited result code *EDIF.

Set command: ***EDIF=<onoff>**

Options: <onoff> **0**

Disable notification with the unsolicited result code *EDIF

1

Enable notification with the unsolicited result code *EDIF

Example: AT*EDIF=1

OK

Read command: ***EDIF?**

Example: AT*EDIF?

*EDIF: 1

OK

Test command: ***EDIF=?**

Example: AT*EDIF=?

*EDIF: (0-1)

OK

AT Commands Phone Terminal Terminated

***EDIS** *Ericsson Divert Set*

Description: Enables and disables the divert setting in the currently active profile. The command is also used to set the divert number for the profile. See also the command AT+CCFC.

Set command: ***EDIS=<onoff>[,<number>[,<type>]]**

Options:	<onoff>	0	Disable unconditional divert for the profile
		1	Enable unconditional divert for the profile
	<number>	String	String type phone number of forwarding address in format specified by <type>.
	<type>	Integer	Type of octet address in integer format (GSM 04.08, [3]). Default 145 when international code included, otherwise 129.

Example: AT*EDIS=1,TBA
OK

Read command: ***EDIS?**

Example: AT*EDIS?
*EDIS: TBA
OK

Test command: ***EDIS=?**

Example: AT*EDIS=?
*EDIS: (0-1)
OK

Unsolicited Result Codes

+CREG *Network Registration*

Description: Indicates a change in the ME network registration status.

Unsolicited Result code:	+CREG: <stat>	Produced when an accessory is connected to the MS (i.e. DTMS is asserted).
Defined values:	<stat>	
	0	Not registered, ME is not currently searching a new operator to register to.
	1	Registered, home network.
	2	Not registered, but ME is currently searching a new operator to register to.
	3	Registration denied.
	4	Unknown.
	5	Registered, roaming.

+CLIP *Calling Line Identification Presentation*

Please refer to AT command [+CLIP](#).

AT Commands Phone Terminal Terminated

+CCWA *Call Waiting*

Description: Allows control of the Call Waiting supplementary service.

Unsolicited Result

code: **+CCWA:** <number>, <type>, <class>

Defined values: <number> **string** Phone number of format specified by <type>.

 <type> **integer** Address octet in integer format (see GSM 04.08 [4] subclause 10.5.4.7)

 <class> **integer** Sum of integers each representing a class of information.

1 voice L1.

2 Data. Not supported

4 Fax. Not supported

128 Voice L2.

AT Commands Phone Terminal Terminated

+CSSU *Supplementary service notification*

Description: Refers to supplementary service related network initiated notifications.

Unsolicited Result

code: **+CSSU:** <code2>[,<cindex>]

Defined values:	<code2>	0	This is a forwarded call (MT call setup).
		1	This is a CUG call (also <cindex> present) (MT call setup) Not supported
		2	Call has been put on hold (during a voice call).
		3	Call has been retrieved (during a voice call).
		4	Multiparty call entered (during a voice call).
		5	Call on hold has been released (this is not an SS notification) during a voice call.
		6	Forward check SS message received (can be received whenever)
		16	This is a CUG call (also <cindex> present) (MT call setup)
	<cindex>	0..32767	CUG index

AT Commands Phone Terminal Terminated

+CSSI *Supplementary service notification*

Description Refers to supplementary service related network initiated notifications.

Unsolicited Result

code: **+CSSI:** <code1>[,<cindex>]

Defined values:	<code1>	0	This is a forwarded call.
		1	CUG call. Not supported.
		2	Call has been put on hold.
		3	Call has been retrieved.
		4	CUG call. Not supported.
		5	The call on hold has been released. (Not a SS Notification).
		6	Forward check SS message. Not supported.
		7	CLIR suppression rejected
		16	This is a CUG call (also <cindex> present)
	<cindex>	0..32767	CUG index

AT Commands Phone Terminal Terminated

***EDIF** *Ericsson Divert Function*

Description This unsolicited result code is sent whenever the call forwarding information (divert) for the phone is changed. Enable with the AT*EDIF command.

Unsolicited Result code: ***EDIF:** <reason>, <status>, <classx> [, <number>, <type>]

Options:	<reason> 0	Unconditional.
	1	Mobile busy.
	2	No reply.
	3	Not reachable.
	<status> 0	Disabled.
	1	Enabled, the phone is diverted for the <reason> above.
	<classx> integer	Sum of integers each representing a class of information.
	1	Voice L1.
	2	Data.
	4	Fax.
	0..127	Also all other values below 128 are reserved by ETSI.
	128	Voice L2.
	<number> string	Phone number of format specified by <type>.

AT Commands Phone Terminal Terminated

<type>	integer	Address octet in integer format (see GSM 04.08 [4] subclause 10.5.4.7). Default 145 when international code included, otherwise 129.
--------	----------------	---

4.7 Ensemble S8/C/E : GSM Facility Lock

+CLCK *Facility lock*

Description: Locks or unlocks a ME or network facility. These operations require a password.

Set command: **+CLCK=<fac>,<mode>[,<passwd>[,<class>]]**

Options:	<fac>	"CS"	Lock Control Surface, e.g.phone, keyboard.
		"PS"	Lock Phone to SIM card.
		"SC"	Lock SIM Card.
		"P2"	SIM PIN2
		"AO"	Bar All Outgoing calls.
		"OI"	Bar Outgoing International Calls.
		"AI"	Bar All Incoming calls.
		"IR"	Bar Incoming calls when Roaming outside the home country.
		"OX"	Bar Outgoing international calls eXcept to home country.
		"AB"	All Barring services.
		"AG"	All outgoing barring services.
		"AC"	All incoming barring services.

AT Commands Phone Terminal Terminated

<mode>	0	Unlock.
	1	Lock.
	2	Query status.
	10	Full lock (only valid for <fac>="PS", after power on always ask for password).
<passwd>		String type password defined in +CPWD command.
<class>	1	Voice L1.
	2	Data.
	4	Fax.
	8..127	Reserved.
	128	Voice L2.

Example 1: +CLCK="CS" , 1 , "passwd"
OK Lock phone keyboard.

Example 2: +CLCK="PS" , 1 , "passwd"
OK Lock phone to SIM card.

Example 3: +CLCK="CS" , 2
+CLCK: 1 Lock phone keyboard is activated.
OK

Test command: **+CLCK=?** Always returns
("CS", "PS", "SC", "P2", "AO",
"OI", "OX", "AI", "IR", "AB",
"AG", "AC").

Returns: <status> **0** Not active.
1 Active.

Example: AT+CLCK=?

AT Commands Phone Terminal Terminated

```
+CLCK: ( "CS", "PS", "SC", "P2", "AO",  
"OI", "OX", "AI", "IR", "AB", "AG", "AC" )
```

```
OK
```

AT Commands Phone Terminal Terminated

+CPWD *Set/change new password*

Description: Action command sets a new password for the facility lock function defined by command Facility Lock +CLCK.

Set command: **+CPWD=<fac>,<oldpwd>, <newpwd>**

Options:	<fac>	"PS"	lock Phone to SIM card.
		"SC"	lock SIM Card.
		"P2"	SIM PIN2.
		"AO"	bar All Outgoing calls.
		"OI"	bar Outgoing International calls.
		"AI"	bar All Incoming calls.
		"IR"	bar Incoming calls when Roaming outside the home country.
		"OX"	bar Outgoing international calls eXcept to home country.
		"AB"	All Barring services.
		"AG"	All outGoing barring services.
		"AC"	All inComing barring services.
	<oldpwd>		same as password specified for the facility from the ME user interface.
	<newpwd>		create a new password, length determined with <pwdlength>.

AT Commands Phone Terminal Terminated

Example: AT+CPWD="SC", "4321", "1234"

OK

Lock SIM card and change password.

Test Command: **+CPWD=?**

Returns: +CPWD: list of supported (<fac>,<pwdlength>)s
<pwdlength> Integer type, maximum length of the password.

Example: AT+CWPDP=?

+CPWD: ("PS", 8), ("SC", 8), ("P2", 8),
("AO", 8), ("OI", 8), ("OX", 8), ("AI", 8),
("IR", 8), ("AB", 8), ("AG", 8), ("AC", 8)

OK

4.8 Ensemble C9/C/E : Multi Mode Phones

+WS46 *Mode selection*

Description: Allows an accessory to query and control the cellular protocol mode of the phone.

Set command:	+WS46=[n]	
<n>	0	All systems. No wireless stack is active and the phone is not connected to a charger.
	1	GSTN (telephone), analog. Enables standard voice / data / fax modem behavior.
	2	Mobitex. Used by Ericsson Mobitex wireless packet data adapters.
	4	Cellular Digital Packet Data.
	7	AMPS Analog Cellular - Data Mode. Causes the MS to set a number of parameters to enable a AMPS analog cellular data call to be made.
	12	GSM Digital Cellular. Used for GSM at 900 Mhz, DCS-1800, and PCS-1900 phones.
	13	CDMA Digital Cellular. Used by the WCS phones.
	14	TDMA Digital Cellular (DAMPS) Mode. For IS-135 asynchronous data/ fax and voice services.
	15	Concurrent access to multiple wireless data services. Used to invoke an IP modem interface along with AT +WS45.

AT Commands Phone Terminal Terminated

- 17** AMPS Analog Cellular - Voice Mode. Returned in response to AT+WS46? during a call at 800 Mhz. Other multi-mode phone systems (WCS, PCS-1900) support the set command to this value (not DAMPS phones).
- 240** Charge Only Mode. Indicates that no wireless stack is active and the phone is connected to a charger.
- 241** ACES Satellite Mode. Used by Ericsson ACES Satellite phones.
- 242** Reserved
- 243** 800 Mhz. AMPS Only Mode. A phone with AMPS capability is commanded to scan at 800 Mhz. and camp on an 800 Mhz. control channel. The phone requests an AMPS analog voice channel for incoming and outgoing calls. The set command is accepted only when there is no call in progress.
- 244** Reserved
- 245** Multi-scan mode. The phone scans multiple systems for incoming calls according to a prioritized list. Outgoing data calls are attempted according to the same prioritized list.

Example: AT+WS46=12

OK

Read command **+WS46?**

Example: AT+WS46?

+WS46: 12 GSM Digital Cellular.

OK

Test command: **+WS46=?**

AT Commands Phone Terminal Terminated

Example: AT+WS46=?
 +WS46: (0,12,240)
 OK

4.9 Ensemble S9/C/E : GSM Mobile Equipment,Control and Status

+CKPD *Keypad control*

Description: Emulates the ME keypad by giving each character in a string with stroke and pause times *0.1 seconds.

Execute command: **+CKPD=<keys>[,<time>[,<pause>]]**

<keys>	#	Hash(number).
	*	Star(*).
	0... 9	Number keys.
	<	Left arrow.
	>	Right arrow.
	C/c	Clear display (C/CLR).
	D/d	Volume down.
	E/e	Connection end.
	S/s	Connection start (SEND).
	U/u	Volume up.
<time>	0..255	0..25.5 seconds.
<pause>	0..255	0..25.5 seconds.

Example: AT+CKPD=" C " , 20

 OK

 Clear main display by holding clear button down for two seconds.

Test command: **+CKPD=?**

Example: AT+CKPD=?

 OK

+CIND *Indicator control*

“call” Call in progress (0-1).

“roam”	roaming indicator (0-1) (Home net status, 0 = Home Net).
“smsfull”	a short message memory storage in the MT has become full (1), or memory locations are available (0); i.e. the range is (0-1).

Example: AT+CIND=?

```
+CIND: ("battchg",(0-4)),("sig-  
nal",(0-5)) ,("batterywarn-  
ing",(0-1))  
 ,("chargerconnected",(0-  
1)),("service",(0-  
1)),("sounder",(0-1)),("mes-  
sage",(0-1)),("call",(0-  
1)),("roam",(0-1)),("sms-  
full",(0-1))
```

OK

AT Commands Phone Terminal Terminated

+CPAS *Mobile phone activity status*

Description: Returns the activity status of the mobile phone.

Execute command: **+CPAS=<mode>**

Options: <mode> **1** Allows the CPAS to return Ericsson specific <pas> values, such as 129, 130 and 131.

Returns: +CPAS: <pas>

<pas>	0	Ready.
	3	Ringing.
	4	Call in progress.
	129	MMI in idle state. This is a substate of (0) ready. 1. Operator, clock and date. 2. No conversion or data call in progress. 3. No submenus shown. 4. Only digits clear, *, NO, and # allowed.
	130	Mobile oriented call in progress. This is a sub-state to 'call in progress' (4).
	131	Mobile terminated call in progress. This is a sub-state to 'call in progress' (4).

Example: AT+CPAS=1
 +CPAS: 0
 OK

Test command: **+CPAS=?**

Example: AT+CPAS=?

AT Commands Phone Terminal Terminated

+CPAS: (0 , 3 , 4 , 129 , 130 , 131)

OK

AT Commands Phone Terminal Terminated

+CPIN *Send Password*

Description: Sends the password to the ME, this is necessary to make the ME operational.

Execute command: **+CPIN=<pin>[,<newpin>]**

Options: <pin> Numeric string type values.

 <newpin> The range for SIM PIN and PH-SIM is 4-8 digits. SIM PUK consists of 8 digits.

Example: AT+CPIN="1234"

 OK

Read command: **+CPIN?**

Returns: +CPIN: <code>

 <code> **READY** ME has no pending request for any password.

SIM PIN ME is waiting SIM PIN to be entered.

SIM PUK ME waiting SIM PUK to be entered.

PH-SIM PIN ME waiting PPhone to SIM password to be entered.

SIM PIN 2 ME waiting SIM PIN 2 to be entered. This <code> is recommended to be returned only when the last executed command resulted in PIN2 authentication failure.

SIM PUK 2ME waiting SIM PUK 2 to be entered. (this <code> is recommended to be returned only when the last executed command resulted in PUK2 authentication failure.

BLOCKEDSIM card blocked for user.

Example: AT+CPIN?
+CPIN: READY
OK

Test command: **+CPIN=?**

Example: AT+CPIN=?
+CPIN (READY,SIM PIN,SIM PUK,SIM PIN 2,
SIM PUK 2,PH-SIM PIN,BLOCKED)
OK

AT Commands Phone Terminal Terminated

+CBC *Mobile phone battery charge*

Description: Returns the connection status and charge level of the mobile phone battery.

Execute command: **+CBC**

Returns: +CBC: <bc>,<bcl>

<bc>	0	mobile phone is powered by the battery.
	1	mobile phone has the battery connected but is not powered by it.
	2	mobile phone does not have a battery connected.
<bcl>	0	battery discharged.
	1-99	Battery charging level, battery has 1-99 percent of capacity remaining.
	100	Battery fully charged.

Example: AT+CBC

 +CBC: 0,50

 OK ME powered by battery with 50% capacity remaining.

Read command: **+CBC?** Returns (0-1),(0-100).

Returns: +CBC: <bc>,<bcl>

Example: AT+CBC?

 +CBC: 0,50

 OK ME powered by battery with 50% capacity remaining.

Test command: **+CBC=?** Returns (0-1),(0-100).

Example: AT+CBC=?

AT Commands Phone Terminal Terminated

+CBC: (0-2),(0-100)

OK

AT Commands Phone Terminal Terminated

+CSQ *Mobile phone signal quality*

Description: Returns the signal strength and channel bit error rate at the mobile phone. Test command returns values supported by the TA as compound values.

Execute command: **+CSQ**

Returns: **+CSQ: <rss>,<ber>**

<rss>	0	-113 dBm or less.
	1	-111 dBm.
	2-30	-109 dBm to -53 dBm.
	31	-51 dBm or greater.
	99	Not known or not detectable.
<ber>	0-7	As RXQUAL values in GSM 05.08.
	99	Not known or not detectable.

Example: AT+CSQ

 +CSQ: 0,0

 OK

Test command: **+CSQ=?** Returns (0-31),(99).

Example: AT+CSQ=?

 +CSQ: (0-31,99),(0-7,99)

 OK

AT Commands Phone Terminal Terminated

+CMER *Mobile equipment event reporting*

Description: Set command enables or disables the sending of unsolicited results codes from TA to TE.

Set command: **+CMER=[<mode>[,<keyp>[,<disp>[,<ind>[,<bfr>]]]]]**

<mode>	0	Buffer unsolicited result codes in the TA.
	3	Forward unsolicited result codes directly to the TE.
		Default = 0 .
<keyp>	0	No keypad even reporting.
	2	Keypad event reporting using result code +CDEV All key pressings are indicated.
		Default = 0 .
<disp>	0	No Display event reporting.
	2	Display event reporting using +CDEV. All events are indicated.
		Default = 0 .
<ind>	0	No indicator reporting.
	1	Indicator reporting using +CIEV. Only events not caused by +CIND are indicated.
		Default = 0 .
<bfr>	0	When mode (1..3) entered TA buffer is cleared of unsolicited result codes defined within this command.

AT Commands Phone Terminal Terminated

Example: AT+CMER=0,0,1,0,0

OK

Read Command: **+CMER?**

Example: AT+CMER?

+CMER: 0,0,1,0,0

OK

Test Command: **+CMER=?**

Example: AT+CMER=?

+CMER: (0,3),(0,2),(0,2),(0-1),(0)

OK

+CVIB *Vibrator Mode*

Description: used to enable and disable the vibrator alert feature of the ME.

Set command: **+CVIB=<mode>**

<mode>	0	Disable.
	1	Enable.
	16	Enable when silent.

Example: AT+CVIB=0
OK

Read Command: **+CVIB?**

Example: AT+CVIB?
+CVIB: 0
OK

Test Command: **+CVIB=?**

Example: AT+CVIB=?
+CMER: (0,1,16)
OK

AT Commands Phone Terminal Terminated

***EDME** *Ericsson enable data menus*

Description: Enables or disables data menus on the phone.

Set command: ***EDME=<onoff>**

Options: <onoff> **0** Disable call data menus.

1 Enable call data menus.

Default 0.

Example: AT*EDME=0

 OK

Read command: ***EDME?**

Example: AT*EDME?

 *EDME: 0

 OK

Test command: ***EDME=?**

Example: AT*EDME=?

 *EDME: (0-1)

 OK

AT Commands Phone Terminal Terminated

***ELAN** *Ericsson Language*

Description: When the user has selected the language in the interface the command sets the language in the ME.

Set command: ***ELAN=<code>**

Options:	<code>	"AUTO"	Language is read from SIM card. "AUTO" is never returned by the read-command.
		"sv"	Swedish.
		"fi"	Finnish.
		"da"	Danish.
		"no"	Norwegian.
		"de"	German.
		"fr"	French.
		"es"	Spanish.
		"it"	Italian.
		"en"	English.
		"ae"	American.

Example: `AT*ELAN="sv"`
OK

Read command: ***ELAN?** Current language.

Example: `AT*ELAN?`
`*ELAN: "sv"`
OK

Test command: ***ELAN=?**

Example: `AT*ELAN=?`
`*ELAN:(list of supported languages)`

AT Commands Phone Terminal Terminated

OK

AT Commands Phone Terminal Terminated

***EMAR** *Ericsson master reset*

Description: Requests the ME to reset user data.

Set command: ***EMAR=<phone lock code>**

Options: <phone **String** Security code (Phone Lock
lock code> code) must be verified
before performing the
master reset.

Example: AT*EMAR=" 8765 "

OK

Read command: ***EMAR=?**

Example: AT*EMAR=?

OK

AT Commands Phone Terminal Terminated

***ERIL** *Ericsson ring level set*

Description: Sets the ring volume level. Note that the <place>-parameter should be ignored for phones with profile features.

Set command: ***ERIL=<volume>[,<call type>[,<place>]]**

Options:	<volume> 0	Off.
	1-6	Volume setting, not increasing ring.
	129-134	Volume setting, increasing ring.
	<call type> 1	Line 1. Default= 1 .
	2	Line 2.
	3	Fax.
	4	Data.
	<place> 0	Hand held. Default= 0 .
	1	Car mounted.

Example: AT*ERIL=3,1,1
OK

Read command: ***ERIL?**

Example: AT*ERIL?
*ERIL: 3,1,1
*ERIL: 3,2,1
*ERIL: 4,3,0
*ERIL: 6,4,0
OK

Test command: ***ERIL=?**

Example: AT*ERIL

AT Commands Phone Terminal Terminated

*ERIL: (0-6,129-134),(1-4),(0-1)

OK

***ERIN** *Ericsson ring set*

Description: Sets the ring type for incoming calls.

Set command: ***ERIN**=<sound type>,[<call type>]

Options:	<sound type>	1	Low ring signal.
		2	Medium ring signal.
		3	High ring signal.
		4	Mixed ring signal.
		11-20	Melody 1-10 - preset.
		31-34	Own melodies 1-4.
	<call type>	1	Line 1. Default=1.
		2	Line 2.
		3	Fax.
		4	Data.
		5	Alarm.

Example: AT*ERIN=1,1
OK

Read command: ***ERIN?**

Example: AT*ERIN?
*ERIN:1,1
OK

Test command: ***ERIN=?**

Example: AT*ERIN=?
*ERIN:(1-4,11-20,31-34),(1-5)
OK

AT Commands Phone Terminal Terminated

***ERIP** *Ericsson ring signal playback command*

Description: Used to play one of the sound types that are available as a ring signal on the phone.

Set command: ***ERIP=<volume>,<sound type>**

Options:	<volume>	0	Off.
		1	Step.
		2-7	Volume setting.
	<sound type>	1	Low ring signal.
		2	Medium ring signal.
		3	High ring signal.
		4	Mixed ring signal.
		11	Melody 1.
		12-20	Melody 2-20 - preset.
		31-34	Own melodies 1-4.

Example: AT*ERIP=3,3

OK

Test command: ***ERIP=?**

Example: AT*ERIP=?

*ERIP: (0-7),(1-4,11-20,31-34)

OK

***ESIL** *Ericsson silence command*

Description: Sets silent mode on the phone. An icon will be displayed when the phone is in silent mode.

Set command: ***ESIL=<mode>**

Options: <mode> **0** Off.

1 On.

Example: AT*ESIL=0

 OK

Read command: ***ESIL?**

Example: AT*ESIL?

 *ESIL: 0

 OK

Test command: ***ESIL=?**

Example: AT*ESIL=?

 *ESIL: (0-1)

 OK

***ESKL** *Ericsson settings key lock mode*

Set command:	*ESKL =<mode>		
Options:	<mode>	0	Manual.
		1	Automatic.

Read command: ***ESKL?**

Page 128
Online Reference

AT Commands Phone Terminal Terminated

***ESKS** *Ericsson settings key sound*

Description: Sets the key sound mode of the MS.

Set command: ***ESKS=<mode>**

Options:	<mode>	0	Silent.
		1	Click.
		2	Tone.

Example: AT*ESKS=2

OK

Read command: ***ESKS?**

Example: AT*ESKS?

*ESKS: 2

OK

Test command: ***ESKS=?**

Example: AT*ESKS=?

*ESKS: (0-2)

OK

AT Commands Phone Terminal Terminated

***ESMA** *Ericsson set message alert sound*

Description: Sets the message alert sound of the MS.

Set command: ***ESMA=<mode>**

Options:	<mode>	0	Silent.
		1	Click.
		2	Tone.

Example: AT*ESMA=1
OK

Read command: ***ESMA?**

Example: AT*ESMA?
*ESMA: 1
OK

Test command: ***ESMA=?**

Example: AT*ESMA=?
*ESMA: (0-2)
OK

AT Commands Phone Terminal Terminated

***ESMM** *Ericsson settings minute minder*

Description: Sets the minute minder on or off in the MS.

Set command: ***ESMM=<mode>**

Options:	<mode>	0	Minute minder Off.
		1	Minute minder On.

Example: AT*ESMM=0
OK

Read command: ***ESMM?**

Example: AT*ESMM?
*ESMM: 0
OK

Test command: ***ESMM=?**

Example: AT*ESMM=?
*ESMM: (0-1)
OK

AT Commands Phone Terminal Terminated

***ESAM** *Ericsson settings answer mode*

Description: Sets the answer mode settings in the MS.

Set command: ***ESAM=<mode>**

Options:	<mode>	0	Answer Mode is neither set to "Any key", nor "Auto" (off).
		1	Any Key Mode on.
		2	Auto Mode on.

Example: AT*ESAM=2

OK

Read command: ***ESAM?**

Example: AT*ESAM?

*ESAM: 2

OK

Test command: ***ESAM=?**

Example: AT*ESAM=?

*ESAM: (0-2)

OK

***ESBL** *Ericsson settings back light mode*

Description: Sets the back light mode of the MS. Note that the <place>-parameter should be ignored for phones with profile features.

Set command: ***ESBL=<place>,<mode>**

Options:	<place>	0	Handheld.
		1	Car mounted.
	<mode>	0	Always off.
		1	Always on.
		2	AUTO, back light is turned on when the ME reacts to a user event or when receiving a call. The light is then turned off after short while.

Example: AT*ESBL=0,1
OK

Read command: ***ESBL?**

Example: AT*ESBL?
*ESBL: 0,1
*ESBL: 1,1
OK

Test command: ***ESBL=?**

Example: AT*ESBL=?
*ESBL: (0-1),(0-2)
OK

AT Commands Phone Terminal Terminated

***ESDF** *Ericsson settings date format*

Description: Sets the date information format in the MS.

Set command: ***ESDF=<mode>**

Options:	<mode>	0	Off.
		1	DD-MMM-YY
		2	DD-MM-YY
		3	MM/DD/YY
		4	DD/MM/YY
		5	DD.MM.YY
		6	YYMMDD
		7	YY-MM-DD

Example: AT*ESDF=1
OK

Read command: ***ESDF?**

Example: AT*ESDF?
*ESDF: 1
OK

Test command: ***ESDF=?**

Example: AT*ESDF=?
*ESDF: (0-7)
OK

AT Commands Phone Terminal Terminated

***ESOM** *Ericsson settings own melody*

Description: Sets the user defined own melody in the MS.

Set command: ***ESOM**=<melody index>,<melody string>

Options: <melody index> **1-4** Melody 1-4.

 <melody string> **string** A sequence of <tones> and <pause> entries. The <tones> may be preceded by one or two <prefix>.

Melody characteristics: <p> **p** Pause.

 <prefix> **#** Half tone higher.

(b) Half tone lower.

+ One octave higher.

 <tones> **c,d,e,f,g,a,b,c**

 Short tones.

C,D,E,F,G,A,B,C

 Long tones.

Example: AT*ESOM=1 , "aAffFgaAgfEpgGefgeafDC"

 OK (The Swedish national anthem).

AT Commands Phone Terminal Terminated

Read command: ***ESOM?**

Example: AT*ESOM?

*ESOM: 1, "aAffFgaAgfEpgGefgeafDC"

OK

Test command: ***ESOM=?**

Response: (list of supported <melody index>),(list of supported <pause>s),(list of supported <prefix>s),(list of supported <tone>s), <mlength>,<mtones>

where: <mlength> **integer** maximum length of <melody string>
<mtones> **integer** maximum number of tones in <melody string>

Example: AT*ESOM=?

*ESOM: (1-4), ('p'), ('#', '(b)', '+'), ('c', 'd', , 'A', 'B'), 120, 40

OK

***ESTF** *Ericsson settings time format*

Set command: ***ESTF=<mode>**

Example: AT*ESTF=1
 OK

```
Example:  AT*ESTF?
          *ESTF: 1
          OK
```

Example: AT*ESTF=?
 *ESTF: (1-2)
 OK

Unsolicited Result Codes

+CKEV *Keypad event*

Description: Is enabled with the AT+CMER command and indicates key press/release.

Unsolicited Result

code: **+CKEV:** <key>,<press>

Defined values:	<key>	#	Hash(number).
		*	Star(*).
		0... 9	Number keys.
		<	Left arrow.
		>	Right arrow.
		C/c	Clear display (C/CLR).
		D/d	Volume down.
		E/e	Connection end.
		S/s	Connection start (SEND).
		U/u	Volume up.
		<press>	0 Key released
		1	Key pressed

Example: AT+CMER= , 2 , , 1 , Request unsolicited result codes for keypad- and indicator events.

OK

+CKEV: 49,1 Number-key "1" is pressed

+CKEV: 49,0 Number-key "1" is released

AT Commands Phone Terminal Terminated

+CIEV *Indicator event reporting*

Description: Is enabled with the AT+CMER command and indicates changes in indicator levels.

Unsolicited Result

code: **+CIEV:** <ind>,<value>

Defined values:	<ind>	1	Battery charge level indicator
		2	Signal quality indicator
		3	Battery warning indicator
		4	Charger connected indicator
		5	Service availability indicator
		6	Sounder activity indicator
		7	Message received indicator
		8	Call in progress indicator
		9	Transmit activated by voice activity indicator
		10	Roaming indicator
		11	Short message memory storage indicator in the MS.
	<value>	Integer	New value of the specific indicator.

Example: AT+CMER= , 2 , , 1 , Request unsolicited result codes for keypad- and indicator events.

OK

+CIEV: 2,5 Signal strength indicator changes its state to 5

AT Commands Phone Terminal Terminated

<number> string String type phone number as specified by <type>. Valid only for <ccstatus>=1.

<type> integer Address octet in integer format (see GSM 04.08 subclause 10.5.4.7). Default 145 when dialing string includes "+", otherwise 129. Valid only for <ccstatus>=1.

Example: ATD08044864; Dial number.

OK

*ECAV: CALLING

1,1,1,,084044864,129

*ECAV: 1,2,1,, CONNECTING

*ECAV: 1,3,1,, ACTIVE CALL

AT+CHLD=2 Put call on hold

OK

*ECAV: 1,4,1,, HOLD indication

AT+CHLD=2 Retrieve held call

OK

*ECAV: 1,3,1,, ACTIVE call again

ATH Hang up

OK

*ECAV: IDLE. Call Control (CC) exit cause 16 (normal clearing)
1,0,1,8,16

Example: RING Incoming call

*ECAV: 1,6,128,, ALERTING (VOICE2)

AT Commands Phone Terminal Terminated

RING

RING

ATA

Answer call

OK

*ECAV: 1,3,1,,

ACTIVE call indication.

*ECAV:

Remote party hangs up.

1,0,1,8,16

IDLE call state entered.

Call Control (CC) exit
cause 16 (normal clearing).

4.10 Ensemble S11/C/E : GSM SMS and CBS PDU Mode

+CSMS *Select SMS message service*

Description: Defines the message service and returns the functionality of the message service in the form:

Set command: **+CSMS=<service>**

Options: <service> **0** GSM 03.40 and 03.41 specific. (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported (e.g. correct routing of messages with new Phase 2+ data coding schemes))
Default=**0**.

1 GSM 03.40 and 03.41 specific. (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions).

2-127 Reserved. **Not Supported.**

Response: **+CSMS:<mt>,<mo>,<bm>**

<mt> **0** Mobile terminated messages not supported.

1 Mobile terminated messages supported.

AT Commands Phone Terminal Terminated

<mo>	0	Mobile originated messages not supported.
	1	Mobile originated messages supported.
<bm>	0	Broadcast messages not supported.
	1	Broadcast messages supported.

Example: AT+CSMS=0
+CSMS: 1,1,0
OK

Read command: **+CSMS?**

Response: **+CSMS:**<service>,<mt>,<mo>,<bm>

Example: AT+CSMS?
+CSMS: 1,1,0
OK

Test command: **+CSMS=?**

Response: **+CSMS:**<list of supported services>

Example: AT+CSMS=?
+CSMS: (0-1)
OK

AT Commands Phone Terminal Terminated

+CPMS: 3,20,3,20

OK

Read command: **+CPMS?** Returns the current setting.

Example: AT+CPMS?

+CPMS: "ME",5,10,"SM",3,20,"ME",5,10

OK

Test command: **+CPMS=?** Always returns
(ME,SM),(ME,SM),(ME).

Example: AT+CPMS=?

+CPMS: ("ME" , "SM") , ("ME" , "SM") ,
("ME")

OK

AT Commands Phone Terminal Terminated

+CMGL *List messages*

Description: Returns messages with status value <stat> from preferred message storage <mem1> to the TE.

Set command: **+CMGL=[<stat>]**

Options:	<stat>	0	Received unread messages. Default= 0 .
		1	Received read messages.
		2	Stored unsent messages. (only applicable to SMS)
		3	Stored sent messages. (only applicable to SMS)
		4	All messages (only applicable to +CMGL command).
		16	Template message.

Returns:	<index>	Integer	Integer value in the range of location numbers supported by the associated memory.
	[<alpha>]	String	Manufacturing specific. Should be left empty but not omitted.
	<length>	Integer	Value indicating in PDU mode (+CMGF=0), the length of the actual TP data unit in octets.

AT Commands Phone Terminal Terminated

	<pdu>	In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number. In the case of CBS: GSM 03.41 TPDU in hexadecimal format.
Example 1:	AT+CMGL=0	Messages received and unread.
	+CMGL: 1,0,,128<128 byte pdu>	
	OK	
Example 2:	AT+CMGL=2	
	+CMGL: 2,0,68<68 byte pdu>	
	OK	
Example 3:	AT+CMGL=1	List received messages.
	OK	None received.
Example 4:	AT+CMGL=2	List stored unsent messages. None stored.
Example 5:	AT+CMGL=3	List stored sent messages.
	+CMGL: 1,3,,32<32 byte pdu>	
	OK	Message in index 1 of SM is stored and sent.
Test command:	+CMGL=?	
Example:	AT+CMGL=?	
	+CMGL: (4)	
	OK	

AT Commands Phone Terminal Terminated

+CMGR *Read message*

Description: Returns message with location value <index> from preferred message storage <mem1> to the TE. Status of the message and entire message data unit <pdu> is returned.

Set command: **+CMGR=<index>**

Options: <index> **Integer** Value in the range of location numbers supported by the associated memory.

Returns: <stat> **0** Received unread.

1 Received read.

2 Stored unsent (only applicable to SMS).

3 Stored sent (only applicable to SMS).

16 Template message.

[<alpha>] **String** Manufacturing specific. Should be left empty but not omitted.

<length> **Integer** Value indicating in PDU mode (+CMGF=0), the length of the actual TP data unit in octets.

AT Commands Phone Terminal Terminated

<pdu>

In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number. In the case of CBS: GSM 03.41 TPDU in hexadecimal format.

Example: AT+CMGR=2

+CMGR: 0,,68 <64 byte pdu>

OK

Test command: **+CMGR=?**

Example: AT+CMGR=?

OK

AT Commands Phone Terminal Terminated

+CMGS *Send SMS messages*

Description: Sends a message to the phone network. On successful delivery a message reference number is returned. Sending can be cancelled by sending the **ESC** character.

Set command: **+CMGS=<length><CR><pdu is given><CTRL-Z/ESC>**

Options: <length> **Integer** Value indicating in PDU mode (+CMGF=0), the length of the actual TP data unit in octets.

Returns: <mr> **Integer** GSM 03.40 TP-Message-Reference in integer format.

[,<ackpdu>
] GSM 03.40 RP-User-Data element of RP-ACK PDU; format is same as for <pdu> in case of SMS, but without GSM 04.11 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.

Example: AT+CMGS=35<CR><35 byte pdu><CTRL-Z>
 +CMGS: 13
 OK

Test command: **+CMGS=?**

Example: AT+CMGS=?
 OK

AT Commands Phone Terminal Terminated

+CMSS *Send from storage*

Description: Sends message with location value <index> from message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND). Reference value <mr> is returned to the TE on successful message delivery.

Set command: **+CMSS=<index>**

Options: <index> **Integer** Value in the range of location numbers supported by the associated memory.

Returns: <mr> **Integer** GSM 03.40 TP-Message-Reference in integer format.

Example: AT+CMSS=1

 +CMSS: 1,12

 OK

Test command: **+CMSS=?**

Example: AT+CMSS=?

 OK

+CMGD *Delete message*

Description: Deletes message from preferred message storage
 <mem1> location <index>.

Set command: **+CMGD=<index>**

Options: <index> **Integer** Value in the range of
 location numbers
 supported by the
 associated memory.

Example: AT+CMGD=2

OK Delete read message at
 index 2 in <mem1>.

Test command: **+CMGD=?**

Example: AT+CMGD=?

OK

AT Commands Phone Terminal Terminated

+CMGF *Message format*

Description: Informs the TA which input and output format of messages to use.

Set command: **+CMGF=<mode>**

Options: <mode> **0** PDU mode.

Example: AT+CMGF=0 Select PDU mode.

OK

Read command: **+CMGF?**

Example: AT+CMGF?

+CMGF: 0 PDU mode.

OK

Test command: **+CMGF=?**

Example: AT+CMGF=?

+CMGF: (0) Only PDU mode available.

OK

AT Commands Phone Terminal Terminated

+CSCA *SMS service centre address*

Description: Updates the SMSC address which is used to originate mobile Short Message Service transmissions.

Set command: **+CSCA=<sca>[,<tosca>]**

Options: <sca> **String** GSM 04.11 RP SC address
Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set.

<tosca> **128 - 255** Other values refer GSM 04.08 section 10.5.4.7

129 ISDN / telephony numbering plan, national / international unknown.

145 ISDN / telephony numbering plan, international number.

161 ISDN / telephony numbering plan, national number.

If a '+' is included in the phone number (number) then a default of 145 is used. In all other cases a default value of 129 is applied.

Example: AT+CSCA="+358501234589"

OK Change SCA.

Read command: **+CSCA?** Returns the current setting.

AT Commands Phone Terminal Terminated

Example: AT+CSCA?
 +CSCA: "358501234567",145
 OK

Test command: **+CSCA=?**

Example: AT+CSCA=?
 +CSCA: (128-255)
 OK

AT Commands Phone Terminal Terminated

+CSCB *Select cell broadcast message type*

Description: Selects the type of cell message broadcasts to be received by the ME.

Set command: **+CSCB=[<mode>[,<mids>],[<dcss>]]**

Options:	<mode>	0	Message types in <mids> accepted.
	<mids>	string	All possible combinations of message identifiers.
	<dcss>	string	All possible combinations of coding schemes.

Example: AT+CSCB=0 Accept <mids> messages.
OK

Read command: **+CSCB?**

Example: AT+CSCB?
+CSCB: 0
OK

Test command: **+CSCB=?**

Example: AT+CSCB=?
+CSCB: (0)
OK

+CSAS *Save Settings*

Description: Saves active message service settings to a non-volatile memory. A TA can contain several profiles of settings. Settings specified in commands Service Centre Address +CSCA, Set Message Parameters +CSMP and Select Cell Broadcast Message Types +CSCB (if implemented) are saved.

Set command: **+CSAS**[=<profile>]

Options: <profile> **0..255** Manufacturer specific profile number where settings are to be stored

Example: AT+CSAS Save settings.
OK

Test command: **+CSAS=?**

Example: AT+CSAS=?
+CSAS: (0)
OK

+CRES *Restore Settings*

Description: restores message service settings from non-volatile memory to active memory. A TA can contain several profiles of settings. Settings specified in commands Service Centre Address +CSCA, Set Message Parameters +CSMP and Select Cell Broadcast Message Types +CSCB (if implemented) are restored.

Set command: **+CRES**[=<profile>]

Options: <profile> **0..255** Manufacturer specific profile number where settings are to be stored

Example: AT+CRES Restore settings.

OK

Test command: **+CRES=?**

Example: AT+CRES=?

+CRES: (0)

OK

AT Commands Phone Terminal Terminated

+CNMI *New message indication to TE*

Description: Selects the procedure that sets how new messages are indicated on the TE.

Set command: **+CNMI**=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]

Options:	<mode>	3	Forward unsolicited result codes directly to the TE. TA-TE link specific inband technique used to embed result codes and data when TA is in on-line data mode.
	<mt>	0	No SMS-DELIVER indications are routed to the TE. Default= 0 .
		1	If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI: <mem>,<index>
		3	Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes +CMT: <length><CR><LF><pdu>. Messages of other data coding schemes result in indication as defined in <mt>=1.
	<bm>	0	Store message to "BM" (or some manufacturer specific memory). No CBM indications are routed to the TE. Default= 0 .

	2	New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode enabled).
<ds>	0	No SMS-STATUS-REPORTs are forwarded to the TE.
<bfr>	1	TA buffer of unsolicited result codes defined within this command are cleared when <mode> 1...2 is entered (OK response shall be given before flushing the codes).
Example:	AT+CNMI=3,1,2,0	Send SM indications to TE.
	OK	

Read command: **+CNMI?**

Example 1: AT+CNMI?

+CNMI: 3,1,2,0

OK

Test command: **+CNMI=?**

Example: AT+CNMI=?

+CNMI: (3),(0-3),(0,2),(0)

OK

Unsolicited Result
codes: **+CBM: <length><CR><LF><pdu>**

Unsolicited Result Codes

+CBM *New Message Indication*

Description: Cell broadcast message.

Unsolicited Result
code: **+CBM: <length> <CR><LF><pdu>**

Received when CBMs are
routed directly to the TE.

Defined values: <length> **integer** The length of the actual TP
data unit in octets.

<pdu> For SMS: GSM 04.11 SC
address followed by GSM
03.40 TPDU in hex format.

For CBS: GSM 03.41
TPDU in hex format.

+CMTI *New Message Indication*

Description: Indicates the memory location where the message routed to the TE is located.

Unsolicited Result

code: **+CMTI:**<mem>, <index>

When a message has been received and SMS-DELIVER is stored into ME/TA.

Defined values:	<mem>	ME	ME message storage.
		SM	SIM message storage.
	<index>	integer	Value in the range of location numbers supported by the associated memory.

AT Commands Phone Terminal Terminated

+CMT *Received Message*

Description: The command AT+CNMI selects the procedure of how the receiving of new messages from the network is indicated to the TE when the TE is active. Received SMS are routed directly to the TE using unsolicited result code.

Unsolicited Result

code: **+CMT:**<length>, <pdu>

When a message has been received and SMS-DELIVER is stored into ME/TA.

Defined values: <length> **Integer**

Value indicating in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)

<pdu>

In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))In the case of CBS: GSM 03.41 TPDU in hexadecimal format

AT Commands Phone Terminal Terminated

+CMS *Report operational/access failure (+CMS)*

The +CMS ERROR result codes indicate an error relating to the Infrared Modem, Mobile Phone or Network relating to the Short Message Service (SMS) and replaces the final result code ERROR.

+CMS ERROR: 0	GSM 04.11 Annex E-2 values.
to	
+CMS ERROR: 127	
+CMS ERROR: 128	GSM 03.40 Section 9.2.3.22 values.
to	
+CMS ERROR: 255	
+CMS ERROR: 300	Mobile phone failure.
+CMS ERROR: 301	Short message service of mobile phone reserved.
+CMS ERROR: 302	Operation not allowed.
+CMS ERROR: 303	Operation not supported.
+CMS ERROR: 304	Invalid PDU mode parameter.
+CMS ERROR: 305	Invalid text mode parameter.
+CMS ERROR: 310	SIM card not inserted.
+CMS ERROR: 311	SIM card PIN necessary.
+CMS ERROR: 312	SIM card PIN necessary for PH-SIM.
+CMS ERROR: 313	SIM card failure.
+CMS ERROR: 314	SIM card busy.
+CMS ERROR: 315	SIM card wrong.

AT Commands Phone Terminal Terminated

+CMS ERROR: 316	SIM PUK required
+CMS ERROR: 317	SIM PIN2 required
+CMS ERROR: 318	SIM PUK2 required
+CMS ERROR: 320	Memory failure.
+CMS ERROR: 321	Invalid memory index.
+CMS ERROR: 322	Memory full.
+CMS ERROR: 330	SMSC address unknown.
+CMS ERROR: 331	No network service.
+CMS ERROR: 332	Network timeout.
+CMS ERROR: 340	no +CNMA acknowledgement expected
+CMS ERROR: 500	Unknown error.
+CMS ERROR: ...511	range 256...511 reserved
+CMS ERROR: 512...	manufacturer specific

4.11 Ensemble S14/E : GSM Digital Binary Ping Pong Mode

***BINARY** *Start binary mode*

Description: Sets the AT phone in digital binary mode.

Set command: ***BINARY**

Example: AT*BINARY

CONNECT

Set phone in digital binary mode.

4.12 Ensemble S16/C/E : GSM Phonebook Commands

+CPBS *Select mobile phone phonebook memory storage*

Description: Selects phonebook memory storage <storage>, which is used by other phonebook commands.

Set command: **+CPBS=<storage>**

Options:	<storage> "FD"	SIM fix-dialing-phonebook. Only in reference point E.
	"LD"	SIM last-dialing-phonebook.
	"ME"	ME phonebook.
	"SM"	SIM phonebook.
	"DC"	ME dialed calls list.
	"RC"	ME received calls list.
	"MC"	ME missed calls list.
	"MV"	ME Voice Activated Dialing list.

Example: AT+CPBS="SM"

OK

Read command: **+CPBS?** Returns the current setting.

Example: AT+CPBS?

+CPBS: "SM"

OK

Test command: **+CPBS=?**

Example: AT+CPBS=?

+CPBS: ("LD" , "ME" , "SM" ,
"DC" , "RC" , "MC" , "MV")

OK

AT Commands Phone Terminal Terminated

+CPBR *Read mobile phone phonebook entries*

Description: Returns the phonebook entries from index1 to index2 as stored on the SIM card or in the Mobile Phone memory. Use the AT+CPBS command (see previous page) to select one of these memories. The default is the SIM memory.

Set command: **+CPBR=<index1>,[<index2>]**

Options:	<index1>	Number location, start.
	<index2>	Number location, end.
Returns:	<indexn>	Integer entry to be read.
	<number>	String number of <type> format.
	<type>	Integer format type of address.
	<text>	Field of <length> maximum length.

Example: AT+CPBR=1,4

+CPBR: 1,"931123456",129,"FREDRIK"

+CPBR: 2,"9501234567",129,"MAGNUS"

+CPBR: 2,"901234567",129,"LARS"

OK

AT Commands Phone Terminal Terminated

Test command:	+CPBR=?	Returns (1-100),20,18. The returned values are the number of entries available in the current phone book memory, the maximum length of the phone number and the maximum length of the text. These values can vary between different SIM cards and mobile phones. The result from this test command depends on the phonebook storage chosen with AT+CPBS
Returns:	<nlength>	Integer value of maximum length of field <number>.
	<tlength>	Integer value of maximum length of field <text>.
Example:	AT+CPBR=? +CPBR: (1-100),20,18 OK	

AT Commands Phone Terminal Terminated

+CPBF *Phonebook Find*

Description: Returns phonebook entries (from the current phonebook memory storage selected with +CPBS) which alphanumeric field start with string <findtext>.

Set command: **+CPBF=<findtext>**

Options: <findtext> **String** Field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS.

Returns: <indexn> Integer entry to be read.
 <number> String number of <type> format.
 <type> Integer format type of address.
 <text> Field of <tlength> maximum length.

Example: AT+CPBF="MAGNUS"
 +CPBF: 2,"9501234567",129,"MAGNUS"
 OK

Test command:	+CPBF=?	Returns (1-100),20,18. The returned values are the number of entries available in the current phone book memory, the maximum length of the phone number and the maximum length of the text. These values can vary between different SIM cards and mobile phones.
Returns:	<nlength> <tlength>	Integer value of maximum length of field <number>. Integer value of maximum length of field <text>.
Example:	AT+CPBF=? +CPBF: 80,20 OK	

AT Commands Phone Terminal Terminated

+CPBW *Write mobile phone phonebook entries*

Description: Store entries in the phonebook.

Set command: **+CPBW**=[<index>],[<number>],[<type>],[<text>]]

Options: <index> Location number for the storage of the phone details. If omitted then the first free location is assigned.

 <number> **String** Phone number.

 <type> **128-255** Type of ISDN/Phone numbering plan.

129 Nationality unknown.

145 International.

161 National.

If a '+' is included in the phone number <number> then a default of 145 is used, in all other cases a default value of 129 is applied.

 <text> **String** Name or description of the phone number.

AT Commands Phone Terminal Terminated

Example 1: `AT+CPBW=3,"921123456",,"Mikael"`
 OK

The new entry overwrites position 3 in the phonebook.

Example 2: `AT+CPBW=4`
 OK

Clear entry 4 in the phonebook.

Test command: **`+CPBW=?`**

Returns (1-100),20,(128-255),20.

The returned values are the number of entries available in the current phone book memory, the maximum length of the phone number and the maximum length of the text. These values can vary between different SIM cards and mobile phones. The result from this test command depends on the phonebook storage chosen with `AT+CPBS`.

Example: `AT+CPBW=?`
 `+CPBW: (1-100),20,(128-255),20`
 OK

AT Commands Phone Terminal Terminated

***ECAR** *Ericsson Callers Allowed Read*

Description: Execution command returns calls allowed index, groupname if applicable, storage and phonebook index.

Set command: ***ECAR**=<CAindex1>[, <CAindex2>]

Defined values **Integer** Start value of location number.
<CAindexn>:

Response: <CAindex>,[<groupname>][,<storage>,<PIndex>]

<groupname>: **String** Name of callers allowed group.

<storage>: **String** "SM" SIM phonebook
 "ME" Mobile phonebook

<PIndex>: **Integer** Values in the range of location numbers of phonebook memory

Example: AT*ECAR=1,5 List callers allowed between index 1 and 5 in the "callers allowed"-list

*ECAR: 1,, "ME",15

*ECAR: 4,, "SM",34

*ECAR: 5,"Work"

OK

Test command: ***ECAR=?**

Returns: (list of supported <CAindex>s),<gn_length>,(list of supported <storage>s)

Example: AT*ECAR=?

*ECAR: (1-10),18, ("SM","ME")

OK

***ECAW** *Ericsson Callers Allowed Write*

AT Commands Phone Terminal Terminated

***EPRR** *Ericsson Personal Ringtype Read*

Description: Returns phone number, phone number type and sound type in location number <indexr>.

Set command: ***EPRR=** <indexr>

Options: <indexr> **1..10** Value of location number

Returns: <indexr>

 <number> **String** Phone number of format <type>.

 <type> **Integer** Type of address octet (refer GSM 04.08 [4] section 10.5.4.7)

128-255 Other values refer GSM 04.08 [4] section 10.5.4.7.

129 ISDN / telephony numbering plan, national / international unknown.

145 ISDN / telephony numbering plan, international number.

161 ISDN / telephony numbering plan, national number.

If a '+' is included in the phone number <number> then a default of 145 is used, in all other cases a default value of 129 is applied.

 <sound type> **1** Low ring signal.

2 Medium ring signal.

AT Commands Phone Terminal Terminated

3	High ring signal.
4	Mixed ring signal.
11-20	Melody 1-10 - preset.
31-34	Own melodies 1-4.

Example: AT*EPRR=4

EPRR :
4,046194533,2

Phone number 046194533
and ringtype 2 for index 4
in personal ringtype list.

OK

Test command: ***EPRR=?**

Returns: (list of supported
<index>s)

Example: AT*EPRR=?

EPRR: (1-10)

OK

AT Commands Phone Terminal Terminated

***EPRW** *Ericsson Personal Ringtype Write*

Description: Writes phone number, phone number type and sound type in location number <indexr>. It is possible to use wild cards for phone number.

Set command: ***EPRW=** <indexr>,<number>,<type>,<ringtype>

Options: <indexr> **1..10** Value of location number

 <number> **String** Phone number of format <type>.

 <type> **Integer** Type of address octet (refer GSM 04.08 [4] section 10.5.4.7)

128-255 Other values refer GSM 04.08 [4] section 10.5.4.7.

129 ISDN / telephony numbering plan, national / international unknown.

145 ISDN / telephony numbering plan, international number.

161 ISDN / telephony numbering plan, national number.

If a '+' is included in the phone number <number> then a default of 145 is used, in all other cases a default value of 129 is applied.

Example: AT*EPRW=4,046194533,2

AT Commands Phone Terminal Terminated

	OK	Set phone number 046194533 and ringtype 2 for index 4 in the personal ringtype list.
Test command:	*EPRW=?	
Returns:	(list of supported <index>s)	
	<nlength>	Integer value of maximum length of field <number>.
	(list of supported <type>s)	
	(list of supported <sound type>s)	
	1	Low ring signal.
	2	Medium ring signal.
	3	High ring signal.
	4	Mixed ring signal.
	11-20	Melody 1-10 - preset.
	31-34	Own melodies 1-4.
Example:	AT*EPRW=?	
	*EPRW: (1-10), 10, (128-255), (1-4, 11-20, 31-34)	
	OK	List of index and maximum length of number and list of possible ring types.

AT Commands Phone Terminal Terminated

***ECAS** *Ericsson Callers Allowed Set*

Description: The command is used to set alternatives for call screening.

Set command: ***ECAS=** <callscreen>

Options:	<callscree 0 n>	No callers allowed.
	1	All callers allowed, normal actions shall be taken on incoming calls. Default=1
	2	Some callers allowed.

Example: AT*ECAS=2
OK

Read command: ***ECAS?**

Example: AT*ECAS?
*ECAS: 2
OK

Test command: ***ECAS=?**

Returns: (list of supported
<callscreen>s)

Example: AT*ECAS=?
*ECAS: (0-2)
OK

4.13 Ensemble S18/E : GSM Clock, Date and Alarm Handling

+CCLK *Clock*

Description: Sets the real time clock of the ME.

Set command: **+CCLK=<time>**

Options: <time> **String** Format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range - 47...+48).

Example: AT+CCLK= "97/09/29,14:25:00+00"

OK

Set correct time to 29th of September 1997, 14:25:00 and no time difference between local time and GMT.

Read command: **+CCLK?**

Example: AT+CCLK?

+CCLK: "97/09/27,22:10:00+00"

OK

Test command: **+CCLK=?**

Example: AT+CCLK=?

OK

AT Commands Phone Terminal Terminated

+CALA *Alarm*

Description: Sets an alarm time in the ME. The alarm time is set in minutes and hours. Date, seconds and time zone are not possible to use.

Set command: **+CALA=<time>**

Options: <time> **String** Format is "hh:mm", where characters indicate hour, minutes.

Example: AT+CALA= "14:25"

OK

Read command: **+CALA?**

Example: AT+CALA?

+CALA: "22:10"

OK

Test command: **+CALA=?**

Example: AT+CALA=?

OK

4.14 Ensemble S19/E : GSM Subscriber Identification

+CIMI *Read International Mobile Subscriber Identity (IMSI)*

Description: Execution command which causes the TA to return <imsi>. This identifies the individual SIM which is attached to the ME.

Execute command: **+CIMI**

Returns: <imsi>

The IMSI, an integer string without double quotes.

Example: AT+CIMI
931123456
OK

Test command: **+CIMI=?**

Example: AT+CIMI=?
OK

4.15 Ensemble C20/C/E : Audio Control

***EALR** *Audio Line Request*

Description: The AT*EALR command is used by accessories to request the ATMS and AFMS.

Set command: ***EALR=<mode>[,<activation>[,<aud_status>]]**

Options **0** No request of ATMS nor AFMS
<mode>:

1 Request of ATMS and not AFMS

2 Request of AFMS and not ATMS

3 Request of ATMS and AFMS.
Default=**3**

<activation>: **0** Not direct activated audio accessory
(e.g. Cordless Portable Hands Free).
Default=**0**

1 Direct activated audio accessory (e.g.
Vehicle Hands Free)

<aud_status>: **0** No change of the audio status.
Default=**0**

1 Audio Handover. (Accessory hands
over control of both the audio lines and
the call to the phone)

2 Audio Demand. (Accessory demands
control of both the audio lines and the
call)

Example: AT*EALR=0,1

 *EALR: 0,1

 OK

Read command ***EALR?**

Example: AT*EALR?

*EALR: 3,0,0

OK

Test command: ***EALR=?**

Example: AT*EALR=?

*EALR: (0-3), (0-1), (0-2)

OK

***EARS** *Analog Ring Signal Request*

Description: This command is used to enable an analog ring signal as indication of an incoming call in an external loudspeaker (AFMS).

Set command: ***EARS=<mode>**

<mode>:: **0** Disable analog ring signal
 1 Enable analog ring signal.
 Default=1

Example: AT*EARS=0

OK

Read command ***EARS?**

Example: AT*EARS?

*EARS: 1

OK

Test command: ***EARS=?**

Example: AT*EARS=?

*EARS: (0,1)

OK

***EMIR** *Mute Indication Request*

Description: This command is used to request music mute indications. A music mute indication shall be sent to all accessories that have requested the indication when a call is set up.

Set command: ***EMIR=<mode>**

 <mode>:: **0** Off, Music Mute Indication result codes will **not** be sent to the accessory.

1 On, Music Mute Indication result codes will be sent to the accessory
Default=1

Example: AT*EMIR=0

OK

Read command ***EMIR?**

Example: AT*EMIR?

*EMIR: 1

OK

Test command: ***EMIR=?**

Example: AT*EMIR=?

*EMIR: (0,1)

OK

AT Commands Phone Terminal Terminated

***EAMS Audio Mode Selection**

Description: Used for setting the Audio mode selection. The command has to be sent to the MS at the initialization of an audio accessory, but can also be send later to change the audio mode selection..

Set command: ***EAMS=<internal_voice_alg>**
 [,<noise_reduction>
 [,<side_tone>
 [,<short_echo_canceling>
 [,<ATMS_gain>
 [,<class>
 [,<ATMS_sensitivity_deviation_from_class>
 [,<AFMS_sensitivity_deviation_from_class>]]]]]]]

Options Sets the voice-processing mode in the phone.
<internal_voice_alg>:

- 0** None
- 1** Semi-duplex
- 2** Full duplex

<noise_reduction>: Sets the noise reduction functionality in the phone.

- 0** Off. Default=**0**
- 1** On

<side_tone>: Activates the side tone functionality in the phone.

- 0** Off. Default=**0**
- 1** On

<short_echo_canceling>: Activates the short echo canceling functionality in the phone.

- 0** Off. Default=**0**
- 1** On

<ATMS_gain>: Indicates the gain of the signal that is sent to the phone.

0	Normal (0 dB) (Internal voice processing). Default= 0
1	12 dB from accessory (External voice processing)

<class>: Indicates the Hands Free class. The class parameter is used to fine adjust some parameters in the internal voice algorithm.

0	None. Default= 0
1	Low end , class reference Vehicle HF
2	Mid End, class reference Vehicle HF
3	High End, class reference Vehicle HF
4	Large room, class reference Office Hands free

<ATMS_sensitivity_deviation_from_class>: Indicates the ATMS sensitivity deviation from a given class, for example if a HF product has a new microphone that is more sensitive.

0	0 dB. Default= 0
1	2,5 dB.
2	-2,5 dB.
3	5,0 dB.
4	-5,0 dB.

Example: AT*EAMS=0,0,0,1,0,0,0,1
OK

Read command ***EAMS?**

Example: AT*EAMS?
*EAMS: 0,0,0,1,0,0,0,1
OK

AT Commands Phone Terminal Terminated

Test command: ***EAMS=?**

Example: AT*EAMS=?

*EAMS: (0-2), (0-1), (0-1), (0-1),
(0-1), (0-4), (0-4), (0-4)

OK

***EPHD** *Portable Hands Free Detection*

Description: Used by Cascade Accessories to indicate to the MS that the voltage level of CFMS on the downstream side is constantly low (i.e. a Portable Hands Free is connected).

Set command: ***EPHD=<mode>[,<phf_level>[,<button>]]**

Options **0** No Portable Hands Free attached.
<mode>:

1 Portable Hands Free attached.
 Default=1

<phf_level>: **0** Internal Mic gain. Default=0
 1 External Mic gain.

<button>: **0** No Button pushed.
 1 Button pushed on Portable Hands
 Free. Default=1

Example: AT*EPHD=0 , 0 , 0
 OK

Read command ***EPHD?**

Example: AT*EPHD?
 *EPHD: 0 , 0 , 0
 OK

Test command: ***EPHD=?**

Example: AT*EPHD=?
 *EPHD: (0-1) , (0-1) , (0-1)
 OK

AT Commands Phone Terminal Terminated

***ECBP** *CHF Button Pushed*

Description: This command is used by the Cordless Hands Free (CHF) to indicate the MS that the button of the CHF has been pushed.

Execute command: ***ECBP**

Example: AT*ECBP

OK

Test command: ***ECBP=?**

Example: AT*ECBP=?

OK

Unsolicited Result Codes

***EALV** *Audio Line Response*

Description: This unsolicited result code is sent to the accessory when the phone wants that accessory to change audio state. Use the AT*EALR command to enable the response.

Unsolicited Result ***EALV:**<mode>,<activation>,<resp>
code:

Defined values:	<mode>	See AT*EALR command
	<activation>	See AT*EALR command
	<resp>	0 Disable ATMS and AFMS
		1 Enable ATMS and Disable AFMS
		2 Disable ATMS and Enable AFMS
		3 Enable ATMS and AFMS

***EMIV** *Music Mute Indication Response*

Description: This Music Mute indication shall be sent out from the phone every time a parameter change occurs. Use the AT*EMIR command to enable the response.

Unsolicited Result ***EMIV:**<resp>
code:

Defined values:	<resp>	0 Music Mute inactive
		1 Music Mute active

4.16 Ensemble S20/C/E : Ericsson Specific AT Commands for GSM

***ECUR** *Ericsson current report*

Description: Reports the current consumption of the connected device.

Set command: ***ECUR=<mamp>**

Options: <mamp> **Integer** Number of milliamps divided by 10.

Example: AT*ECUR=12 120 milliamps.

OK

Test command: ***ECUR=?**

Example: AT*ECUR=?

OK

***EENL** *Ericsson Environment List*

Execute command: ***EENL**

1 Portable hands free.

3 RS232-cord.

5 Reserved.

6 Charger – intelligent.

7 Charger – simple.

8 Reserved.

9 Reserved.

10 Reserved.

11 Reserved.

12 External Handset.

13..255 Reserved.

<unique_id>: 0	Request a new unique identifier from the phone.
----------------	---

1-65534 Unique identifier for a unique accessory.

65535 Default value used by non-unique accessories.

<envname>: **String** Name of the environment.

Example: AT*EENL

```
*EENL: 1,65535,Portable HF
```

*EENL: 2,65535,Vehicle HF

*EENL: 6,5519,Desktop Charger

AT Commands Phone Terminal Terminated

OK

Test command: ***EENL=?**

Returns **Integer** Maximum number of environments
<nenvname>: known to the TE.

Example: AT*EENL=? 14

OK

***EKSP** *Ericsson Key Sound Playback*

Description: This command generates a Key Playback from the MS. The sound is set up by the Key Sound Setting in the phone. The sound properties (tone, quality and duration) should be exactly the same as if a key is pressed on the MS keypad.

Execute command: ***EKSP**

Example: AT*EKSP

OK

Test command: ***EKSP=?**

Example: AT*EKSP=?

OK

***EKSR** *Ericsson Key Sound Change Report*

AT Commands Phone Terminal Terminated

Returns: List of supported <mode>s
List of supported <report>s

Example: AT*EKSR=?
*EKSR: (0-3), (0-1)
OK

***EMIC** *Ericsson microphone mode*

Description: Enables or disables the phone microphone. The microphone should be enabled for each new call even if it was disabled for the previous call.

Set command: ***EMIC=<mode>**

Options: <mode> **0** Disable microphone.
 1 Enable microphone.

Example: AT*EMIC=0
 OK

Read command: ***EMIC?**

Example: AT*EMIC?
 *EMIC: 0
 OK

Test command: ***EMIC=?**

Example: AT*EMIC=?
 *EMIC: (0-1)
 OK

AT Commands Phone Terminal Terminated

***EPEC** *Ericsson Profile Environment Change*

Description: Used to enable and disable automatic change of profile when the phone environment is changed..

Set command: ***EPEC=<setting>**

Options: <setting> **0** Disabled - The phone does not change profile automatically when the phone environment is changed.
Default=**0**

1 Enabled - When the environment changes, the phone automatically changes current profile to the profile associated with the new environment.

Example: AT*EPEC=1
OK

Read command: ***EPEC?**

Example: AT*EPEC?
*EPEC: 0
OK

Test command: ***EPEC=?**

Returns: List of supported <setting>s

Example: AT*EPEC=?
*EPEC: (0-1)
OK

AT Commands Phone Terminal Terminated

***EPEE** *Ericsson pin event*

Description: Requests the MS to report when the pin code has been inserted and accepted.

Set command: ***EPEE=<onoff>**

Options: <onoff> **0** Request not activated.

1 Request activated.

Example: AT*EPEE=1

 OK

Read command: ***EPEE?**

Example: AT*EPEE?

 *EPEE: 1

 OK

Test command: ***EPEE=?**

Example: AT*EPEE

 *EPEE: (0-1)

 OK

Unsolicited Result
code: ***EPEV:**

AT Commands Phone Terminal Terminated

***EPED** *Ericsson Profile's List Of Environments Delete*

Description: Used to remove an environment from the list of environments associated to the current profile.

Set command: ***EPED=<accessory id>[,<unique_id>]**

Options	1	Portable hands free.
<accessory_id>:	2	Vehicle hands free.
	3	RS232-cord.
	4	IR-device.
	5	Reserved.
	6	Charger – intelligent.
	7	Charger – simple.
	8	Reserved.
	9	Reserved.d
	10	Reserved.
	11	Reserved.
	12	External Handset.
	13..255	Reserved.
<unique_id>:	0	Request a new unique identifier from the phone.
	1-65534	Unique identifier for a unique accessory.
	65535	Default value used by non-unique accessories.

Example: **AT*EPED=1 , 65535**

OK

Test command: ***EPED=?**

AT Commands Phone Terminal Terminated

Example: AT*EPED=? (1-14), (1-65535)
 OK

AT Commands Phone Terminal Terminated

***EPEW** *Ericsson Profile's List Of Environments Write*

Description: The command is used to add an environment to the list of environments associated to the active profile. The command may also be used for listing all environments associated to the active profile. Only one profile may be associated with an environment. However, several environments may be associated with a profile. If trying to associate an environment already associated with another profile, this command should produce an error..

Set command: ***EPEW**=<accessory id>[,<unique_id>]

Options **1** Portable hands free.
<accessory_id>:

2 Vehicle hands free.

3 RS232-cord.

4 IR-device.

5 Reserved.

6 Charger – intelligent.

7 Charger – simple.

8 Reserved.

9 Reserved.

10 Reserved.

11 Reserved.

12 External Handset.

13..255 Reserved.

<unique_id>: **0** Request a new unique identifier from the phone.

1-65534 Unique identifier for a unique accessory.

AT Commands Phone Terminal Terminated

65535 Default value used by non-unique accessories.

Example: AT*EPEW=1,65535

OK

Read command: ***EPEW?**

Returns
<accessory_id>

<unique_id>

<envname>: **String** Name of the environment.

Example: AT*EPEW?

*EPEW: 1,65535,Vehicle HF

OK

Test command: ***EPEW=?**

Returns **Integer** Maximum number of environments
<nenvname>: known to the TE.

Example: AT*EPEW=? 14

OK

AT Commands Phone Terminal Terminated

***EAPS** *Ericsson Active Profile Set*

Description: There are six (6) profiles predefined in the MS. There is always one profile active. The profiles are identified by an index from 1 to 6 and by a profile name. The name may be changed by using the AT*EAPN-command. This command is used to select the active profile.

The profile consists of the parameters and settings corresponding to the following commands:

Command	Name
AT+CCFC	Call Forwarding Number and Conditions
AT*EDIF	Divert function and reporting
AT*EDIS	Divert set
AT*ELIN	Set Line
AT*ERIL	Ring Level Set
AT*ECAS	Set Callers Allowed
AT*ESBL	Setting Back Light Mode
AT*ESCN	Set Credit Card Number
AT*ESIL	Silence Command
AT+CVIB	Vibrator Mode
AT*EPEC	Automatic activation
AT*EPEW AT*EPED	List of environments

Set command: ***EAPS=<index>**

Options: <index> **1..6** Number of profile.

Example: AT*EAPS=1

OK

AT Commands Phone Terminal Terminated

Read command: ***EAPS?**

Returns <index>

<tagx> **String** Name tag for the profile x
(e.g. Home, Office,
Meeting, ...)

Example: AT*EAPS?

*EAPS: 1,"Office"

OK

Test command: ***EAPS=?**

Returns (list of supported
<index>s) **1..6**

<nlength> **Integer** Integer value of maximum
length of field <name
tagx>.

Example: AT*EAPS=? (1,6), 12

OK

AT Commands Phone Terminal Terminated

***EAPN** *Ericsson Active Profile Rename*

Description: This command sets a new name for the active profile.

Set command: ***EAPN=<name tag>**

Options: <name **String** Name tag for the active profile (e.g. Home, Office, Meeting, ...)

Example: AT*EAPN="Vacation"

OK

Read command: ***EAPN?**

Returns <index> **1..6** Number of profile.
 <name **String** Name tag for the profile x (e.g. Home, Office, Meeting, ...)

Example: AT*EAPN?

*EAPS: 1, "Office"
*EAPS: 2, "Home"
*EAPS: 3, "Meeting"
*EAPS: 4, "Vacation"

OK

Test command: ***EAPN=?**

Returns <nlength> **Integer** Integer value of maximum length of field <name tag>.

Example: AT*EAPN=? 12

OK

AT Commands Phone Terminal Terminated

***ESNU** *Ericsson settings number*

Description: Sets a number in the MS according to <type>.

Set command: ***ESNU=<type>,<number>[,<number type>]**

Options:	<type>	0	Voice L1.
		1	Voice L2.
		2	Fax.
		3	Data.
	<number>	0-9,+	Number.
	<number type>	145	International Dialling including "+".
		129	All other numbers.

Example: AT*ESNU=0,"90920465",129

OK

Read command: ***ESNU?**

Example: AT*ESNU? : 0,0,129

*ESNU: 0,"90920465",129

OK

Test command: ***ESNU=?**

Example: AT*ESNU=?

*ESNU: (0-3)

OK

AT Commands Phone Terminal Terminated

***EBCA** *Ericsson Battery And Charging Algorithm*

Description: Used to test charging algorithm in the phone and to turn on/off unsolicited signal result codes.

Set command: ***EBCA=<onoff>**

Options **0** Disable.
<onoff>: Default=**0**

1 Enable.

Returns **Integer** Battery voltage. Number of mV,
<vbatx>: multiplied by 10. I.e. a value of 300 is
reported as " 3 V". Range 0 .. 65500

<vbat1>:TXON high and CHARGING on.

<vbat2>:TXON high and CHARGING off.

<vbat3>:TXON low and CHARGING on.

<vbat4>:TXON low and CHARGING off.

<btype>: **0** NiMH

1 Li

2 Unknown battery

<dcio>: **Integer** DCIO voltage measurement. Battery
voltage. Number of mV, multiplied by
10. I.e. a value of 300 is reported as "
3 V". Range 0 .. 65500.

<icharge>: **Integer** Charge current measurement. Current
charge, Number of ma. I.e. a value of
1000 is reported as "1A". Range 0 ..
65500.

<iphone>: **Integer** Phone current consumption, Number
of mA, I.e. a value of 1000 is reported
as "1 A". Range 0 .. 65500.

AT Commands Phone Terminal Terminated

<acapacity>:	Integer	Added capacity during charge, Number of mAh, multiplied by 20 I.e. a value of 100 is reported as "2 Ah". Range 0 .. 65500.
<ccapacity>:	Integer	Consumed capacity during charge, Number of mAh, multiplied by 20 I.e. a value of 100 is reported as "2 Ah". Range 0 .. 65500.
<capacity>:	Integer	Actual capacity, mAh, Number of mAh, multiplied by 20 I.e. a value of 100 is reported as "2 Ah". Range 0 .. 65500.
<ncapacity>:	Integer	Nominal capacity, mAh, Number of mAh, multiplied by 20 I.e. a value of 100 is reported as "2 Ah". Range 0 .. 65500.
<tempbattery>:	Integer	Temperature battery in deg C, -20 deg C .. +70 deg C.
<tempphone>:	Integer	Temperature phone in deg C, -20 deg C .. +70 deg C.
<bcapacity>:	0	slim.
	1	standard.
	2	high capacity.
<chargestate>:	0	Start.
	1	Safe Charge. If NiMH: Charge
	2	Await
	3	Handheld
	4	Charge completed Safety timer.
	5	Charge completed Low Current. If NiMH: Charge completed dT/dt.
	6	Charge Completed. If NiMH: Charge Completed d2v/dt2.

7 Constant Current.
If NiMH: Charge completed: flat V.

8 Constant Voltage.
If NiMH: Value not applicable.

Example: AT*EBCA=1

*EBCA: 300,300,300,300,0,300,1000,100
0,100,100,100,100,22,21,0,1

OK

Read command: ***EBCA?**

Example: AT*EBCA?

*EBCA: 1

OK

Test command: ***EBCA=?**

Response: List of supported parameters

Example: AT*EBCA=?

*EBCA: <vbat1>, <vbat2>,<vbat3>,
<vbat4>, <btype>, <dcio>, <icharge>,
<iphone> <acapacity>, <ccapacity>,
<pacapacity>, <ncapacity>, <tempbat-
tery>, <tempphone>, <bcapacity>,
<chargestate>

OK

AT Commands Phone Terminal Terminated

***EQVL** *Ericsson External Volume Status*

Description: Used to turn on/off unsolicited volume level change result codes (*EVOLC) via the <report> parameter. The command also queries the status of the volume level of the phone.

Set command: ***EQVL=<report>**

Options **0** Report disabled.
<report>: Default=**0**

 1 Report enabled.

Example: AT*EQVL=1

 OK

Read command: ***EQVL?**

Returns
<report>:

<current volume>: **0** Low volume

 1 .. n-1 Steps in volume

 n High volume

Example: AT*EQVL?

 *EQVL: 1,4

 OK

Test command: ***EQVL=?**

Response: List of supported <report>s

Example: AT*EQVL=?

 *EQVL: (0-1)

 OK

AT Commands Phone Terminal Terminated

***EXVC** *Ericsson Set External Volume Control*

Description: Used to set or query whether an external accessory such as the vehicle handsfree controls the audio volume.

Set command: ***EXVC=<external volume>**

Options	0	The phone MMI controls audio volume over AFMS. Default= 0
<external volume>:	1	Audio volume over AFMS is output at maximum level that is no clipping occurs. An external accessory such as a vehicle kit controls the actual volume level heard by the user.

Example: AT*EXVC=0
OK

Read command: ***EXVC?**

Example: AT*EXVC?
*EXVC: 1
OK

Test command: ***EXVC=?**

Response: List of supported <external volume>s

Example: AT*EXVC=?
*EXVC: (0-1)
OK

Unsolicited Result Codes

EBCA** ***Ericsson Indication Algorithm Status

Description:	This unsolicited result code indicates the changes in status of parameters of charging algorithm. This unsolicited status is enabled with the AT*EBCA command.
--------------	--

Unsolicited Result
code: *EBCA:

***EPEV** *Ericsson Pin Code event*

Description: Reports that the user has entered the PIN Code and it has been accepted. ME is not pending for any password

Unsolicited Result code:	*EPEV:	Unsolicited status is enabled with AT*EPEE command.
-----------------------------	---------------	---

***EVOLC** *Ericsson Volume Change Report*

Description:	This unsolicited result code is enabled by AT*EQVL to indicate changes in the volume control made by the user.
--------------	--

Unsolicited Result code:	*EVOLC: <current volume>		
Defined values:	<current volume>	0	Low Volume
		1.. n-1	Steps in volume
		7	High volume

AT Commands Phone Terminal Terminated

***EKSC** *Ericsson Key Sound Change Report*

Description: Indicates changes in the key sound setting made by the user. This result code is also sent by the phone upon successful execution of AT*EKSR=1.

Unsolicited Result

code: ***EKSC:** <mode>

Defined values:	<mode>	0	SILENT, no sound when a key is pressed
		1	CONTINUOUS TONE, a continuous tone while a key is pressed
		2	CLICK, a click when a key is pressed
		3	QUICK TONE BURST, a quick tone burst while a key is pressed

4.17 Ensemble C21/C/E : Accessory Menus

***EAM** *Ericsson Add Accessory Menu Item*

Description: Used to add the persistent menu item to the phone menu structure. A new menu item overwrites any existing menu item for the accessory. If the accessory disconnects, the menu item is deleted.

Set command: ***EAM=<persistent menu item text>**

This creates the additional menu if it is not already present, and then adds an item with the text specified in <persistent menu item text>.

Example: **AT*EAM=<start>**

OK

Test command: ***EAM=?**

Example: **AT*EAM=?**

OK

***EAST** *Ericsson Accessory Status Text*

Description: An accessory can request that the phone display a text string on the standby screen. This text may for example be shown beside the operator name or it may replace the time. The request may be denied, for example if the phone is not capable of displaying the text. Another request will overwrite the previous text.

Set command: ***EAST=<area>,<status text>**

Options:	<area>	0	Very important status text.
		1	More important than time information.
		2	Display if you can.
	<status text>		String of text.

Example: AT*EAST=0,"World"

OK

Test command: ***EAST=?**

Example: AT*EAST=?

OK

AT Commands Phone Terminal Terminated

***EASM** *Ericsson Accessory Sub Menu*

Description: Used to add a submenu to a menu item. If the accessory is disconnected all corresponding accessory submenus items are deleted.

Set command: ***EASM=<title>,<next state>,<selected item>,<number of menu items>[,<menu item>[,<menu item>,...]]**

Options **String** The menu title.
 <title>:

<next state>: Specifies what happens when the user Accepts (Yes/Send) or Rejects (No/End) the input dialog or submenu.

0 Accept: Go to persistent.

 Reject: Go to persistent.

1 Accept: Wait.

 Reject: Go to persistent.

2 Accept: Wait.

 Reject: Wait.

3 Accept: Go to persistent.

 Reject: Wait.

4 Accept: Go to standby.

 Reject: Go to persistent.

5 Accept: Go to standby.

 Reject: Wait.

6 Accept: Go to standby.

 Reject: Go to standby.

7 Accept: Go to persistent.

 Reject: Go to standby.

8 Accept: Wait.

 Reject: Go to standby.

<selected item>: **integer 1..** Index of the selected item starting at 1

<number of menu items>: **Integer 1..** Number of menu items

<menu item>: **String** Text for menu items in the accessory menu

Example: AT*EASM=size,0,1,2,big,small

OK

Test command: ***EASM=?**

Example: AT*EASM=?

*EASM: (0-8), (0-12)

OK

AT Commands Phone Terminal Terminated

***EAID** *Ericsson Accessory Input Dialog*

Description: Used to request the phone to add an input dialog. The dialog is dynamic. A request can be denied, for example if the phone is already displaying a dialog box on the standby screen.

Set command: ***EAID=<type>, <next state>, <title>, [, <para 1>[, <para 2>[, <para 3>]]]**

Options Type of input. Command syntax.
<type>:

- | | | |
|----------|---------------------|---|
| 0 | No dialog | 0 |
| 1 | Message box. | *EAID=1, <next state>, <title>, <message text>[, <timeout>] |
| 2 | Yes-No Input. | *EAID=2, <next state>, <title>, <question text>[, <timeout>] |
| 3 | On-Off Input | *EAID=3, <next state>, <title>, <default on/off> |
| 4 | Percent Input | *EAID=4, <next state>, <title>, <percent steps>, <default percent step> |
| 5 | 1-of-many selection | *EAID=5, <next state>, <title>, <default selected>, <number of list items> [, <list item> [, <list item> [, ...]]] |
| 6 | Real Input | *EAID=6, <next state>, <title>, <prompt>, <max real value> [, <default real value>] |

AT Commands Phone Terminal Terminated

7	Integer Input	*EAID=7 ,<next state>,<title>,<prompt>,<max value>,<default value>]
8	Phone number Input	*EAID=8 ,<next state>,<title>,<prompt>[,<default number>]
9	Date Input	*EAID=9 ,<next state>,<title>[,<default date>]
10	Time Input	*EAID=10 ,<next state>,<title>[,<time>]
11	String Input	*EAID=11 ,<next state>,<title>,<prompt>,<max length>[,<default text>]
12	Numeric Authentication Input	*EAID=12 ,<next state>,<title>,<prompt>,<max length>]
13	Timed Feedback	*EAID=13 ,<next state>,<title>
14	Information	*EAID=14 ,<next state>,<title>,<text>
<title>:	String	The header for the input, or the question.
<prompt>:	String	Text before the input.
<next state>:		(please refer to description under command *EASM)
<message text>:	String	Text in the message box.
<timeout>:	Integer 0-100	Timeout in tens of seconds, 0-100s, until the information dialog disappears. If no timeout is given the dialog stays up until the user interaction.

AT Commands Phone Terminal Terminated

<question text>:	String	Text for the question.
<default selected>:	Integer	Default selected, 0 if no default selected.
<number of list items>:	Integer	Number of items in the list.
	String	Item in a list.
<list item>:		
<default on/off>:	0=off, 1=on	Default selected in an on-off dialog.
<default text>:	String	Text to edit.
<max real value>:	String	Maximum real value allowed to enter.
<default real value>:	String	Default real value to be changed.
<min value>:	Integer	Minimum value accepted.
<max value>:	Integer	Maximum value accepted.
<default value>:	Integer	Integer to edit.
<default text>:	String	Text to edit.
<default number>:	String	Phone number to edit.
<percent steps>:	1..10	Number of steps in the input dialog.
<default percent steps>:	0..10	Default percent step selected, if <percent step>=5 and <default percent step>=1, then 20% is default selected.
<default date>:	String	"yy/MM/dd".
<default time>:	String	"hh:mm".
<text>:	String	Information text
Example:	AT*EAID=1,0,Info,Hello world OK	
Test command:	*EAID=?	
Example:	AT*EAID=?	

AT Commands Phone Terminal Terminated

OK

Unsolicited Result Codes

***EAAI** *Ericsson Accessory Additional Indication*

Description: The unsolicited result code is sent to the accessory when the user selects the persistent menu item from the additional menu related to the accessory. See also the AT*EAM command.

Unsolicited Result ***EAAI**
code:

***EAMI** *Ericsson Accessory Menu Indication*

Description: This unsolicited result code is sent when the user selects an alternative in the accessory menu. The index of the selected menu item is returned. The index is one based (the first item has index 1). If the user rejects the submenu *EAMI:0 is sent to the accessory. See also the AT*EASM command.

Unsolicited Result ***EAAI:<menu item index>**
code:

Defined values: <menu Index of selected menu item. First
item menu item has index 1. 0 means that
index> the user rejected the submenu.

Integer **0=rejected submenu**
 1.. index of menu item

AT Commands Phone Terminal Terminated

***EAll** *Ericsson Accessory Input Dialog Indication*

Description: This unsolicited result code is sent by the phone when the user has accepted (pressed Yes) a dynamic input dialog. It may also be sent if the user rejected the dialog (pressed No), depending on the <next state> parameter. See also the AT*EAID command.

Unsolicited Result code: ***EAll**[<type>, <input (If CLR or NO was pressed, 1>, ...)] no string is appended to this unsolicited result code)

<type> Dialog type. Unsolicited Result Code Syntax.

Aborted ***EAll**

Rejected ***EAll:0**

1 Message box ***EAll:1,1**

2 Yes-No ***EAll:2, <yes-no>**

3 On-Off ***EAll:3, <on-off>**

4 Percent ***EAll:4, <percent>**

5 1-of-many selection ***EAll:5, <selected>**

6 Real ***EAll:6, <real value>**

7 Integer ***EAll:7, <value>**

8 Phone number ***EAll:8, <phone number>**

9 Date ***EAll:9, <date>**

10 Time ***EAll:10, <time>**

11 String ***EAll:11, <text>**

12 Authentication (0..9) ***EAll:12, <text>**

AT Commands Phone Terminal Terminated

13 Timed ***EAll:13,1**
Feedback

14 Informatio ***EAll:14,1**
n

Defined values:

<yes-no> **0=no,**
 1=yes

<on-off> **0=off,**
 1=on

<percent> **0..100**

<selected> **Integer** Selected alternative in list.

<text> **String** Text entered by user.

<real
value> **String**

<value> **Integer**

<phone
number> **Phone
number**

<date> “yy/MM/
dd”

<time> “hh:mm”

AT Commands Phone Terminal Terminated

4.18 Ensemble C22/C/E : Accessory Authentication

+CSCC *Secure Control Command*

Description: Used for authentication of accessories.

Set command: **+CSCC**=<mode>,<cmd set>[,<token>]

Defined values:	1	Request challenge token to enable access to specified command set (<token> not used).
<mode>		

2 Enable access to specified command set (<token> required).

3 Disable access to specified command set (<token> not used).

<cmd set> 0..127 Reserved by ETSI

128..198 Reserved for future use.

199 Command set for Ericsson
Accessories for 3 volt platform T28.

200..255 Reserved for future use.

<token>	1 byte IRA String "0110 1100" represented by the IRA string "6C"	1 Byte token from the authentication algorithm
---------	--	--

Returns: <challenge>	1 byte IRA String "0110 1100" represented by the IRA string "6C"	1 Byte to be converted to a token by the authentication algorithm
-------------------------	---	---

Example: AT+CSCC=2,199,01101100

+CSCC:11001100

OK

Read command: **+CSCC?**

Example: AT+CSCC?

AT Commands Phone Terminal Terminated

CSCC: 2,199

OK

Test command: **+CSCC=?**

Example: AT+CSCC=?

CSCC: (1-2),(199)

OK

4.19 Ensemble C24/C/E : Voice Call Control

***EVA** *Answer Incoming Call Command*

Description: Voice call: Signals the MS to answer an incoming call.

Execute command: ***EVA**

Example: AT*EVA

OK

***EVD** *Voice Dial Command*

Description: Instructs the MS to originate (dial) a voice call. All characters are considered part of the call addressing information, up to a semicolon character or the end of the command line.

Execute command: ***EVD=[<dial_string>]**

Defined values **0 1 2 3 4 5 6 7 8 9 * #** Valid characters for
<dial_string>: **+** origination

Example: AT*EVD=" +4646371700 "

OK

***EVH** *Voice Hook Command*

Description: Signals the MS to terminate an active voice call.

Execute command: ***EVH**

Example: AT*EVH

OK

4.20 Ensemble C25/E : ETSI 07.10 Multiplex Protocol

+CMUX *Activate Multiplex Protocol*

Description: The command is used for turning on the multiplexer.

Set command: **+CMUX**=<transparency>[,<subset>[,<port speed>[,<N1>[,<T1>[,<N2>[,<T2>[,<T3>]]]]]]]

Defined values **0** No transparency.
<transparency>:

 <subset>: **0** Only UIH frames used.

 <port speed>: **0** 9600 bit/s.

 <N1>: **31** Default maximum frame size.

 <T1>: **10** 100ms default timer.

 <N2>: **3** Default maximum number of re-transmissions.

 <T2>: **30** 300ms default timer.

 <T3>: **10** 10s default timer.

Example: AT+CMUX=0 Enable 07.10. @57600 bps
 OK Switch to new baud rate
 and 07.10

Read command: **+CMUX?**

Example: AT+CMUX?
 +CMUX: 0,0,0,31,10,3,30,10
 OK

Test command: **+CMUX=?**

Example: AT+CMUX=?
 +CMUX: (0),(0),(0),(31),
 (10),(3),(30),(10)
 OK

4.21 Ensemble C26/C/E : Accessory Identification

***EACS** *Ericsson Accessory Status*

Description: Identifies an accessory, reports accessory status and requests a unique identifier.

Set command: ***EACS=<accessory id>,<status value>[,<unique id>]**

Defined values <accessory_id>:	1	Portable hands free. Presented in TE as: PORTABLE_HF_TXT
	2	Vehicle hands free. Presented in TE as: VEHICLE_HF_TXT
	3	RS232-cord. Presented in TE as: DATA_CABLE_TXT
	4	IR-device. Presented in TE as: INFRARED_MODEM_TXT
	5	Reserved for Vibrator. Not supported
	6	Charger – intelligent. Presented in TE as: DESKTOP_CHARGER_TXT+<nr>
	7	Charger – simple. Presented in TE as: TRAVEL_CHARGER_TXT
	8	Reserved for MC-Link. Not supported
	9	Reserved for FM Radio. Not supported
	10	Reserved for Cordless headset. Not supported
	11	Reserved for PC card. Not supported
	12	External Handset. Presented in TE as: EXTERNAL_HANDSET_TXT

AT Commands Phone Terminal Terminated

	13..255	Reserved for future accessories. Presented in TE as: ACCESSORY_TYPE_TXT+<accessory id>
<status value>:	0	Device is not working.
	1	Device is connected and working.
	2	Device is connected and working and is searching for other IrDA-devices. (Only Infrared, accessory id 4)
	3	Device is connected and working and has found another IrDA-device in range. (Only Infrared, accessory id 4) Not supported.
	4	Device is connected and working and is engaged in an IrDA connection. (Only Infrared, accessory id 4)
	5	Device is connected and working and is engaged in an IrDA connection, but the IrDA beam is obstructed. (Only Infrared, accessory id 4)
Returns <unique id>:	0	Request a new unique identifier from the phone.
	1-65534	Unique identifier for a unique accessory.
	65535	Default value used by non-unique accessories.
Example:	AT*EACS=1,1,1 *EACS: 1 OK	
Read command:	*EACS?	
Example:	AT*EACS? *EACS: 1,1,1	

AT Commands Phone Terminal Terminated

*EACS: 2,1,2

OK

Test command: ***EACS=?**

Example: AT*EACS=?

*EACS: (1-2)

OK

4.22 Ensemble C30/C/E : VAD Support for Vehicle HF 3V

***EYRR** *Recording Result*

Description: Sent from the external VAD to the MS. VAD returns the result of the recording.

Set command: ***EYRR=<result>[,<storage>,<index>]**

Defined values	0	Matched Name or Training Good. Response for *EYRE, *EYTN.
<result>:	1	No Match Detected, or no word detected. Response for *EYRE, *EYTN.
	2	To Loud. Response for *EYRE, *EYTN
	3	To Silent/Quiet. Response for *EYRE, *EYTN
	4	No User Input Detected. Response for *EYRE, *EYTN
	5	Two Names Detected as Close. Response for *EYRE
	6	Name close to,. Response for *EYTN
<storage>:	String	<div> <div>"SM"</div> <div>SIM</div> </div> <div> <div>"ME"</div> <div>Mobile</div> </div> <div> <div>"MT"</div> <div>(SIM+Mobile) Not supported (Accessory Vehicle HF must support this value)</div> </div> <div> <div>"RC"</div> <div>ME received calls Not supported (Accessory Vehicle HF must support this value)</div> </div>

	“DC”	ME dialled calls Not supported (Accessory Vehicle HF must support this value)
	“MC”	ME missed calls Not supported (Accessory Vehicle HF must support this value)
	“EN”	SIM or ME emergency number Not supported (Accessory Vehicle HF must support this value)
	“ON”	SIM or ME own numbers Not supported (Accessory Vehicle HF must support this value)
	“FD”	SIM fixdialling-phonebook Not supported (Accessory Vehicle HF must support this value)
	“LD”	SIM last-dialling-phonebook Not supported (Accessory Vehicle HF must support this value)
	“TA”	TA phonebook Not supported
	“HP”	Hierarchical phonebook (Ericsson specific) Not supported (Accessory Vehicle HF must support this value)
<index>:	Integer	0..255 Depending on SIM capacity and ME capacity
Example:	AT*EYRR=0 , 67 VAD recording matches index 67OK	

***EYRE**

Description: Sent from the external VAD to the MS. Tells MS that index <index> in phonebook is recognised (not recognised) by external VAD.

Set command: ***EYRE=**<storage>,<index>, <recognised>,
<records left>

Defined values See values under command *EYRR
 <storage>:

<index>: See values under command *EYRR

<recognised>:	Integer	0	Phonebook unrecognised. Response for *EYSR, *EYDE.
---------------	----------------	----------	--

1 Phonebook recognised.
Response for *EYSR,
*EYDE.

<records left>	Integer	Number of free record places left. Response for *EYSR
----------------	----------------	--

Example: AT*EYRE="SM" , 20 Index 20 in SIM is
, 1, 30 recognised. VAD has 3
record places free.

OK

*EYDO	Done
Description:	Sent from the external VAD to the MS. VAD is done with playback.
Execute command:	*EYDO
	Response for *EYPE,*EYPP,*EYPT
Example:	AT*EYDO
	VAD is done with playback.
	OK

Description: Sent from the external VAD to the MS. External VAD is available.

Set command: ***EYRV=<VAD status>,<total records>,<records left>**

Defined values <VAD status>:

Integer 0	Phone is recognised
1	Phone is not recognised, free entry for new phone.
2	Phone is not recognised, no free entry for new phone.

<total records> **Integer** Number of total record places (free+used).

<records left> **Integer** Number of free record places left.

Example: **AT*EYRV=0,10,10** Phone is recognised, 10 free record places that can be trained. Totally 10 record places.

OK

AT Commands Phone Terminal Terminated

***EYPI** *Phone Info*

Description: Sent from the external VAD to the MS. External VAD is available.

Set command: ***EYRV**=<max>, <used>[, <entry>, <SIM>, <IMEI>, <Phone number>]

Defined values **Integer** Maximum number of different phones supported
 <max>:

 <used> **Integer** How many are used

 <entry> **Integer** The number for this entry

 <SIM> **String** ISMI for entry

 <IMEI> **String** IMEI for entry

<Phone number> **String** Subscriber phone number

Example: AT*EYPI=2,2,1,"97439587349857",
 "94358998456", "+4646193370"

OK

Unsolicited Result Codes

***EYPE** *Play Entry*

Description: This is sent from the MS to the external VAD. Play phonebook entry.

Unsolicited Result code: ***EYPE:**<storage>,<index>

Defined values See values under command *EYRR
<storage>:

<index>: See values under command *EYRR

***EYPP** *Play Prompt*

Description: This is sent from the MS to the external VAD. Play prompt.

Unsolicited Result code: ***EYPP:**<prompt>

Defined values **Integer** **0** WarningBeep_sd
<prompt>:

1 VoiceMissBeep_sd

2 StartVoiceRecording_sd

***EYRE** *Recognise*

Description: This is sent from the MS to the external VAD. VAD starts recognising.

Unsolicited Result code: ***EYRE**

AT Commands Phone Terminal Terminated

***EYTN** *Train Name*

Description: This is sent from the MS to the external VAD. VAD starts recording.

Unsolicited Result ***EYTN**
code:

***EYPT** *Play Training Recording*

Description: This is sent from the MS to the external VAD. VAD starts playback of recording.

Unsolicited Result ***EYPT**
code:

***EYDE** *Delete Entry*

Description: This is sent from the MS to the external VAD. VAD deletes the entry from its list.

Unsolicited Result ***EYDE:<storage>,<index>**
code:

Defined values See values under command *EYRR
<storage>:

<index>: See values under command *EYRR

AT Commands Phone Terminal Terminated

***EYSR** **Save Recording**

Description: This is sent from the MS to the external VAD. VAD saves the recording.

Unsolicited Result ***EYSR:**<storage>,<index>
code:

Defined values See values under command *EYRR
<storage>:

<index>: See values under command *EYRR

***EYAB** **Abort**

Description: This is sent from the MS to the external VAD. Aborts playback/recording.

Unsolicited Result ***EYAB**
code:

***EYGP** **Get Phones**

Description: This is sent from the MS to the external VAD. VAD should supply phone with information about phone entry <entry>. See also command AT*EYPI.

Unsolicited Result ***EYGP:**<entry>
code:

Defined values **Integer** The number for this entry.
<entry>:

AT Commands Phone Terminal Terminated

***EYDP** **Delete Phone**

Description: This is sent from the MS to the external VAD. VAD should delete a phone from VAD.

Unsolicited Result ***EYDP:<entry>**
code:

Defined values **Integer** The number for this entry.
<entry>:

***EYRP** **Register Phone**

Description: This is sent from the MS to the external VAD. User has selected external handsfree, please register phone.

Unsolicited Result ***EYRP**
code:

***EYSS** **Start Synchronise**

Description: This is sent from the MS to the external VAD. Starts the synchronisation.

Unsolicited Result ***EYSS**
code:

4.23 Ensemble C31/C/E : Quick Menu

***ECMW** *Ericsson Customized Menu Write*

Description: Puts a menu item given by <index> from the menu list into the Customized menu in the position given by <pos>. The item on this position and items below this position are shifted down one step. If the parameter <pos> is not given then the item will be placed at the first empty place in the Customized menu list.

Set command: ***ECMW=[<pos>],<index>**

Defined values **Integer** The position in the Customized Menu.
 <pos>:

 <index>: **Integer** Gives the position of a menu item in
 the menu list

Example: AT*ECMW=1 , 1

OK

Delete command: ***ECMW=<pos>** Deletes item on position.

Example: AT*ECMW=1

OK

Read command: ***ECMW?**

Example: AT*ECMW?

*ECMW: 1 , 1

*ECMW: 2 , 3

OK

Test command: ***ECMW=?**

Example: AT*ECMW=?

*ECMW: (1-4)

OK

***EMLR** *Ericsson Menu List Read*

Description: Lists the menu items that are possible to add to the Customized Menu. The index and the name of the menu items are listed. The name is given in the language of the current setting.

Execute command: ***EMLR**

Returns: ***EMLR:<index1>,<name1>[<CR><LF>
*EMLR:<index2>,<name2>[...]]**

Defined values **Integer** Gives the position of a menu item in
<index>: the menu list.

<name>: **String** The name of the menu item.

Example: AT*EMLR
 *EMLR: 1,open
 *EMLR: 3,close
 OK

Test command: ***EMLR=?**

Example: AT*EMLR=?
 OK

5AT Commands Modem Terminated

Note: These commands require IR modem.

5.1 Ensemble S1/B/E : GSM DTE-DCE Interface commands

+CSCS *Select terminal character set*

Description: Defines the character set to be used.

Set command: **+CSCS=[<chset>]**
Options: <chset> "GSM" Default GSM alphabet.
Example: AT+CSCS="GSM"
OK

Read command: **+CSCS?** Returns the current setting.
Example: AT+CSCS?
+CSCS: "GSM"
OK

Test command: **+CSCS=?**
Example: AT+CSCS=?
+CSCS: "GSM" , "IRA" , "88591" , "ERICSSON"
OK

5.2 Ensemble C2/B : Identification and Control

AT *Attention Command*

Description: Determines the presence of a MS.

Execute command: **AT**

Example: AT

OK

Z *Reset to user defined configuration*

Description: Perform a 'soft reset', i.e. terminate any ongoing operation and connection and restore one of the configurations stored in nonvolatile memory as the active profile.

Set command: **Z=[<profile>]**

Options: <profile>

0

Select the user profile to restore.

Example 1: ATZ

OK

Test command: **Z=?**

Example: ATZ=?

Z: (0)

OK

&F *Set to factory configuration*

Description: Resets the settings to the predefined factory configurations. Configurations which would adversely effect an open connection or a current data transmission are not loaded until the connection ceases.

Command: **&F=[<pr>]** or **&F[<pr>]**

Options: <pr> **0** Reset all the settings to the factory defaults.

Example: AT&F
OK

Test command: **&F=?** Always returns (0).

Example: AT&F=?
&F: (0)
OK

I Identification information

Description: Returns information text and final result code. Provides compatibility with Windows 95.

Execute command: I[<value>]

Options: <value> 0 As +GMM.
1 As +GMR.
5 Userprofile 1 and 2.
Default = 0.

Example: AT+I0
Ericsson DI 28
OK

+GMI *Request Infrared Modem manufacturer identification*

Description: Returns the manufacturer identification for the Infrared Modem.

Execute command: **+GMI**

Example: AT+GMI
Ericsson
OK

Test command: **+GMI=?**

Example: AT+GMI=?
OK

+GMM *Request Infrared Modem model identification*

Description: Returns the model identification of the Infrared Modem.

Execute command: **+GMM**

Example: AT+GMM
<TAE Model Identification>
OK

Test command: **+GMM=?**

Example: AT+GMM=?
OK

+GMR *Request Infrared Modem revision identification*

Description: Returns the revision identification of the Infrared Modem.

Execute command: **+GMR**

Example: AT+GMR
 9807021414
 OK

Test command: **+GMR=?**

Example: AT+GMR=?
 OK

+GCAP *Request Infrared Modem capabilities list*

Description: Returns a list of valid Infrared Modem command prefixes.

Execute command: **+GCAP**

 Returns: **+FCLASS** Fax class 1 and 2 commands.

+CGSM GSM commands.

Example: AT+GCAP

 +GCAP: +FCLASS , +CGSM

 OK

Test command: **+GCAP=?**

Example: AT+GCAP=?

 OK

5.3 Ensemble S2/B : GSM Call Control

+CR *Service reporting control*

Description: Enables or disables display of intermediate bearer capability reports during the handshake phase.

Set command: **+CR=[<mode>]**

Options: <mode> **0** Disable reporting.
 1 Enable reporting.

Default = 0.

Example 1: AT+CR=1 Enable service reporting.
 OK

Example 2: AT+CR=0 Disable service reporting.
 OK

Read command: **+CR?** Returns the current setting.

Example: AT+CR?
 +CR: 0
 OK

Test command: **+CR=?** Always returns (0,1).

Example: AT+CR=?
 +CR: (0,1)
 OK

Unsolicited
Result code: **+CR ASYNC** Asynchronous transparent call connection indicated.

+CRC *Cellular result codes*

Description: Enables or disables extended format of incoming call identification.

Set command: **+CRC=[<mode>]**

Options: <mode> **0** Disable extended format.

1 Enable extended format.

Default = 0.

Example 1: AT+CR=1 Enable CRC.

 OK

Example 2: AT+CRC=0 Disable CRC.

 OK

Read command: **+CRC?** Returns the current setting.

Example: AT+CR?

 +CR: 0

 OK

Test command: **+CRC=?** Always returns (0,1).

Example: AT+CR=?

 +CR: (0,1)

 OK

Unsolicited

Result code: **+CRING: <type>**

Unsolicited Result Codes

***CRING** *Cellular result code*

Description Set command controls whether or not the extended format of incoming call indication is used.

Unsolicited Result code:	*CRING: <type>	When enabled,indicates the incoming call to the TE instead of the normal RING.
Defined values:	<type>	
	ASYNC	Asynchronous transparent.
	SYNC	Synchronous transparent.
	REL	Asynchronous non-transparent.
	ASYNC	
	REL	Synchronous non-transparent.
	SYNC	
	FAX/	Facsimile.
	VOICE	Normal voice (TS 11).

5.4 Ensemble C3/B : Call Control

A **Answer**

Description: Answer and initiate connection to an incoming call.

Execute command: **A**

Example: ATA

CONNECT 9600

H **Hook control**

Description: Terminates a connection.

Execute command: **H[<n>]**

Example: ATH

OK

Option: <n> **0** Disconnect data connection.

AT Commands Modem Terminated

D **Dial**

Description: Initiate a phone voice connection (phone number terminated by semicolon). The phone number used to establish the connection will consist of digits and modifiers or a stored number specification.

Execute command:	D	Dial the phone number entered on the phone display.
Other options:	D<n>	Dial the phone number specified in the command as <n>.
	D=ME<i>	Dial the phone number stored in the mobile phone which is located by the index <i>.
	D=SIM<i>	Dial the phone number stored in the SIM card which is located by the index <i>.
	DL	Redial the last phone number dialled.
Modifiers:	W	The W modifier is ignored but is included only for compatibility purposes.
	,	The comma modifier is ignored but is included only for compatibility purposes.
	;	Informs the Infrared Modem that the number is a voice rather than a fax or data number.
	T	The T modifier is ignored but is included only for compatibility purposes.

AT Commands Modem Terminated

	P	The P modifier is ignored but is included only for compatibility purposes.
Dial examples:	ATD0705862975	
	<response>	See below for possible responses.
	ATD=ME7	Dial the number stored in index 7 of the mobile phone.
	<response>	
	ATD=SIM5	Dial the number stored in index 5 of the SIM card.
	<response>	
	ATD046193000;	Voice dial, immediately returns OK.
	ATDL	Redial the last number dialled.
Responses:	CONNECT <speed>	Data or fax connection established at the rate given in <speed>.
	NO CARRIER	Unable to establish a connection or the connection attempt was aborted by the user.
	ERROR	An unexpected error occurred while trying to establish the connection.
	NO DIALTONE	The mobile phone is being used for a voice call or is not within coverage of the network.
	BUSY	The phone number called is engaged, only valid for data and fax connections.

O ***Return to on-line data mode***

Description: Switch to the on-line data mode from the on-line command mode during an active call. Returns `ERROR` when not in on-line command mode.

Execute command: **O**

Examples: `ATO`
 `CONNECT 9600`

P ***Select pulse dialling***

Description: Implemented for compatibility only. Would normally cause the next D command to use pulses/tones when dialling the number.

Set command: **P**

Example: `ATP`
 `OK`

Test command: **P=?**

Example: `ATP=?`
 `OK`

T ***Select tone dialling***

Description: Implemented for compatibility only. Would normally cause the next D command to use pulses/tones when dialling the number.

Set command: **T**

Example: `ATT`
 `OK`

AT Commands Modem Terminated

Test command: **T=?**

Example: ATT=?

OK

5.5 Ensemble S3/B : GSM Data/Fax

+CRLP *Radio link protocol*

Description: Define the Radio Link Protocol parameters.

Set command: **+CRLP**=[<iws>,[<mws>,[<T1>,[<N2>]]]]

Options: <iws> **0 - 61** IWF to MS window size.
Default = **61**.

<mws> **0 - 61** MS to IWF window size.
Default = **61**.

<T1> **38 - 255** Acknowledgement timer in
units of 10ms.
Default = **48**.

<N2> **0 - 255** Retransmission attempts.
Default = **6**.

Example: AT+CRLP=61,61,48,6
OK

Read command: **+CRLP?** Returns the current setting.

Example: AT+CRLP?
+CRLP: 61,61,48,6
OK

Test command: **+CRLP=?** Always returns (0,61),
(0,61),(38-255),(0-255).

Example: AT+CRLP=?
+CRLP: (0-61),(0-61),(38-255),(0-255)
OK

AT Commands Modem Terminated

+CBST *Select bearer service type*

Description: Define the type of bearer service (name), data rate (speed) and connection element (ce) used when initiating a call.

To configure the Infrared Modem to operate with an ISDN connection, the speed value must be 68 or greater.

Set command: **+CBST=[<speed>,[<name>],[<ce>]]]**

Options:	<speed>	0	Auto selection of baud setting.
		4	2400bps V22bis.
		6	4800bps V32.
		7	9600bps V32.
		68	2400bps V.110 (ISDN).
		70	4800bps V.110 (ISDN).
		71	9600bps V.110 (ISDN).
			Default = 0 .
	<name>	0	Asynchronous connection.
	<ce>	1	Non transparent.

Example: AT+CBST=0,0,1

OK

Read command: **+CBST?** Returns the current setting.

Example: AT+CBST?

+CBST: 0,0,1

OK

AT Commands Modem Terminated

Test Command: **+CBST=?** Always returns (0,4,6,7,
68,70,71),(0),(1).

Example: AT+CBST=?
 +CBST: (0,4,6,7,68,70,71),(0),(1)
 OK

5.6 Ensemble C4/B : Interface Commands

S2 *Escape sequence character*

Description: Defines the character to be used as the escape sequence character when switching from on-line data mode to on-line command mode. The response to the command is modified to reflect the change.

Set command: **S2=[<esc>]**

Options: <esc> **43** The ASCII value of the escape sequence character.

 0-255 Escape sequence character.

 Default = **43**.

Example: ATS2=43
 OK

Read command: **S2?** Returns the current setting.

Example: ATS2?
 043
 OK

Test command: **S2=?**

Example: ATS2=?
 S2: (0-255)
 OK

S3 ***Command line termination character***

Description: Defines the character to be used as the line termination character. This is used both for the detection of an end of command and in formatting of responses. The response to the command is modified to reflect the change.

Set command: **S3=[<value>]**

Options: <value> **13**

The default ASCII value of the Command Line termination character.

0-127

Command Line termination character.

Default = **13**.

Example: **ATS3=13**

OK

Read command: **S3?**

Returns the current setting.

Example: **ATS3?**

013

OK

Test command: **S3=?**

Always returns (0-127).

Example: **ATS3=?**

S3: (0-127)

OK

S4 *Response formatting character*

Description: Defines the character to be used as the line formatting character. The response to the command is modified to reflect the change.

Set command: **S4=[<value>]**

Options: <value> **10**

The default ASCII value of formatting character.

0-127

Formatting character.

Default = **10**.

Example: ATS4=10

OK

Read command: **S4?**

Returns the current setting.

Example: ATS4?

010

OK

Test command: **S4=?**

Always returns (0-127).

Example: ATS4=?

S4: (0-127)

OK

S5 *Command line editing character*

Description: Defines the character to use as command line editing character.

Set command: **S5=[<value>]**

Options: <value> **8**

The default ASCII value of the Line Editing Character.

0-127

Line editing character.

Default = **8**.

Example: ATS5=8

OK

Read command: **S5?**

Returns the current setting.

Example: ATS5?

008

OK

Test command: **S5=?**

Always returns (0-127).

Example: ATS5=?

S5: (0-127)

OK

AT Commands Modem Terminated

E **Command echo**

Description: Enables or disables the command line echo.

Set command: **E**=[<value>] or **E**[<value>]

Options: <value> **0** No echo of command mode characters.

1 Echo command mode characters.

Default = 1.

Example: ATE=1

 OK

Read command: **E?** Returns the current setting.

Example: ATE?

 E: 1

 OK

Test command: **E=?** Always returns (0,1).

Example: ATE=?

 E: (0,1)

 OK

Q ***Result code suppression***

Description: Enables or disables the display of result codes. When the result code is disabled, the Infrared Modem does not issue any final result codes but continues to provide normal text in response to commands.

Set command: **Q=[<value>] or Q[<value>]**

Options: <value> **0** Enable result codes.
 1 Disable result codes.
 Default = **0**.

Example: ATQ=1
 OK

Read command: **Q?** Returns the current setting.

Example: ATQ?
 Q: 1
 OK

Test command: **Q=?** Always returns (0,1).

Example: ATQ=?
 Q: (0,1)
 OK

V **Result code format**

Description: Select either verbose or numeric response codes.

Set command: **V**=[<value>] or **V**[<value>]

Options: <value> **0** Display numeric result codes.

1 Display verbose result codes.

Default = **1**.

Example: **ATV=1**

 OK

Read command: **V?** Returns the current setting.

Example: **ATV?**

V: 1

 OK

Test command: **V=?** Always returns (0,1).

Example: **ATV=?**

V: (0,1)

 OK

&C *Circuit 109 (DCD) control*

Description: Determines the behaviour of the carrier detect.

Set command: **&C[<value>]**

Options: <value> **0** DCD always on.

1 DCD follows the connection.

 Default = 1.

Example: AT&C1

 OK

&D *Circuit 108 (DTR) response*

Description: Controls all actions initiated by data terminal ready from DTE.

Set command: **&D[<value>]**

Options: <value> for DTR On to Off transitions:

0 Ignore. Default value.

1 When in on-line data mode then switch to on-line command mode. All other states, as for n = 2.

2 Disconnect and switch to off-line command mode.

Example: AT&D2

 OK

AT Commands Modem Terminated

+IFC *DTE-DCE local flow control*

Description: Defines the flow control between the Infrared Modem and the computer when in on-line data mode. No flow control is enabled in any of the command modes.

Set command: **+IFC=[<by_te>,<by_ta>]**

Options:	<by_te>	0	No flow control on DTE.
		1	Xon/Xoff flow control on DCE. Control characters are removed by the DCE interface.
		2	RTS flow control on DCE.
		3	Xon/Xoff flow control on DCE. Control characters are passed to the remote DCE/DTE.
			Default = 2 .
	<by_ta>	0	No flow control on DCE.
		1	Xon/Xoff flow control on DTE.
		2	CTS flow control on DCE.
			Default = 2 .

Example: **AT+IFC=2,2**
OK

Read command: **AT+IFC?** Returns the current setting.

Example: **AT+IFC?**
+IFC: 2,2
OK

AT Commands Modem Terminated

Test command: **AT+IFC=?** Always returns (0-3),(0-2).

Example: AT+IFC=?
+IFC: (0-3),(0-2)
OK

S0 ***Automatic answer control***

Description: Defines the automatic answering feature of the Infrared Modem. A non-zero value specifies the number of rings before the call is answered.

Note that the call is always answered in the current Fax Class, regardless of whether the incoming call is voice, data or fax.

Set command: **S0=[<rcnt>]**

Options: <rcnt> **0** Disable automatic answer.
 1 - 7 Answer after the specified number of rings.
 Default = **0**.

Example: AT S0=0
 OK

Read command: **S0?** Returns the current setting.

Example: AT S0?
 000
 OK

Test command: **S0=?** Always returns (0-7).

Example: AT S0=?
 S0: (0-7)
 OK

S6 *Blind dial delay control*

Description: Defines the number of seconds to wait before call addressing when a dial-tone is not detected. This command is ignored by the Infrared Modem and is only included for compatibility.

Set command: **S6**=[<dly>]

Options: <dly> **2 - 255**

Default = 2.

Example: `ATS6=2`

OK

Read command: **S6?**

Returns the current setting.

Example: `ATS6?`

002

OK

Test command: **S6=?**

Always returns (2-255).

Example: `ATS6=?`

S6: (2-255)

OK

S7 **Connection completion timeout**

Description: Defines the maximum time allowed between completion of dialling and the connection being established. If this time is exceeded then the connection is aborted.

Set command: **S7=[<tmo>]**

Options: <tmo> **1 - 255** Timeout value in seconds.
Default = **50**.

Example: ATS7=50

OK

Read command: **S7?** Returns the current setting.

Example: ATS7?

050

OK

Test command: **S7=?** Always returns (1-255).

Example: ATS7=?

S7: (1-255)

OK

S8 *Comma dial modifier delay control*

Description: Implemented for compatibility only.

Set command: **S8**=[<dly>]

Options: <dly> **1 - 255** The value of the dial
modifier delay in seconds.
Default = **2**.

Example: **ATS8=2**

OK

Read command: **S8?** Returns the current setting.

Example: **ATS8?**

002

OK

Test command: **S8=?** Always returns (1-255).

Example: **ATS8=?**

S8: (1-255)

OK

S10 ***Automatic disconnect delay control***

Description: This parameter specifies the amount of time that the DCE will remain connected to the line after the absence of received line signal. This command is ignored by the Infrared Modem and is only included for compatibility.

Set command: **S10=[<val>]**

Options: <val> **1-254**

Example: ATS10=2

OK

Read command: **S10?**

Example: ATS10?

002

OK

Test command: **S10=?** Always returns (1-254).

Example: ATS10=?

S10: (1-254)

OK

M **Monitor speaker control**

Description: Define the activity of the speaker. This command is ignored by the Infrared Modem and is only included for compatibility.

Set command: **M**=[<speaker>]

Options: <speaker> **0-3** 0 is off during the entire call.

Examples: ATM=0

OK

Read command: **M?**

Example: ATM?

M: 0

OK

Test command: **M=?** Always returns (0-3).

Example: ATM=?

M: (0-3)

OK

X *Call progress monitoring control*

Description: Define whether the dial tone detection and busy tone detection are to be used during a call setup.

Set command: **X**=[<n>] or **X**[<n>]

Options:	<n>	0	Busy and dial tone detection off. No line speed reported on connection.
		1	Busy and dial tone detection off. Report linespeed on connection.
		2	Busy detection on and dial tone detection off. Report line speed on connection.
		3	Busy detect off and dial tone detection on. Report line speed on connection.
		4	Busy detect and dial tone detection on. Report line speed on connection.
			Default = 4 .

Examples: **ATX4**
 OK

Read command: **X?** Returns the current setting.

Example: **ATX?**
 X: 4
 OK

Test command: **X=?** Always returns (0-4).

Example: **ATX=?**
 X: (0-4)
 OK

5.7 Ensemble S4/B : GSM Extended Error Reporting

+CEER *Extended error report*

Description: Returns the text description of the last error encountered in an unsuccessful connection.

Execute command: **+CEER**

Returns: <report> Text string containing reason of last call clearing or unsuccessful call set-up (originating or answering).

Example: AT+CEER
 +CEER: failure
 OK

Test command: **+CEER=?**

Example: AT+CEER=?
 OK

5.8 Ensemble C6/B : Data Compression

+DS

Data compression

Description: This extended-format compound parameter controls the V.42 bis data compression function if provided in the TAE. .

Set command: **+DS**=[<direction>[,<compression_negotiation>[,<max_dict>[,<max_string>]]]]

Options
<direction>: specifies the desired direction(s) of operation of the data compression function; from the TE point of view

Value	0	Disable V.42 bis
	1	Enable V.42bis in transmit direction only
	2	Enable V.42bis in receive direction only
	3	Enable V.42bis compression both ways. Default= 3

<compression_negotiation>: specifies whether or not the TAE should continue to operate if the desired result is not obtained

Value	0	Accept connection if compression is negotiated according to direction. Default= 0
	1	Disconnect if compression is not negotiated according to direction

<max_dict>: specifies the maximum number of dictionary entries which should be negotiated

Value	512-4096	Maximum dictionary size. Default= 4096
-------	-----------------	--

<max_string>: specifies the maximum string length to be negotiated (V.42bis P2)

Value **6-250** Maximum string length. Default=**32**

Example: AT+DS=0,1,512,6

OK

Read command: **+DS?** Returns the current setting.

Example: AT+DS?

+DS: 3,0,4096,32

OK

Test command: **+DS=?**

Example: AT+DS=?

+DS: (0-3),(0,1),(512-4096),(6-250)

OK

+DR *Data compression reporting*

Description: If enabled, the intermediate result code is transmitted at the point after error control negotiation (handshaking) at which the TAE has determined which data compression technique will be used (if any) and the direction of operation..

Set command: **+DR=<value>**

 <value> **0** Disable compression mode reporting

1 Enable compression mode reporting

 Default=**0**

Example: AT+DR=1

 OK

Read command: **+DR?** Returns the current setting.

Example: AT+DR?

 +DR: 0

 OK

Test command: **+DR=?**

Example: AT+DR=?

 +DR: (0 , 1)

 OK

Unsolicited Result Codes

+DR *Data Compression Indication*

Description: The intermediate result code is issued after the Error Control Report (+ER) and before the final result code (e.g. CONNECT). Use the AT+DR command to enable the indication.

- Unsolicited Result code: **+DR:<type>**
- <type>: **NONE** No data compression negotiated
- V42B** V.42 bis data compression negotiated
- V42B RD** V.42 bis half duplex compression negotiated on received data
- V42B TD** V.42 bis half duplex compression negotiated on transmitted data

5.9 Ensemble S10/B : GSM Mobile Equipment Error Control

+CMEE *Report mobile equipment error*

Description: Enables or disables mobile phone error reporting.

Set command: **+CMEE=[<n>]**

Options:	<n>	0	Disable +CMEE error reporting.
		1	Enable +CMEE error reporting. Use numeric <err> values.
			Default = 0 .

Example: AT+CMEE=1 Enable, error numeric.
OK

Read command: **+CMEE?** Returns the current setting.

Example: AT+CMEE?
+CMEE: 1 Enabled.
OK

Test command: **+CMEE=?**

Example: AT+CMEE=?
+CMEE: (0 , 1)
OK

5.10 Ensemble C18/B : Fax Class 1

Some fax commands can only be used during connection to a remote facsimile and return `ERROR` otherwise. Most fax commands return `ERROR` when the appropriate Fax Class is not selected beforehand.

+FCLASS *Capabilities Identification and Control*

Description: Sets the service class.

Set command: **+FCLASS=<class>**

- | | | | |
|----------|---------|----------|----------------------------|
| Options: | <class> | 0 | Data modem. |
| | | 1 | Service Class 1 fax modem. |
| | | 2 | Service Class 2 fax modem. |

Example: `AT+FCLASS=1`
`OK`

Read command: **+FCLASS?** Returns the current service class setting.

Example: `AT+FCLASS?`
`1`
`OK`

Test command: **+FCLASS=?** Provides the service classes available as a list of comma separated values.

Example: `AT+FCLASS=?`
`0,1,2`
`OK`

+FMI *Manufacturer identification*

Description: Request manufacturer's identification.

Read command: **+FMI?**

Example: AT+FMI?
Ericsson
OK

+FMM *Request product identification*

Description: Request model identification.

Read command: **+FMM?**

Example: AT+FMM?
<TAE Model Identification>
OK

AT Commands Modem Terminated

+FMR *Request version*

Description: Request model revision.

Read command: **+FMR?**

Example: AT+FMR?
9910080907
OK

+FTS *Stop transmission and wait*

Description: Stops the transmission for the specified period.

Set command: **+FTS=<Time>**

Options: <Time> **0 - 255** The silence period in units of 10 ms.

Example: AT+FTS=8
OK

Test command: **+FTS=?** Always returns (0-255).

Example: AT+FTS=?
(0 - 255)
OK

AT Commands Modem Terminated

+FRS *Receive silence*

Description: Waits for silence on the line for the specified period.

Set command: **+FRS=<Time>**

Options: <Time> **0 - 255** The silence period in units of 10 ms. Entering a character will abort the silence period.

Example: AT+FRS=8

OK

Test command: **+FRS=?** Always returns (0-255).

Example: AT+FRS=?

(0 - 255)

OK

AT Commands Modem Terminated

+FTM *Facsimile transmit*

Description: Start transmitting fax data at given speed.

Set command: **+FTM=<Mod>**

Options:	<Mod>	24	V.27ter 2,400 bps.
		48	V.27ter 4,800 bps.
		72	V.29 7,200 bps.
		96	V.29 9,600 bps.

Example: AT+FTM=96

CONNECT

OK

Test command: **+FTM=?** Always returns
(24,48,72,96).

Example: AT+FTM=?
(24 , 48 , 72 , 96)
OK

+FRM **Facsimile receive**

Description: Selects facsimile receive mode.

Set command: **+FRM=<Mod>**

Options:	<Mod>	24	V.27ter 2,400 bps.
		48	V.27ter 4,800 bps.
		72	V.29 7,200 bps.
		96	V.29 9,600 bps.

Example: AT+FRM=96
CONNECT

Test command: **+FRM=?** Always returns (24,48,72,96).

Example: AT+FRM=?
(24 , 48 , 72 , 96)
OK

AT Commands Modem Terminated

+FTH *Transmit HDLC*

Description: HDLC transmit speed.

Set command: **+FTH=<Mod>**

Options: <Mod> **3** V.21 Ch2 300 bps.

Example: AT+FTH=3

CONNECT

Test command: **+FTH=?** Always returns (3).

Example: AT+FTH=?

(3)

OK

+FRH *Receive HDLC*

Description: HDLC receive speed.

Set command: **+FRH=<speed>**

Options: <speed> **3** V.21 Ch2 300 bps.

Example: AT+FRH=3

CONNECT

Test command: **+FRH=?** Always returns 3.

Example: AT+FRH=?

(3)

OK

5.11 Ensemble C19/B : Fax Class 2

Some fax commands can only be used during connection to a remote facsimile and return `ERROR` otherwise. Most fax commands return `ERROR` when the appropriate Fax Class is not selected beforehand.

+FCLASS *Capabilities Identification and Control*

Description: Sets the service class.

Set command: **+FCLASS=<class>**

- | | | | |
|----------|---------|----------|----------------------------|
| Options: | <class> | 0 | Data modem. |
| | | 1 | Service Class 1 fax modem. |
| | | 2 | Service Class 2 fax modem. |

Example: `AT+FCLASS=1`
`OK`

Read command: **+FCLASS?** Returns the current service class setting.

Example: `AT+FCLASS?`
`1`
`OK`

Test command: **+FCLASS=?** Provides the service classes available as a list of comma separated values.

Example: `AT+FCLASS=?`
`0,1,2`
`OK`

+FAA *Fax auto answer setting*

Description: Used to determine if the fax setting is selected by auto answer or by the setting in +FCLASS.

Set command: **+FAA=[<value>]**

Options: <value> **0** Answer according to settings in FCLASS only.

Example: AT+FAA=0

OK

Read command: **+FAA?** Returns the current setting.

Example: AT+FAA?

0

OK

Test command: **+FAA=?** Always returns (0).

Example: AT+FAA=?

(0)

OK

+FAXERR *Request hang-up cause code*

Description: Returns the code of the error which caused the last hang-up.

Read command: **+FAXERR?**

Response: **+FAXERR=<value>**

<value>	0	Normal and proper end of connection Mandatory value.
	1	Ring Detect without successful handshake.
	2	Call aborted, from +FK or <CAN>.
	3	No Loop Current.
	10	Unspecified Phase A error Mandatory value.
	11	No Answer (T.30 T1 timeout) [2].
	20	Unspecified Transmit Phase B error Mandatory value.
	21	Remote cannot receive or send.
	22	COMREC error in transmit Phase B.
	23	COMREC invalid command received.
	24	RSPEC error.
	25	DCS sent three times without response.

AT Commands Modem Terminated

26	DIS/DTC received 3 times; DCS not recognized.
27	Failure to train at 2400 bps or FMINSP value.
28	RSPREC invalid response received.
40	Unspecified Transmit Phase C error Mandatory value.
43	TE to TAE data underflow.
50	Unspecified Transmit Phase D error Mandatory value.
51	RSPREC error.
52	No response to MPS repeated 3 times.
53	Invalid response to MPS.
54	No response to EOP repeated 3 times.
55	Invalid response to EOP.
56	No response to EOM repeated 3 times.
57	Invalid response to EOM.
58	Unable to continue after PIN or PIP.
70	Unspecified Receive Phase B error Mandatory value.
71	RSPREC error.
72	COMREC error.

73	T.30 T2 [2] timeout, expected page not received.
74	T.30 T1 [2] timeout after EOM received.
90	Unspecified Receive Phase C error.
91	Missing EOL after 5 seconds (section 3.2 T.4 [3]).
92	-unused code-.
93	TAE to TE buffer overflow.
94	Bad CRC or frame (ECM or BFT modes).
100	Unspecified Receive Phase D errors.
101	RSPREC invalid response received.
102	COMREC invalid response received.
103	Unable to continue after PIN or PIP.
120-255	-reserved codes-.

Example: `AT+FAXERR?`

1

OK

Test command: **+FAXERR=?** Always returns (0-255).

Example: `AT+FAXERR=?`

(0 - 2 5 5)

OK

+FBADLIN *Number of consecutive bad lines to accept*

Description: Sets the maximum acceptable number of consecutive bad lines.

Set command: **+FBADLIN=[<value>]**

Options: <value> **0** Error checking not present or disabled.

Default = **0**.

Example: AT+FBADLIN=0

OK

Read command: **+FBADLIN?** Returns the current setting.

Example: AT+FBADLIN?

0

OK

Test command: **+FBADLIN=?**

Example: AT+FBADLIN=?

(0)

OK

AT Commands Modem Terminated

+FBOR *Facsimile page transfer bit order parameter*

Description: Set the bit order for negotiation (<bit n>) and facsimile page transfer (<bit f>).

Set command: **+FBOR=[<value>]**

 <value> is the sum of <bit f> and <bit n> where:

<bit f> 0 = same bit order.
 1 = reverse bit order.

 <bit n> 0 = same bit order.
 2 = reverse bit order.

Options: <value> **0** bit f + bit n = 0.
 1 bit f + bit n = 1.
 2 bit f + bit n = 2.
 3 bit f + bit n = 3.
 Default = **0**.

Example: AT+FBOR=0
 OK

Read command: **+FBOR?** Returns the current setting.

Example: AT+FBOR?
 3
 OK

Test command: **+FBOR=?** Always returns (0-3).

Example: AT+FBOR=?
 (0 - 3)
 OK

+FBUF *Buffer size report*

Description: Request buffering parameters.

Read command: **+FBUF?**

Returns: <bs>,<xoft>,<xont>,<bc>

Options:

<bs>	= buffer size.
<xoft>	= XOFF threshold.
<xont>	= XON threshold.
<bc>	= current number of characters in buffer.

Example: AT+FBUF?
 256,0,0,0
 OK

+FBUG *Session Message Report*

Description: Request buffering parameters.

Execute command: **+FBUG=[<value>]**

Options: <value> **0** Disables HDLC frame reporting.

1 Enables reporting.

Default = **0**.

Example: AT+FBUG=1

OK

Read command: **+FBUG?**

Example: AT+FBUG?

1

OK

Test command: **+FBUG=?**

Example: AT+FBUG=?

(0 , 1)

OK

+FCQ *Copy quality checking*

Description: Copy quality checking.

Set command: **+FCQ=[<value>]**

Options: <value> **0**

Do not perform quality checking.

Example: AT+FCQ=0

OK

Read command: **+FCQ?**

Returns the current setting.

Example: AT+FCQ?

0

OK

Test command: **+FCQ=?**

Always returns (0).

Example: AT+FCQ=?

(0)

OK

+FCR *Capability to receive parameter*

Description: Capability to receive.

Set command: **+FCR=[<value>]**

Options: <value> **0** Can not receive fax but can be polled.

1 Can receive fax.

Default = 1.

Example: AT+FCR=1

 OK

Read command: **+FCR?** Returns the current setting.

Example: AT+FCR?

 1

 OK

Test command: **+FCR=?** Always returns (0,1).

Example: AT+FCR=?

 (0 , 1)

 OK

AT Commands Modem Terminated

+FCIG *Local polling ID parameter*

Description: Local polling ID.

Set command: **+FCIG=<local polling ID string>**

Options: <local polling ID string>

String of 0 to 20 characters length.

Example: AT+FCIG="Ericsson Fax"

OK

Read command: **+FCIG?**

Returns the current polling string.

Example: AT+FCIG?

Ericsson Fax

OK

Test command: **+FCIG=?**

Always returns (20)(32-127).

Example: AT+FCIG=?

(20) (32-127)

OK

AT Commands Modem Terminated

+FCTCRTY Continue to correct count during ECM

Description: Continue to correct count during ECM.

Set command: **+FCTCRTY=[<value>]**

Options: <value> **0-255** <value> is in units of 4 retries.

Default = **0**, disabled.

Example: AT+FCTCRTY=1

OK

Read command: **+FCTCRTY?** Returns the current setting.

Example: AT+FCTCRTY?

0

OK

Test command: **+FCTCRTY=?** Always returns (0-255).

Example: AT+FCTCRTY=?

(0-255)

OK

+FDFFC *Data format failure check*

Description: Data format failure check.

Set command: **+FDFFC=[<value>]**

Options: <value> **0** Disable mismatch checking.

Example: AT+FDFFC=0

OK

Read command: **+FDFFC?** Returns the current setting.

Example: AT+FDFFC?

0

OK

Test command: **+FDFFC=?** Always returns (0).

Example: AT+FDFFC=?

(0)

OK

+FDCC *TAE Capability parameters*

Description: This command allows the TE to sense and constrain the capabilities of the facsimile TAE.

Set command: **+FDCC=<vr>,
,<wd>,<ln>,<df>,<ec>,<bf>,<st>**

Options: <vr> = vertical resolution.

0 Normal, 98 lpi.

1 Fine, 196 lpi.

 Default = **1**.

 = bit rate.

0 2400 bit/s V.27ter.

1 4800 bit/s V.27ter.

2 7200 bit/s V.29 or V.17, optional.

3 9600 bit/s V.29 or V.17, optional.

 Default = **3**.

 <wd> = page width.

0 1728 pixels in 215 mm.

1 2048 pixels in 255 mm, optional.

2 2432 pixels in 303 mm, optional.

3 1216 pixels in 151 mm, optional.

4 864 pixels in 107 mm, optional.

 Default = **0**.

AT Commands Modem Terminated

<ln>		= page length.
	0	A4, 297 mm.
	1	B4, 364, optional.
	2	Unlimited length, optional.
		Default = 2 .
<df>		= data compression format.
	0	1-D modified Huffman.
	1	2-D modified Read, optional.
	2	2-D uncompressed mode, optional.
	3	2-D modified Read, optional.
		Default = 0 .
<ec>		= error correction.
	0	Disable ECM
<bf>		= binary file transfer.
	0	Disable ECM

<st> = scan time per line.

0	0 ms
1	5 ms
2	10 ms
3	10 ms
4	20 ms
5	20 ms
6	40 ms
7	40 ms

Default = **0**.

Example: AT+FDCC=0,3,0,2,0,0,0,1

OK

Read command: **+FDCC?**

Example: AT+FDCC?

0,3,0,2,0,0,0,1

OK

Test command: **+FDCC=?**

Example: AT+FDCC=?

(0-1),(0-3),(0-4),(0-2),
(0-3),(0),(0),(0-7)

OK

+FDCS *Session results*

Description: Current session results.

Read command: **+FDCS?**

Returns: <vr>,
,<wd>,<ln>,<df>,<ec>,<bf>,<st>

Options: **<vr>** = vertical resolution.
 **
** = bit rate.
 <wd> = page width.
 <ln> = page length.
 <df> = data compression format.
 <ec> = error correction.
 <bf> = binary file transfer.
 <st> = scan time per line.

Please refer to the +FDCC command for further information on these parameters.

Example: AT+FDCS?
 0,3,0,2,0,0,0,1
 OK

Test command: **+FDCS=?** Always returns
 (0-1),(0-3),(0-4),(0-2),(0-3),
 (0),(0),(0-7).

Example: AT+FDCS=?
 (0-1),(0-3),(0-4),(0-2),
 (0-3),(0),(0),(0-7)
 OK

AT Commands Modem Terminated

+FDIS *Current session negotiation parameters*

Description: Current session negotiation parameters.

Set command: **+FDIS=<vr>,
,<wd>,<ln>,<df>,<ec>,<bf>,<st>**

Options:	<vr>	0	Normal, 98 dpi.
		1	Fine, 196 dpi.
			Default = 1.
	 	0	2400 bps.
		1	4800 bps.
		2	7200 bps.
		3	9600 bps.
			Default = 3.
	<wd>		Page width.
		0	1728 pixels in 215 mm.
1		2048 pixels in 255 mm.	
2		2432 pixels in 303 mm.	
3		1216 pixels in 151 mm.	
4		364 pixels in 107 mm.	
		Default = 0.	
<ln>		Page length.	
	0	A4, 297 mm.	
	1	B4, 364 mm.	
	2	unlimited.	
		Default = 2.	

AT Commands Modem Terminated

<df>		Data compression format.
	0	1-D modified huffman.
	1	2-D modified read.
	2	2-D uncompressed mode.
	3	2-D modified modified read.
		Default = 0 .
<ec>		Error correction.
	0	Disable ECM.
<bf>		Binary file transfer.
	0	Disable BFT.
<st>		Scan time per line.
	0-7	0-40 ms depending on <vr> setting.
		Default = 0 .

Example: AT+FDIS=0,30,2,0,0,0

OK

Read command: **+FDIS?** Returns the current settings.

Example: AT+FDIS?

1,3,0,2,0,0,0,0

OK

Test command: **+FDIS=?** Always returns (0-1),(0-3),(0-4),(0-2),(0-3),(0),(0),(0-7).

Example: AT+FDIS=?

(0-1),(0-3),(0-4),(0-2),
(0-3),(0),(0),(0-7)

OK

+FDR *Fax data receive command*

Description: The +FDR command initiates transition to Phase C data reception. This can occur after answering, after dialling, after a document received, or after a page is received.

Action command: **+FDR**

Example: AT+FCLASS=2

OK

AT+FCR=1

OK

AT+FLID=<local ID>

RING <-

ATA

+FCON

[+FTSI : "<discodes>]

OK

AT+FDR

+FCFR

[+FDCS: <dcs codes>]

CONNECT

<DC2> Page data stream.

<DLE><ETX>

+FPTS:1, <1c>

+FET:0 <-

OK

AT+FDR

CONNECT

<DC2>

Page data stream.

<DLE><ETX>

+FPTS: 1, (1c)

+FET: 2 <-

OK

AT+FDR

+FHNG: 0

+FDT *Fax data transmission command*

Description: The FDT command prefixes Phase C data transmission. When the TAE is ready to accept Phase C data, it will issue the negotiation responses and the CONNECT result code to the TAE. The DF, VR, WD, and LN subparameters are optional.

Action command: **+FDT**[=<df>,<vr>,<wd>,<ln>]

Options:	<df>	Data compression format.
	<vr>	Vertical resolution.
	<wd>	Page width.
	<ln>	Page length.

Example: AT+FCLASS=2
OK
AT+FLID=<local ID>
OK
ATD<dial string>
+FCON
[+FCSI : "<csi>"]
+FDIS:<dis codes>
OK
AT+FDT
+FDCS<dcs codes>
CONNECT
<XON>
OK

AT Commands Modem Terminated

<DLE><ETX>

First page data.

AT+FET=0

+FPTS:1

OK

CONNECT

<XON>

AT+FDT

OK

<DLE><DTX>

Second page data.

AT+FET=2

+FPTS:1

+FHNG:0

OK

+FECM *Error correction mode*

Description: Defines error correction mode.

Set command: **+FECM=<value>**

 <value> **0**

Error correction disabled or not supported.

Example: AT+FECM=0

 OK

Read command: **+FECM?**

Always returns 0.

Example: AT+FECM?

 0

 OK

Test command: **+FECM=?**

Always returns (0).

Example: AT+FECM=?

 (0)

 OK

AT Commands Modem Terminated

+FET *Page punctuation*

Description: This command is used to punctuate page and document transmission, after one or more +FDT commands.

Set command: **+FET=<ppm>[,<pc>,<bc>, <fc>]**

Options: <ppm>

Next page type.

0

[PPS-]MPS - another page next, same document.

1

[PPS-]EOM - another document next.

2

[PPS-]EOP - no more pages or documents.

<pc>

Page Count.

<bc>

Block Count.

<fc>

Frame Count.

Example: AT+FET=0

+FTPS:1

OK

Read command: **+FET?**

Example: AT+FET?

1

OK

Test command: **+FET=?**

Example: AT+FET=?

+FET: (0-2),(0-255),(0-255),(0-255)

OK

+FK *Orderly fax abort*

Description: Aborts fax transmission.

Execute command: **+FK**

Example: AT+FK

+FHNG: 2 ("2" is a hangup status code)
OK

+FLID *Local polling ID parameter*

Description: Allows you to define the local ID string.

Set command: **+FLID=<local ID string>**

Options: <local ID string> String of 0 to 20 characters length.

Example: AT+FLID="Ericsson"

OK

Read command: **+FLID?** Returns the current polling string.

Example: AT+FLID?
"Ericsson"

OK

Test command: **+FLID=?** Always returns (20)(32-127).

Example: AT+FLID=?
(20) (32-127)

OK

+FLNFC *Page length format conversion parameter*

Description: Defines page length format conversion.

Set command: **+FLNFC=[<value>]**

Options: <value> 0 Disable mismatch checking.

Example: AT+FLNFC=0

OK

Read command: **+FLNFC?** Returns current settings.

Example: AT+FLNFC?

0

OK

Test command: **+FLNFC=?** Always returns (0).

Example: AT+FLNFC=?

(0)

OK

+FLPL *Document for polling parameter*

Description: Used by the DTE to indicate to the DCE facsimile machine that it has a document ready for polling. This information is forwarded to the remote FAX.

Set command: **+FLPL=[<value>]**

Options:	<value>	0	No document to poll.
		1	Document available for polling.
			Default = 0 .

Example: **AT+FLPL=1**
 OK

Read command: **+FLPL?** Returns the current setting.

Example: **AT+FLPL?**
 1
 OK

Test command: **+FLPL=?** Always returns (0,1).

Example: **AT+FLPL=?**
 (0 , 1)
 OK

+FMDL *Request product identification*

Description: Returns the product identification of a Class 2 fax machine.

Read command: **+FMDL?**

Example: AT+FMDL?

 <TAE Model Identification>

 OK

+FMFR *Request manufacturer's identification*

Description: Returns the manufacturer identification for a Class 2 fax machine.

Read command: **+FMFR?**

Example: AT+FMFR?

 Ericsson

 OK

AT Commands Modem Terminated

+FMINS *Minimum facsimile page transfer speed parameter*

Description: Set the minimum negotiable speed parameter.

Set command: **+FMINS**=[
]

Options:	 	0	2400 bps V.27 ter.
		1	4800 bps V.27 ter.
		2	7200 bps V.29 or V.17.
		3	9600 bps V.29 or V.17.

Example: AT+FMINS=3 Set rate to 9600 bps.

OK

Read command: **+FMINS?** Returns the current setting.

Example: AT+FMINS?

3

OK

Test command: **+FMINS=?** Always returns (0-3).

Example: AT+FMINS=?

(0 - 3)

OK

+FPHCTO *Facsimile page transfer timeout parameter*

Description: Sets the period the Infrared Modem waits for another page from the PC before it assumes there are no more pages and aborts.

Set command: **+FPHCTO=[<value>]**

Options: <value> **0 - 255** The timeout period in units of 100ms.

Default = 30.

Example: AT+FPHCTO=30

OK

Read command: **+FPHCTO?** Returns the current setting.

Example: AT+FPHCTO?

30

OK

Test command: **+FPHCTO=?** Always returns (0-255).

Example: AT+FPHCTO=?

(0-255)

OK

AT Commands Modem Terminated

+FPTS *Page transfer status parameter*

Description: Set post page transfer response.

Set command: **+FPTS=<ppr>**

Options:	<ppr>	1	Page good.
		2	Page bad; retrain requested.
		3	Page good; retrain requested.

Example: **AT+FPTS=1**

OK

Read command: **+FPTS?** Returns current settings.

Example: **AT+FPTS?**

1

OK

Test command: **+FPTS=?** Always returns (1-3).

Example: **AT+FPTS=?**

(1 - 3)

OK

+FREV Request DCE revision

Description: Returns the version, revision level or other information related to a Class 2 device.

Read command: **+FREV?**

Example: AT+FREV?
9903020939
OK

+FRBC Receive data block size

Description: Receive data block size.

Set command: **+FRBC=[<value>]**

Options: <value> **0** Block can only be set to a size of 0 bytes.

Example: AT+FRBC=0
OK

Read command: **+FRBC?** Returns the current setting.

Example: AT+FRBC?
0
OK

Test command: **+FRBC=?** Always returns (0).

Example: AT+FRBC=?
(0)
OK

AT Commands Modem Terminated

+FREL *Facsimile page transfer EOL alignment parameter*

Description: Received EOL alignment.

Set command: **+FREL=[<value>]**

Options: <value> **0** EOL patterns are bit aligned as received.

Example: AT+FREL=0

OK

Read command: **+FREL?** Returns the current setting.

Example: AT+FREL?

0

OK

Test command: **+FREL=?** Always returns (0).

Example: AT+FREL=?

(0)

OK

+FSPL *Enable polling parameter*

Description: Used to indicate if the PC wishes or is able to poll a document.

Set command: **+FSPL=[<value>]**

Options:	<value>	0	Do not want to poll.
		1	Can receive a polled document.
			Default = 0.

Example: AT+FSPL=1
OK

Read command: **+FSPL?** Returns the current setting.

Example: AT+FSPL?
1
OK

Test command: **+FSPL=?** Always returns (0,1).

Example: AT+FSPL=?
(0 , 1)
OK

AT Commands Modem Terminated

+FTBC *Fax page transfer data transmit byte count parameter*

Description: Sets the size of the transmit data block.

Set command: **+FTBC=[<value>]**

Options: <value> 0

Block can only be set to a size of 0 bytes.

Example: AT+FTBC=0

OK

Read command: **+FTBC?**

Returns the current setting.

Example: AT+FTBC?

0

OK

Test command: **+FTBC=?**

Always returns (0).

Example: AT+FTBC=?

(0)

OK

+FVRF *Vertical resolution conversion parameter*

Description: Disables mismatch checking.

Set command: **+FVRF**=[<value>]

Options: <value> **0** Disable mismatch checking.

Example: AT+FVRF=0
OK

Read command: **+FVRF?** Returns the current setting.

Example: AT+FVRF?
0
OK

Test command: **+FVRF=?** Always returns (0).

Example: AT+FVRF=?
(0)
OK

+FWDFC *Page width conversion parameter*

Description: Width format conversion checking.

Set command: **+FWDFC=[<value>]**

Options: <value> 0 Disable mismatch checking.

Example: AT+FWDFC=0

OK

Read command: **+FWDFC?** Returns the current setting.

Example: AT+FWDFC?

0

OK

Test command: **+FWDFC=?** Always returns (0).

Example: AT+FWDFC=?

(0)

OK

Glossary

Analog

An analog signal can have any value between two limits. Traditional telephone lines, for example, transfer the human voice, itself an analogue signal, by means of a continuously varying electrical voltage. This voltage is an electrical representation of the pressure produced by the sound on the telephone microphone.

ASCII

Acronym for American Standard Code for Information Interchange. A standard code used for transferring data between computers and associated equipment.

Asynchronous communication

Data communication in which data elements are NOT separated according to time. Instead, a special code such as a start bit and a stop bit is used. By using a code, in lieu of time, asynchronous communication is more tolerant of time variations. Complex timing circuits are not needed. The serial port and the COM port of a computer are associated with asynchronous communication, as is the RS-232-C interface. Also some end to end modem protocols are asynchronous.

AT

The characters AT stand for Attention and tells the Infrared Modem that a command follows. AT must be used at the beginning of a command line or dial string.

AT command set

The commands used to control the Infrared Modem.

Auto-answer mode

The state in which the Infrared Modem automatically answers the telephone when it rings.

Bps

Acronym for bits per second (bits/s). A measure of speed at which bits are transmitted over the telephone lines.

Carrier

The frequency used by two connecting modems to transmit and receive data.

CCITT

Consultative Committee for International Telephony and Telegraphy. A European based advisory committee established by the United Nations to recommend international communication protocol standards.

CD

Carrier Detect. An EIA232 signal sent from the Infrared Modem to your computer, usually indicating that your Infrared Modem has detected a carrier signal over the communications line.

Command line

A line of alphanumeric characters sent to the Infrared Modem to instruct the Infrared Modem to perform the commands specified in the line of characters.

Off-line command mode

The operational state in which the Infrared Modem can accept typed commands.

COM (communications) port

The name allocated to the serial port through which digital signals are exchanged between the computer and a serial peripheral. For example COM1 and COM2.

CTS

Clear To Send. An EIA232 signal sent from a modem to the computer, usually indicating that the modem is ready to receive data.

On-line data mode

The state the Infrared Modem is in when transmitting or receiving data over the telephone line.

DCD

Data Carrier Connect. See the &C command.

DCE

Data Communications Equipment. This term applies to modems and to other equipment that provide communication between data terminal equipment and the telephone line.

Default setting

A setting that the Infrared Modem will always use unless specified otherwise.

Digital transmission

A digital signal can have only two values. These can be, for example, ON and OFF, HIGH and LOW or 1 and 2. A digital signal is usually transferred by means of a voltage which is either HIGH or LOW. Conventional modems communicate by means of audio tones which can use the analog telephone network. (See analog) The Infrared Modem links through your mobile telephone to a digital network and therefore has no need to use audio encoding. However, when you use your mobile telephone for a voice call, the analog signal from the microphone must be converted into a digital signal. This is done by a converter which samples the signal voltage several thousand times per second. Each sample is converted into a binary number which represents the voltage at that instant, eg 10011010, and the binary numbers are sent as a serial stream down the digital network.

DSR

Data Set Ready. An EIA232 signal sent from the Infrared Modem to the computer, usually indicating that the Infrared Modem is ready to establish a connection.

DTE

Data Terminal Equipment. The equipment that provides data, such as a computer or terminal.

DTR

Data Terminal Ready. An EIA232 signal sent from the computer to the Infrared Modem, usually indicating that the computer is ready to begin communication.

EIA

Electronics Industries Association. A U.S. based group that forms technical standards and coordinates ITU-TCCITT activities in the United States.

EOL

End of line.

EOP

End of page.

EOM

End of message.

Escape code

A series of three consecutive characters (default is + + +) sent to the Infrared Modem, causing it to exit on-line data mode and enter on-line command mode.

Factory default settings

The profile configuration that is in effect when the Infrared Modem is shipped from the factory.

Final result code

A message sent from the Infrared Modem to inform the PC that execution of an entered AT command has been completed. Examples are `OK` and `ERROR`.

Flow control

The use of characters or EIA232 signals to start and stop the flow of data to avoid data loss during buffering.

Full duplex

Communication involving data transmitted in two directions simultaneously.

Half duplex

Communication involving data transmitted in two directions, but not at the same time.

Intermediate result code

Information sent from the Infrared Modem to the PC as a response to an executed AT command. Intermediate result codes are always followed by a final result code. For example `+CBC: 0,100`.

ISDN

The term used to refer to the digital public switched telephone network.

ITU-T

The ITU Telecommunication Standardization Sector (ITU-T), is a permanent organ of the International Telecommunication Union. The ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunication on a world wide basis.

As a consequence of a reform process within the International Telecommunication Union (ITU), the CCITT ceased to exist as of 28 February 1993. In its place the ITU Telecommunication Standardization Sector (ITU-T) was created as of 1 March 1993.

MMI

Man-Machine Interface.

ME

Mobile Equipment. The Ericsson wireless terminal excluding the SIM card, which in most cases is a mobile phone.

Modem

Modulator-Demodulator. A device that converts digital signals to analog for transmission over telephone lines, then converts them back to digital at the other end of the line.

MS

This is the Ericsson wireless terminal being controlled through the set of commands described in this document.

Off hook

The Infrared Modem state similar to picking up a telephone receiver. The Infrared Modem goes off hook to dial or answer, and remains off hook while connected.

On hook

The Infrared Modem state similar to hanging up a telephone receiver.

PIN

Personal identification number.

PDA

Personal Digital Assistant.

Protocols

The rules or procedures all modems must follow to communicate.

Result code

A message the Infrared Modem sends to the computer containing information about the state of the Infrared Modem.

RLP

Radio Link Protocol, an error correction protocol used during radio link connections.

RLSD

Received Line Signal Detect. See AT command &C.

RTS

Request To Send. An EIA232 signal sent from the computer to the Infrared Modem, usually indicating that the computer is ready to send data to the Infrared Modem.

RS-232-C interface

A communication standard established by the Electronics Industry Association (Recommended Standard number 232, revision C). Originally established to standardize communication between computer and modem. It was later adapted to become a popular standard for communication between computer and any other peripheral equipment, including other computers.

Serial port

The port through which digital signals are exchanged between the Infrared Modem and the computer.

Short message service (SMS)

A text messaging service permitting the transmission of up to 160 characters to a facsimile, X400, telex and voice services or mobile phone.

Synchronous Communication

V.22bis

ITU-T standard for 2400 bps.

V.27ter

ITU-T standard for 4800 bps full-duplex modems connected to switched telephone networks.

V.29

ITU-T standard for 9600 bps half-duplex modems included in FAX machines.

V.42bis

ITU-T standard for the compression of asynchronous data. V.42bis is based on a dictionary that looks up common strings and replaces the strings with code words. This reduces the amount of characters actually transmitted. V.42bis has been found to be most effective for file transfers that contain long strings of repetitive information and least effective for short strings of unique data. Require LAPM or MNP2, MNP3 or MNP4 as error correcting.

SIM

Subscriber Identity Module.

TA

Terminal Adaptor, which in most cases is a PCMCIA (Personal Computer Memory Card International Association) card.

TAE

Terminal Adaptor Equipment.

TE

Terminal Equipment, which in most cases is a computer.

Unsolicited result code

A message sent from the Infrared Modem to the PC that is not a response to an executed AT command. For example `RING`.

Index

Symbols

&C 274

&D 274

&F 39, 251

&I 252

* 42

*BINARY 169

*CRING 258

*EACS 235

*EAID 224

*EALR 187

*EALS 77

*EAM 220

*EAMS 190

*EAPN 211

*EAPS 209

*EARS 188

*EASM 222

*EAST 221

*EBCA 213, 218

*ECAM 118

*ECAR 177

*ECAS 183

*ECAV 141

*ECAW 178

*ECBP 194

*ECMW 247

*ECSP 78

*ECUR 196

*EDIF 89

*EDIS 90

*EDME 119

*EENL 197

*EKSC 219

*EKSP 199

*EKSR 200

*ELAN 120

*ELIN 79

*EMAR 122

*EMIC 202

*EMIR 189

*EMLR 248

*EPEC 203

*EPED 205

*EPEE 204

*EPEV 218

*EPEW 207

*EPHD 193

*EPNR 80

*EPNW 82

*EPRR 179

*EPRW 181

*EQVL 216

*ERIL 123

*ERIN 125

*ERIP 126

*ESAM 132

*ESBL 133

*ESCN 84

*ESDF 134

*ESIL 127

*ESKL 128

*ESKS 129

*ESLN	83	+CGSN	42
*ESMA	130	+CHUP	44
*ESMM	131	+CIEV	140
*ESNU	212	+CIMI	186
*ESOM	135	+CIND	106
*ESTF	137	+CKEV	139
*ESVM	87	+CKPD	105
*ETXT	138	+CLCK	97
*EVA	233	+CLIP	91, 110
*EVD	233	+CLIR	65
*EVH	233	+CMEE	289
*EVOLC	218	+CMER	115
*EXVC	217	+CMGD	155
*EYDO	241	+CMGF	156
*EYPI	242	+CMGL	148
*EYRE	240	+CMGR	150
*EYRR	238	+CMGS	152
*EYRV	241	+CMGW	154
+CACM	75	+CMOD	43
+CALA	185	+CMS	167
+CAMM	76	+CMSS	153
+CAOC	58	+CMT	166
+CBC	112	+CMTI	165
+CBM	164	+CMUX	234
+CBST	265	+CNMI	162
+CCFC	67	+CNUM	62
+CCLK	184	+COPS	62
+CCWA	69, 92	+CPAS	108
+CEER	284	+CPBF	173
+CFUN	50	+CPBR	171
+CGMI	40	+CPBS	170
+CGMM	40	+CPBW	175
+CGMR	41	+CPIN	110

+CPMS 146	+FCTCRTY 310
+CPUC 86	+FDCC 312
+CPWD 100	+FDCS 315
+CR 256	+FDFFC 311
+CRC 45, 257	+FDIS 316
+CREG 91	+FDR 318
+CRES 161	+FDT 320
+CRING 47	+FECM 322
+CRLP 264	+FET 323
+CSAS 160	+FK 324
+CSCA 157	+FLID 324
+CSCB 159	+FLNFC 325
+CSCC 231	+FLPL 326
+CSCS 37, 249	+FMDL 327
+CSMS 144	+FMFR 327
+CSQ 114	+FMI 291
+CSSI 94	+FMINS 328
+CSSN 73	+FMM 291
+CSSU 93	+FMR 292
+CVIB 117	+FPHCTO 329
+DR 287	+FPTS 330
+DS 285	+FRBC 331
+FAA 298	+FREL 332
+FAXERR 299	+FREV 331
+FBADLIN 302	+FRH 296
+FBADMUL 303	+FRM 295
+FBOR 304	+FRS 293
+FBUF 305	+FSPL 333
+FBUG 306	+FTBC 334
+FCIG 309	+FTH 296
+FCLASS 290, 297	+FTM 294
+FCQ 307	+FTS 292
+FCR 308	+FVRFC 335

+FWDFC 336
+GCAP 255
+GMI 253
+GMM 253
+GMR 42, 254
+IFC 275
+VTS 46
+WS46 102

A

A command 48, 259
abort 245
accessory additional indication 228
accessory input dialog indication 229
accessory menu indication 228
analog 337
ASCII 337
Asynchronous communication 337
AT 38, 250
AT command set 337
AT Commands 17
AT commands 337
 data compression 285
 data compression reporting 287
 escape sequence character 267
 list of AT commands 24
 modem information 255

 standard format 21
 viewing set parameters 23
AT Commands Modem Active 249
AT Commands Modem Terminated 249
AT Commands Phone Terminal Terminated 37
audio line response 195
auto-answer mode 337

B

bits per second 338
bps 338
BUSY result code 12

C

carrier 338
carrier detect 338
CCITT 338, 340, 342
CD 338
Cellular result codes 16
cellular result codes 16
COM port 338
command line 338
command state 338
commands
 command line 21
configuring
 configuring software manually 8, 9
 for data communications 8

- for facsimile communications [9](#)
- for V.25ter [8](#)
- CONNECT + SPEED result code [12](#)
- CONNECT result code [12](#)
- CTS [339](#)

D

- D command [49](#), [260](#)
- data compression AT command [285](#)
- data compression indication [288](#)
- data compression reporting AT command [287](#)
- data, configuring for data [8](#)
- DCD [339](#)
- DCE [339](#)
- default setting [339](#)
 - factory default settings [341](#)
- delete entry [244](#)
- delete phone [246](#)
- digital transmission [339](#)
- drivers, installing software
 - drivers [8](#)
- DSR [340](#)
- DTE [340](#)
- DTR [340](#)

E

- E command [55](#), [271](#)
- EIA [340](#)
- EOL [340](#)
- EOM [340](#)
- EOP [340](#)
- Ericsson divert function [95](#)
- ERROR result code [11](#)
- escape code [340](#)
- escape sequence character
 - AT command [267](#)

F

- facsimile
 - configuring for facsimile [9](#)
- facsimile functions
 - in Infrared modem [7](#)
- final result code [341](#)
- flow control [341](#)
- full duplex [341](#)

G

- get phones [245](#)

H

- H command [48](#), [259](#)
- half duplex [341](#)

I

- I [252](#)
- Infrared modem

- configuring software manually [8](#), [9](#)
- configuring the software [8](#)
- data functions [7](#)
- facsimile functions [7](#)
- introduction to Infrared modem [7](#)
- locating a driver [8](#)
- mobile phone manager [7](#)
- init string [8](#)
- installing software drivers [8](#)
- intermediate result code [341](#)
- introduction to Infrared modem [7](#)
- ISDN [341](#)
- ITU-T [342](#)
- L**
- L command [51](#)
- M**
- M command [282](#)
- manual configuring for the Infrared modem [8](#)
- ME [342](#)
- MMI [342](#)
- mobile phone manager [7](#)
- modem [342](#)
- modem information AT commands [255](#)
- MS [342](#)
- music mute indication response [195](#)
- N**
- NO CARRIER result code [12](#)
- NO DIALTONE result code [12](#)
- O**
- O command [262](#)
- off hook [342](#)
- OK result code [10](#)
- on hook [342](#)
- On-line data mode [339](#)
- P**
- P command [262](#)
- parameters
 - viewing the settings [23](#)
- PDA [343](#)
- Phonebook Commands [170](#)
- PIN [343](#)
- play phonebook entry [243](#)
- play prompt [243](#)
- play training recording [244](#)
- protocols [343](#)
- Q**
- Q command [56](#), [272](#)

R

- recognise [243](#)
- register phone [246](#)
- result code [343](#)
 - *EAAI [228](#)
 - *EAIL [229](#)
 - *EALV [195](#)
 - *EAMI [228](#)
 - *EDIF [95](#)
 - *EMIV [195](#)
 - *EYAB [245](#)
 - *EYDE [244](#)
 - *EYDP [246](#)
 - *EYGP [245](#)
 - *EYPE [243](#)
 - *EYPP [243](#)
 - *EYPT [244](#)
 - *EYRE [243](#)
 - *EYRP [246](#)
 - *EYSR [245](#)
 - *EYSS [246](#)
 - *EYTN [244](#)
- +CRC [16](#)
- +DR [288](#)
- abort [245](#)
- accessory additional indication [228](#)
- accessory input dialog indication [229](#)
- accessory menu indication [228](#)
- audio line [195](#)
- BUSY [12](#)
- cellular [16](#)
- compression [288](#)
- CONNECT [12](#)
- delete entry [244](#)
- delete phone [246](#)
- enabling/disabling [12](#)
- Ericsson divert function [95](#)
- ERROR [11](#)
- final [341](#)
- format [12](#)
- from AT commands [10](#)
- from call connections [12](#)
- get phones [245](#)
- intermediate [341](#)
- music mute [195](#)
- NO CARRIER [12](#)
- NO DIALTONE [12](#)
- OK [10](#)
- play phonebook entry [243](#)
- play prompt [243](#)
- play training recording [244](#)
- recognise [243](#)
- register phone [246](#)
- RING [12](#)
- save recording [245](#)
- start synchronise [246](#)
- train name [244](#)
- unsolicited [345](#)
- verbose/numeric [12](#)
- Result codes [10](#)
- RING [51](#)
- RING result code [12](#)
- RLP [343](#)

RLSD [343](#)

RS-232-C interface [343](#)

RTS [343](#)

S

S0 [277](#)

S10 [281](#)

S2 [267](#)

S3 [268](#)

S4 [53](#), [269](#)

S5 [54](#), [270](#)

S6 [278](#)

S7 [279](#)

S8 [280](#)

save recording [245](#)

serial port [344](#)

Service report [16](#)

setup string [8](#)

short message service [7](#), [344](#)

SIM [344](#)

SMS [7](#)

start synchronise [246](#)

T

T command [262](#)

TA [345](#)

TAE [345](#)

TE [345](#)

train name [244](#)

U

unsolicited result code [345](#)

V

V [57](#)

V command [57](#), [273](#)

V.22bis [344](#)

V.25ter [8](#)

V.27ter [344](#)

V.29 [344](#)

V.42bis [344](#)

X

X command [283](#)

Z

Z command [38](#), [250](#)